

ASUS

A451, A451C, A451CA, A451L, A451LA, A451LB, A451LN, A451LN-WX028D, A451M, A451MA, A451MAV, A551, A551C, A551CA, A551L, A551LN, A551LN-XX173H, D450, D450C, D450CA, D450CA-AH21, D450LA, D450LC, D450M, D450MA, D550, D550CA, D550CA-BH31, D550CA-MH31, D550CA-RS31, D550CA-SX199D, D550CA-SX281H, D550M, D550MA, D550MA-DS01, F451, F451C, F451CA, F451CA-VX124D, F451CA-VX152D, F451CA-VX153D, F451M, F451MA, F451MA-VX015H, F451MA-VX073H, F451MA-VX076H, F451MA-VX084H, F451MA-VX106H, F551MAV-BING-SX1008B, F551MAV-BING-SX395B, F551MAV-BING-SX998B, F751L, F751LA, F751LAV, F751LAV-TY435, F751LD, F751LD-TY081H, F751LD-TY252H, F751LD-TY252H-8, F751LDV-TY178H, F751LDV-TY231H, F751LDV-TY326H, F751LDV-TY326H-8, K451L, K451LA, K451LA-WX097D, K451LA-WX113H, K451LA-WX146D, K451LA-WX147D, K451LA-WX194H, K451LB, K451LB-WX060D, K451LN, K451LN-WX111D, K451LN-WX157H, K551, K551L, K551LB, K551LB-XX180D, K551LB-XX180D-12, K551LB-XX180D-8, K551LB-XX180H, K551LB-XX180H-12, K551LB-XX180H-8, K551LB-XX180V, K551LB-XX180V-12, K551LB-XX180V-8, K551LN, K551LN-XX137, K551LN-XX138, K551LN-XX138H, P451, P451C, P451CA, P551, P551C, P551CA, R411, R411C, R411CA, R411CA-MNC4-H-BLK, R411CA-VX168H, R411M, R411MA, R411MA-VX088H, R411MA-VX105H, R451, R451L, R451LA, R451LB, R451LN, R451LN-CA092H, R451LN-CA092H-8, R453LA, R453LA-WX080H, R453LA-WX124H, R453LB, R453LN, R453LN-WX060, R453LN-WX060H, R453LN-WX084H, R453LN-WX087H, R453LN-WX090H, R508, R508C, R508CA, R508CA-CJ113H, R508CA-CJ122H, R509, R512, R512C, R512CA, R512CA-SX134B, R512CA-SX134D, R512CA-SX134H, R512M, R512MA, R512MA-SX242HS, R551, R551L, R551LA, R551LB, R551LN, R552, R552J, R552JK, R552JK-CN089H, R552JV, R552JV-CM272H, R552JV-CM323H, R552JV-CN195H, R552L, R552LF, R553LB, R553LB-XX247D, R553LB-XX247D-12, R553LB-XX247D-8, R553LB-XX247H, R553LB-XX247H-12, R553LB-XX247H-8, R553LB-XX247V, R553LB-XX292D, R553LB-XX292H, R553LN, R553LN-XO370H, R553LN-XX134, R553LN-XX134-12, R553LN-XX134-8, R553LN-XX134H, R553LN-XX134H-12, R553LN-XX134H-8, R553LN-XX136, R553LN-XX136-12, R553LN-XX136-8, R553LN-XX136H, R553LN-XX136H-8, X451CA-VX007H, X451CA-VX026D, X451CA-VX026H, X451CA-VX036H, X451CA-VX037D, X451CA-VX038G, X451CA-VX050H, X451CA-VX057D, X451CA-VX065D, X451CA-VX066D, X451CA-VX067D, X451CA-VX078D, X451CA-VX104H, X451M, X751, X751L, X751LA, X751LA-TY033H, X751LA-TY318H, X751LA-XS51, X751LD, X751LD-TY062H, X751LD-TY072, X751LJ, X751LJ-T4043H, X751LJ-TY060H, X751LJ-TY148H, X751LK, X751LK-T4007D, X751LK-T4007D-12, X751LK-T4007D-4, X751LK-T4007H, X751LN-TY092D, X751LN-TY092D-12, X751LN-TY092D-8, X751LN-TY092H, X751LN-TY092H-12, X751LN-TY092H-8

SERIA VIVOBOK

F551C, F551CA, F551CA-FH31, F551CA-SX040D, F551CA-SX040H, F551CA-SX079D, F551CA-SX079H, F551CA-SX080D, F551CA-SX080H, F551CA-SX154H, F551CA-SX167H, F551CA-SX241H, F551M, F551MA, F551MA-SX033D, F551MA-SX033H, F551MA-SX062H, F551MA-SX063H, F551MA-SX080H, F551MAV, F551MAV-DB02-B, F551MAV-SD522B, F551MAV-SX, F551MAV-SX1002B, X451, X451C, X451CA, X451CA-VX013H, X451CA-VX032D, X451CA-VX034H, X451CA-VX036D, X451CA-VX039H, X451CA-VX092H, X451CA-VX140D, X451MA, X451MA-VX027H, X451MA-VX048D, X451MA-VX117H, X451MA-VX118H, X451MA-VX303D, X451MAV, X451MAV-VX297D, X551, X551C, X551CA, X551CA-0051A2117U, X551CA-DH21, X551CA-SI30403X, X551CA-SX024H, X551CA-SX029H, X551CARF-HCL1201L, X551M, X551MA, X551MA-DS21Q, X551MA-QSP1-CB, X551MA-RCLN03, X551MA-SX018H, X551MA-SX019D, X551MA-SX020D, X551MA-SX030D, X551MA-SX030H, X551MA-SX035D, X551MA-SX036D