

## **DELL**

### **SERIA INSPIRON**

14-3421, 14-3437, 14-5421, 14-N3421, 14-N5421, 15-1545, 15-1546, 15-1564, 15-3520, 15-3521, 15-3537, 1545, 1546, 1564, 15R-3521, 15R-3537, 15R-5521, 15R-5537, 15R-N3521, 15R-N5521, 15R-N5537, 17-3721, 17-3737, 17-5721, 17-N3721, 17-N3737, 17-N5721, 17R-3721, 17R-3737, 17R-5721, 17R-5737, 17R-N3721, 17R-N3737, 17R-N5721, 17R-N5737, 3421, 3437, 3520, 3521, 3537, 3721, 3737, 5521, 5537, 5721, 5737, N3521, N3537, N3721, N3737, N5521, N5537, N5721, N5737

### **SERIA LATITUDE**

14 3000, 15 3000, 3440, 3540, E3440, E3540

### **SERIA VOSTRO**

2421, 2521