

HP

Seria Pavilion

14-B004TX, 14-B006TX, 14-B024AU, 14-B025TX, 14-B026TX, 14-B033TU, 14-B042TU, 14-B119AU, 14-B121AU, 14-B131TU,

Seria Pavilion Sleekbook

14, 14-1000, 14-B000, 14-B000EO, 14-B000SG, 14-B000SS, 14-B001AU, 14-B001EA, 14-B001SA, 14-B001TX, 14-B002EA, 14-B002EO, 14-B002TX, 14-B003AU, 14-B006AU, 14-B006TU, 14-B009TU, 14-B010AU, 14-B010US, 14-B012TU, 14-B013CL, 14-B013NR, 14-B014TU, 14-B015DX, 14-B017NR, 14-B019US, 14-B022AU, 14-B023AU, 14-B026AU, 14-B028AU, 14-B029AU, 14-B029TU, 14-B030TX, 14-B031TU, 14-B031US, 14-B032TX, 14-B034TU, 14-B035TU, 14-B051TU, 14-B052TU, 14-B054TU, 14-B056TU, 14-B070ED, 14-B090SD, 14-B100EK, 14-B101EIA, 14-B102ED, 14-B102XX, 14-B105AU, 14-B106AU, 14-B107AU, 14-B108AU, 14-B108SA, 14-B109TX, 14-B110AU, 14-B110SA, 14-B110SO, 14-B111AU, 14-B112AU, 14-B113AU, 14-B114AU, 14-B116AU, 14-B117AU, 14-B120AU, 14-B120DX, 14-B128TU, 14-B130TU, 14-B140EF, 14-B145TX, 14-B150EJ, 14-B151TU, 14-B154LA, 14-B155LA, 14-B162LA, 14-B164LA, 14Z-B000, 14Z-B100 CTO, 15, 15-2099, 15-B000ED, 15-B000EM, 15-B000ES, 15-B000EV, 15-B000SH, 15-B000SQ, 15-B000SS, 15-B001EIA, 15-B001EM, 15-B001EU, 15-B001EV, 15-B001SH, 15-B001SIA, 15-B001SU, 15-B001TU, 15-B002EE, 15-B002EJ, 15-B002EM, 15-B002EQ, 15-B002SE, 15-B002SH, 15-B002SM, 15-B002SQ, 15-B002TU, 15-B002TX, 15-B003EIA, 15-B003EM, 15-B003EV, 15-B003SE, 15-B003SIA, 15-B003SQ, 15-B003TX, 15-B004EV, 15-B005EJ, 15-B006ED, 15-B006SE, 15-B007SX, 15-B008TU, 15-B009SE, 15-B010EJ, 15-B010EW, 15-B010SW, 15-B010US, 15-B011ST, 15-B012NR, 15-B013EI, 15-B020ET, 15-B020SW, 15-B025EC, 15-B027EL, 15-B030EB, 15-B030EL, 15-B033EL, 15-B036EZ, 15-B040SL, 15-B041SB, 15-B044SF, 15-B050EA, 15-B050EW, 15-B050SR, 15-B051EL, 15-B051SR, 15-B053EA, 15-B055CA, 15-B058SR, 15-B061EL, 15-B070SL, 15-B079ER, 15-B086SR, 15-B100EJ, 15-B100EU, 15-B100SJ, 15-B100SQ, 15-B100SY, 15-B101SH, 15-B101SP, 15-B102ED, 15-B102EU, 15-B102SQ, 15-B103AU, 15-B104SP, 15-B105EU, 15-B105SF, 15-B105SP, 15-B105SW, 15-B106EV, 15-B107SL, 15-B109SX, 15-B110EX, 15-B110SX, 15-B113TU, 15-B114TU, 15-B115EL, 15-B116EL, 15-B117SS, 15-B118SS, 15-B119SS, 15-B120LA, 15-B121EL, 15-B122EE, 15-B123ES, 15-B123TU, 15-B125SL, 15-B127TU, 15-B129EL, 15-B129SR, 15-B130SW, 15-B133ES, 15-B135SB, 15-B137SS, 15-B139TU, 15-B140EL, 15-B141EL, 15-B146EA, 15-B148EF, 15-B150EJ, 15-B150SG, 15-B150ST, 15-B152EO, 15-B152SO, 15-B153SO, 15-B155SC, 15-B156SG, 15-B160SJ, 15-B172ED, 15-B179ER, 15-B191SG, 15T-B000,

Seria pavilion touchsmart

14-B111SE, 14-B115EJ, 14-B137CA, 14-B142TU, 14-B150TU, 14-B159TU, 14-B163TX, 14T-B100 CTO, 15-B102AU, 15-B103AU, 15-B105ED, 15-B107AU, 15-B109WM, 15-B115TX, 15-B119EE, 15-B120EJ, 15-B121TX, 15-B124SS, 15-B130SA, 15-B140CA, 15-B149CA, 15-B151EX, 15-B153EF, 15-B154EE, 15-B155SW, 15-B160EA, 15-B161EA, 15-B167CA, 15-B193EG,

Seria Pavilion Ultrabook

14, 14-B002EO, 14-B005SA, 14-B027TU, 14-B036TU, 14-B110TX, 14-B121TX, 15, 15-B104EO,