

- Acer Aspire 4250
- Acer Aspire 4333
- Acer Aspire 4339
- Acer Aspire 4349
- Acer Aspire 4352
- Acer Aspire 4625
- Acer Aspire 4733Z
- Acer Aspire 5250
- Acer Aspire 5252
- Acer Aspire 5333
- Acer Aspire 5336
- Acer Aspire 5349
- Acer Aspire 5350
- Acer Aspire 7251
- Acer Aspire AS4250-C52G25Mikk
- Acer TravelMate 4370
- Acer TravelMate 4750
- Acer TravelMate 7340
- Acer Aspire 4253
- Acer Aspire 4253G
- Acer Aspire 4551
- Acer Aspire 4551G
- Acer Aspire 4551G-P322G32Mn
- Acer Aspire 4552
- Acer Aspire 4552-5078
- Acer Aspire 4552G
- Acer Aspire 4560
- Acer Aspire 4560G
- Acer Aspire 4738
- Acer Aspire 4738G
- Acer Aspire 4738Z
- Acer Aspire 4738ZG
- Acer Aspire 4739
- Acer Aspire 4739Z
- Acer Aspire 4741
- Acer Aspire 4741G
- Acer Aspire 4741G-332G32Mnsk
- Acer Aspire 4741G-332G50Mn
- Acer Aspire 4741G-372G50Mnkk02
- Acer Aspire 4741G-372G50Mnkk06
- Acer Aspire 4741G-432G50Mnkk01
- Acer Aspire 4741G-5452G50Mnkk04
- Acer Aspire 4741G-5462G50Mnkk05
- Acer Aspire 4741G-5464G50Mn
- Acer Aspire 4741Z, Aspire 4741ZG
- Acer Aspire 4741ZG-P602G50Mnkkc
- Acer Aspire 4741ZG-P622G50Mnkk03
- Acer Aspire 4743
- Acer Aspire 4743G
- Acer Aspire 4743Z

- Acer Aspire 4743ZG
- Acer Aspire 4750
- Acer Aspire 4750G
- Acer Aspire 4750ZG
- Acer Aspire 4752
- Acer Aspire 4752G
- Acer Aspire 4752Z
- Acer Aspire 4752ZG
- Acer Aspire 4755
- Acer Aspire 4755G
- Acer Aspire 4755ZG
- Acer Aspire 4771
- Acer Aspire 4771G
- Acer Aspire 4771Z
- Acer Aspire 5251
- Acer Aspire 5251-1005
- Acer Aspire 5251-1549
- Acer Aspire 5253
- Acer Aspire 5253G
- Acer TravelMate 5335
- Acer TravelMate 5335G
- Acer TravelMate 5335Z
- Acer TravelMate 5542
- Acer TravelMate 5542G
- Acer Aspire 5551
- Acer Aspire 5551-2013
- Acer Aspire 5551-2036
- Acer Aspire 5551-2805
- Acer Aspire 5551-4200
- Acer Aspire 5551-4937
- Acer Aspire 5551G
- Acer Aspire 5551G-4280
- Acer Aspire 5551G-4591
- Acer Aspire 5551G-P324G32Mn
- Acer Aspire 5551-P323G32Mnsk
- Acer Aspire 5552
- Acer Aspire 5552G
- Acer Aspire 5560
- Acer Aspire 5560 V3
- Acer Aspire 5560G
- Acer Aspire 5733
- Acer Aspire 5733Z
- Acer Aspire 5736
- Acer Aspire 5736G
- Acer Aspire 5736Z
- Acer Aspire 5736ZG
- Acer Aspire 5741
- Acer Aspire 5741-332G25Mn
- Acer Aspire 5741-333G32Mn
- Acer Aspire 5741-334G32Mn

- Acer Aspire 5741-334G50Mn
- Acer Aspire 5741-3404
- Acer Aspire 5741-3541
- Acer Aspire 5741-433G32Mn
- Acer Aspire 5741-434G50Mn
- Acer Aspire 5741-5698
- Acer Aspire 5741-5763
- Acer Aspire 5741G
- Acer Aspire 5741G-332G50Mn
- Acer Aspire 5741G-333G32Bn
- Acer Aspire 5741G-334G50Mn
- Acer Aspire 5741G-334G64Mn
- Acer Aspire 5741G-434G64Bn
- Acer Aspire 5741G-5452G50Mnck
- Acer Aspire 5741G-5452G50Mnkk
- Acer Aspire 5741G-5452G50Mnsk
- Acer Aspire 5741Z
- Acer Aspire 5741ZG
- Acer Aspire 5742
- Acer Aspire 5742G
- Acer Aspire 5742Z
- Acer Aspire 5742ZG
- Acer Aspire 5750
- Acer Aspire 5750G
- Acer Aspire 5750G-2312G50
- Acer Aspire 5750TG
- Acer Aspire 5750Z
- Acer Aspire 5750ZG
- Acer Aspire 5755
- Acer Aspire 5755G
- Acer Aspire 5755Z
- Acer Aspire 5755ZG
- Acer Aspire 7551
- Acer Aspire 7551-2755
- Acer Aspire 7551-3068
- Acer Aspire 7551-3416
- Acer Aspire 7551-3634
- Acer Aspire 7551-5358
- Acer Aspire 7551G
- Acer Aspire 7551G-5407
- Acer Aspire 7551G-5821
- Acer Aspire 7551G-6477
- Acer Aspire 7551Z
- Acer Aspire 7551ZG
- Acer Aspire 7552G
- Acer Aspire 7552G-5107
- Acer Aspire 7552G-5488
- Acer Aspire 7552G-6061
- Acer Aspire 7560
- Acer Aspire 7560G

- Acer Aspire 7741
- Acer Aspire 7741-333G25Mn
- Acer Aspire 7741-5137
- Acer Aspire 7741-7870
- Acer Aspire 7741G
- Acer Aspire 7741G-333G25Bn
- Acer Aspire 7741G-333G32Mn
- Acer Aspire 7741G-334G50Mn
- Acer Aspire 7741G-3647
- Acer Aspire 7741G-374G64Mn
- Acer Aspire 7741G-434G50Mn
- Acer Aspire 7741G-464G64Mn
- Acer Aspire 7741G-7017
- Acer Aspire 7741Z
- Acer Aspire 7741Z-4475
- Acer Aspire 7741Z-4592
- Acer Aspire 7741Z-4633
- Acer Aspire 7741Z-4643
- Acer Aspire 7741Z-4815
- Acer Aspire 7741Z-5731
- Acer Aspire 7741ZG
- Acer Aspire 7741ZG-P604G50Mn
- Acer Aspire 7741Z-P614G50Mn
- Acer Aspire 7750
- Acer Aspire 7750G
- Acer Aspire 7750Z
- Acer Aspire 7750ZG
- Acer Aspire AS5250-C52G25Mikk
- Acer Aspire AS5250-C53G25Mikk
- Acer Aspire AS5250-E352G32Mikk
- Acer Aspire AS5253-C52G32Mnkk
- Acer Aspire AS5253-C54G50Mnkk
- Acer Aspire AS5253-E353G32Mnrr
- Acer Aspire AS5253-E354G32Mnkk
- Acer Aspire AS5741
- Acer Aspire AS5741-H32C/S
- Acer Aspire AS5741-H32C/SF
- Acer Aspire AS5741-H54D/LS
- Acer Aspire AS5741-H54D/S
- Acer Aspire AS5741-H54D/SF
- Acer Aspire AS5741-N32C/KF
- Acer Aspire AS5741-N32D/K
- Acer Aspire AS5741-N54E/K
- Acer Aspire AS5741-N54E/KF
- Acer TravelMate 4740
- Acer TravelMate 4740-352G32Mn
- Acer TravelMate 4740-432G50Mna
- Acer TravelMate 4740-5261
- Acer TravelMate 4740-5452G50Mnssb
- Acer TravelMate 4740-5462G50Mnss02

- Acer TravelMate 4740-7552
- Acer TravelMate 4740-7787
- Acer TravelMate 4740G
- Acer TravelMate 4740Z
- Acer Travelmate 5735
- Acer TravelMate 5735Z
- Acer Travelmate 5735ZG
- Acer TravelMate 5340
- Acer TravelMate 5340G
- Acer TravelMate 5740
- Acer TravelMate 5740-332G16Mn
- Acer TravelMate 5740-332G25Mn
- Acer TravelMate 5740-333G25Mn
- Acer TravelMate 5740-333G32Mn
- Acer TravelMate 5740-352G25Mn
- Acer TravelMate 5740-372G25Mnss
- Acer TravelMate 5740-434G32Mn
- Acer TravelMate 5740-5092
- Acer TravelMate 5740-524G32Mn
- Acer TravelMate 5740-5896
- Acer TravelMate 5740-5952
- Acer TravelMate 5740-6070
- Acer TravelMate 5740-6291
- Acer TravelMate 5740-6529
- Acer TravelMate 5740G
- Acer TravelMate 5740G-334G32Mn
- Acer TravelMate 5740G-434G32Mn
- Acer TravelMate 5740G-524G50Mn
- Acer TravelMate 5740G-528G64Mn
- Acer TravelMate 5740G-5452G32Mnss
- Acer TravelMate 5740G-6765
- Acer Travelmate 5740Z
- Acer TravelMate 5740Z-P602G25Mn
- Acer TravelMate 5740Z-P604G32Mnss
- Acer TravelMate 5742
- Acer TravelMate 5742-372G25Mn
- Acer TravelMate 5742-373G32Mn
- Acer TravelMate 5742-463G32Mn
- Acer TravelMate 5742-5562G50Mnss01
- Acer TravelMate 5742-7013
- Acer TravelMate 5742-7159
- Acer TravelMate 5742-7399
- Acer TravelMate 5742-7906
- Acer TravelMate 5742-7908
- Acer TravelMate 5742G
- Acer TravelMate 5742Z
- Acer TravelMate 5742Z-4693
- Acer TravelMate 5742ZG
- Acer TravelMate 5744
- Acer TravelMate 5744G

- Acer TravelMate 5744Z
- Acer Travelmate 5760
- Acer Travelmate 5760G
- Acer TravelMate 6495
- Acer TravelMate 6495G
- Acer TravelMate 6495T
- Acer TravelMate 6495TG
- Acer TravelMate 6595
- Acer TravelMate 6595G
- Acer TravelMate 6595T
- Acer TravelMate 6595TG
- Acer TravelMate 7740
- Acer TravelMate 7740-352G32Mn
- Acer TravelMate 7740-353G25Mnss
- Acer TravelMate 7740-434G32Mnss
- Acer TravelMate 7740G
- Acer TravelMate 7740G-434G50Mnss
- Acer TravelMate 7740ZG-P604G50Mnss
- Acer TravelMate 7740Z-P604G32Mnss
- Acer TravelMate 7740Z
- Acer TravelMate 7740ZG
- Acer Travelmate 7750
- Acer TravelMate 7750G
- Acer TravelMate 7750Z
- Acer TravelMate 8472 HF
- Acer TravelMate 8472
- Acer TravelMate 8472G HF
- Acer TravelMate 8472G
- Acer TravelMate 8472T HF
- Acer TravelMate 8472T
- Acer TravelMate 8472TG HF
- Acer TravelMate 8472TG
- Acer TravelMate 8473
- Acer TravelMate 8473TG
- Acer TravelMate 8572
- Acer TravelMate 8572
- Acer TravelMate 8572G
- Acer TravelMate 8572T HF
- Acer TravelMate 8572T
- Acer TravelMate 8572TG
- Acer TravelMate 8573
- Acer TravelMate 8573G
- Acer TravelMate 8573T
- Acer TravelMate 8573TG
- Acer TravelMate TM5740
- Acer TravelMate TM5740-X322
- Acer TravelMate TM5740-X322D
- Acer TravelMate TM5740-X322DF
- Acer TravelMate TM5740-X322DHBF
- Acer TravelMate TM5740-X322DOF

- Acer TravelMate TM5740-X322DPF
- Acer TravelMate TM5740-X322F
- Acer TravelMate TM5740-X322HBF
- Acer TravelMate TM5740-X322OF
- Acer TravelMate TM5740-X322PF
- Acer TravelMate TM5740-X522
- Acer TravelMate TM5740-X522D
- Acer TravelMate TM5740-X522DF
- Acer TravelMate TM5740-X522DHBF
- Acer TravelMate TM5740-X522DOF
- Acer TravelMate TM5740-X522DPF
- Acer TravelMate TM5740-X522F
- Acer TravelMate TM5740-X522HBF
- Acer TravelMate TM5740-X522OF
- Acer TravelMate TM5740-X522PF
- Acer TravelMate TM5742
- Acer TravelMate TM5742-X732
- Acer TravelMate TM5742-X732D
- Acer TravelMate TM5742-X732DF
- Acer TravelMate TM5742-X732DHBF
- Acer TravelMate TM5742-X732DOF
- Acer TravelMate TM5742-X732DPF
- Acer TravelMate TM5742-X732F
- Acer TravelMate TM5742-X732HBF
- Acer TravelMate TM5742-X732OF
- Acer TravelMate TM5742-X732PF
- Acer TravelMate TM5742-X742
- Acer TravelMate TM5742-X742D
- Acer TravelMate TM5742-X742DF
- Acer TravelMate TM5742-X742DHBF
- Acer TravelMate TM5742-X742DOF
- Acer TravelMate TM5742-X742DPF
- Acer TravelMate TM5742-X742F
- Acer TravelMate TM5742-X742HBF
- Acer TravelMate TM5742-X742OF
- Acer TravelMate TM5742-X742PF
- Gateway NS41I
- Gateway NS51I
- Gateway NV50A
- Gateway NV51B
- Gateway NV55C
- Gateway NV59C
- Gateway NV73A
- Gateway NV49C
- Gateway NV49C13C
- Gateway NV49xx
- Gateway NV53
- Gateway NV53A
- Gateway NV53A11u

- Gateway NV79
- Gateway NV79C