

Lenovo Z70;Lenovo ThinkPad E465;Lenovo ThinkPad W550s;Lenovo PA-1650;Lenovo Z51;Lenovo ThinkPad X250;Lenovo Z50;Lenovo ThinkPad Edge;Lenovo G500;Lenovo B5400;Lenovo B5400 80B6;Lenovo G400;Lenovo G400 80A5;Lenovo G410;Lenovo G410 80A7;Lenovo G500 80A6;Lenovo G505;Lenovo G505 80AA;Lenovo G700;Lenovo G700 80AG;Lenovo G710;Lenovo G710 80AH;Lenovo M490;Lenovo M495;Lenovo M5400;Lenovo M5400 80B5;Lenovo ThinkPad L540;Lenovo ThinkPad T540p;Lenovo ThinkPad T550;Lenovo G500s;Lenovo G505s;Lenovo IdeaPad S510p;Lenovo IdeaPad S500;Lenovo ThinkPad P50s;Lenovo ThinkPad T560;Lenovo IdeaPad Yoga;Lenovo B50;Lenovo B51;Lenovo B70;Lenovo E50;Lenovo G50;Lenovo G51;Lenovo G70;Lenovo IdeaPad 300;Lenovo IdeaPad 305;Lenovo IdeaPad 500;Lenovo M50;Lenovo Ideapad Z710;Lenovo G40;Lenovo G400s;Lenovo G400s Touch;Lenovo G405s;Lenovo G405s Touch;Lenovo G41;Lenovo G410s;Lenovo G410s Touch;Lenovo G500s Touch;Lenovo G505s Touch;Lenovo IdeaPad S410p;Lenovo Z40;Lenovo Z41;Lenovo IdeaPad Flex;Lenovo ThinkPad L440;Lenovo ThinkPad T440P;Lenovo ThinkPad T540P;Lenovo IdeaPad Z410;Lenovo IdeaPad S310;Lenovo IdeaPad S410;Lenovo IdeaPad S400U;Lenovo ThinkPad E450;Lenovo ThinkPad E450c;Lenovo ThinkPad E455;Lenovo ThinkPad E460;Lenovo IdeaPad Z710;Lenovo ThinkPad E470;Lenovo ThinkPad E570;Lenovo ThinkPad X240;Lenovo B40;Lenovo B41;Lenovo E40;Lenovo Edge 2;Lenovo Flex 2;Lenovo Flex 3;Lenovo G400 14001;Lenovo G400 2048;Lenovo G400 59011;Lenovo G400S 80AU;Lenovo G500S 80AD;Lenovo G500S 80AV;Lenovo G505S 80AM;Lenovo IdeaPad 300S;Lenovo IdeaPad 500S;Lenovo IdeaPad Edge;Lenovo IdeaPad S400u;Lenovo IdeaPad S410P;Lenovo IdeaPad S510P;Lenovo IdeaPad U430;Lenovo IdeaPad U430P;Lenovo IdeaPad U530;Lenovo M41;Lenovo M4400;Lenovo M490S;Lenovo N40;Lenovo N50;Lenovo S41;Lenovo ThinkPad E475;Lenovo ThinkPad E550;Lenovo ThinkPad E550C;Lenovo ThinkPad E555;Lenovo ThinkPad E560;Lenovo ThinkPad E565;Lenovo ThinkPad E575;Lenovo ThinkPad Helix;Lenovo ThinkPad L450;Lenovo ThinkPad L460;Lenovo ThinkPad P40;Lenovo ThinkPad P50S;Lenovo ThinkPad S3;Lenovo ThinkPad S431;Lenovo ThinkPad S440;Lenovo ThinkPad S5;Lenovo ThinkPad S531;Lenovo ThinkPad S540;Lenovo ThinkPad T431s;Lenovo ThinkPad T440;Lenovo ThinkPad T450;Lenovo ThinkPad T450s;Lenovo ThinkPad T450S;Lenovo ThinkPad T460;Lenovo ThinkPad T460S;Lenovo ThinkPad W550S;Lenovo ThinkPad X1;Lenovo ThinkPad X260;Lenovo ThinkPad Yoga;Lenovo U31;Lenovo U41;Lenovo Yoga 13;Lenovo Yoga 2;Lenovo Yoga 500;Lenovo 36200124;Lenovo 36200235;Lenovo 36200249;Lenovo 36200251;Lenovo 36200253;Lenovo 36200607;Lenovo 36200611;Lenovo 45N0253;Lenovo 45N0254;Lenovo 45N0261;Lenovo 45N0262;Lenovo 45N0265;Lenovo 45N0266;Lenovo 45N0267;Lenovo 45N0268;Lenovo ADLX65NCC3A;Lenovo ADLX65NDC3A;Lenovo ADP;