

Asus F52;Asus F52A;Asus F52K;Asus F52Q;Asus K50;Asus K50A;Asus K50AB;Asus K50AD;Asus K50AE;Asus K50AF;Asus K50C;Asus K50E;Asus K50i;Asus K50iD;Asus K50ID;Asus K50IE;Asus K50iE;Asus K50IJ;Asus K50iJ;Asus K50IL;Asus K50iL;Asus K50IN;Asus K50iN;Asus K50IP;Asus K50iP;Asus K50X;Asus K51;Asus K51AB;Asus K51AC;Asus K51AE;Asus K51i;Asus K51iO;Asus K51Xi;Asus K60;Asus K60i;Asus K60I;Asus K60IJ;Asus K60iJ;Asus K60IL;Asus K60iN;Asus K60XI;Asus K61;Asus K61i;Asus K61iC;Asus K61IC;Asus K62;Asus K62F;Asus K62J;Asus K62JR;Asus K70;Asus K7010;Asus K70A;Asus K70AB;Asus K70AC;Asus K70AD;Asus K70AE;Asus K70AF;Asus K70AS;Asus K70AW;Asus K70i;Asus K70IC;Asus K70iC;Asus K70iD;Asus K70IJ;Asus K70iJ;Asus K70iL;Asus K70IO;Asus K70iO;Asus K70Y;Asus K70YD;Asus K70YT;Asus P50;Asus P50i;Asus P50IJ;Asus P50iJ;Asus P50iN;Asus Pro79;Asus Pro79A;Asus Pro79AB;Asus Pro79i;Asus X5;Asus X5A;Asus X5AVc;Asus X5AVn;Asus X5B;Asus X5BTp;Asus X5BVF;Asus X5BVN;Asus X5D;Asus X5DAB;Asus X5DAD;Asus X5DC;Asus X5DIJ;Asus X5DiJ;Asus X5DIN;Asus X5E;Asus X5EA;Asus X5EAC;Asus X5EAE;Asus X5G;Asus X5GA;Asus X5GAG;Asus X5GAT;Asus X5GV;Asus X5GVG;Asus X5GVT;Asus X5i;Asus X5iB;Asus X5iBY;Asus X5iD;Asus X5iDE;Asus X5iDR;Asus X5iDY;Asus X5iF;Asus X5iiN;Asus X5iJ;Asus X5iJB;Asus X5iJC;Asus X5iJE;Asus X5iJK;Asus X5iJR;Asus X5iJT;Asus X5iJU;Asus X5iJV;Asus X5iN;Asus X5J;Asus X5Ji;Asus X5JiJ;Asus X5JX;Asus X5K;Asus X5KF;Asus X5KJ;Asus X5KJC;Asus X5L;Asus X5LDA;Asus X5LJ;Asus X5LJT;Asus X5LJU;Asus X5LJV;Asus X5M;Asus X5MD;Asus X5MDA;Asus X5ME;Asus X5MF;Asus X5MJ;Asus X5MJC;Asus X5MJE;Asus X5MJF;Asus X5MJG;Asus X5MJH;Asus X5MJL;Asus X5MJN;Asus X5MJQ;Asus X5MJR;Asus X5MJT;Asus X5MJV;Asus X5MJX;Asus X5MN;Asus X70;Asus X70A;Asus X70AB;Asus X70AC;Asus X70AD;Asus X70AE;Asus X70AF;Asus X70E;Asus X70F;Asus X70FV;Asus X70I;Asus X70iC;Asus X70iD;Asus X70IJ;Asus X70iJV;Asus X70iL;Asus X70IO;Asus X70iS;Asus X70K;Asus X70KR;Asus X70L;Asus X70S;Asus X70SE;Asus X70SR;Asus X70Z;Asus Pro78VN;Asus A55;Asus A55A;Asus A55D;Asus A55DE;Asus A55DR;Asus A55E;Asus A55N;Asus A55V;Asus A55VD;Asus A55VJ;Asus A55VM;Asus A55VS;Asus A75;Asus A75A;Asus A75D;Asus A75DE;Asus A75V;Asus A75VD;Asus A75VJ;Asus A75VM;Asus K55VJ;Asus K55VS;Asus K55X;Asus K75;Asus K75A;Asus K75D;Asus K75DE;Asus K75V;Asus K75VB;Asus K75VD;Asus K75VJ;Asus K75VM;Asus K75VM-T2119V;Asus R500;Asus R500A;Asus R500D;Asus R500DE;Asus R500DR;Asus R500N;Asus R500V;Asus R500VD;Asus R500VJ;Asus R500VJ-SX121;Asus R500VJ-SX130H;Asus R500VM;Asus R500VM-SX070V;Asus R500VR;Asus R500VS;Asus R700;Asus R700A;Asus R700D;Asus R700DE;Asus R700V;Asus R700VD;Asus R700VJ;Asus R700VM;Asus U57;Asus U57A;Asus U57D;Asus U57DE;Asus U57DR;Asus U57N;Asus U57V;Asus U57VD;Asus U57VJ;Asus U57VM;Asus A52;Asus A52DE;Asus A52DR;Asus A52DY;Asus A52F;Asus A52J;Asus A52JA;Asus A52JB;Asus A52JC;Asus A52JE;Asus A52JK;Asus A52JR;Asus A53;Asus A53E;Asus A53F;Asus A53S;Asus A53SC;Asus A53SD;Asus A53SJ;Asus A53SK;Asus A53SV;Asus A53Z;Asus A54;Asus A54C;Asus A54H;Asus A54HO;Asus A54HR;Asus A72;Asus A72D;Asus A72DR;Asus A72DY;Asus A72F;Asus A72J;Asus A72JK;Asus A72JR;Asus A72JT;Asus A72JU;Asus A72K;Asus A73E;Asus A73SD;Asus A73SJ;Asus A73SM;Asus A73SV;Asus B53;Asus B53F;Asus B53J;Asus B53Xi;Asus F50;Asus F50GX;Asus F50N;Asus F50Q;Asus F50S;Asus F50SF;Asus F50Sf;Asus F50SF-A2;Asus F50SL;Asus F50SR;Asus F50SV;Asus F50SV-A2;Asus F50V;Asus F50VI;Asus F50VL;Asus F50Z;Asus F55;Asus F55A;Asus F55C;Asus F55CR;Asus F55U;Asus F55V;Asus F55VD;Asus F55VDR;Asus F70;Asus F70S;Asus F70SL;Asus F75A1;Asus F75VD;Asus F75VD1;Asus K52;Asus K52D;Asus K52DE;Asus K52DR;Asus K52DY;Asus K52E;Asus K52EQ;Asus K52F;Asus K52J;Asus K52JB;Asus K52JC;Asus K52JE;Asus K52JK;Asus K52JR;Asus K52JT;Asus K52JU;Asus K52JV;Asus K52N;Asus K52X;Asus K52Xi;Asus K53;Asus K53E;Asus K53F;Asus K53S;Asus K53SA;Asus K53SC;Asus K53SD;Asus K53SE;Asus K53SJ;Asus K53SK;Asus K53sk;Asus K53SM;Asus K53SN;Asus K53SU;Asus K53SV;Asus K53sv;Asus K53SV-SX071;Asus K53SV-SX121V;Asus K53Z;Asus K54;Asus K54C;Asus K54H;Asus K54HO;Asus K54HR;Asus K54HY;Asus K72;Asus K72D;Asus K72DR;Asus K72DY;Asus K72F;Asus K72FR;Asus K72FX1;Asus K72J;Asus K72JA;Asus K72JB;Asus K72JC;Asus K72JE;Asus K72JF;Asus K72JH;Asus K72JK;Asus K72JL;Asus

K72JM;Asus K72JO;Asus K72JQ;Asus K72JR;Asus K72JT;Asus K72JU;Asus K72JV;Asus K72JW;Asus K72K;Asus K72L;Asus K72N;Asus K72P;Asus K72Q;Asus K72R;Asus K72S;Asus K72Y;Asus K73E;Asus K73SV;Asus M60;Asus M60J;Asus M60JV;Asus M60Q;Asus M60SV;Asus M60V;Asus M60VA;Asus M60VP;Asus M60W;Asus M60Wi;Asus N50;Asus N50A;Asus N50E;Asus N50F;Asus N50Q;Asus N50SV;Asus N50T;Asus N50TA;Asus N50TP;Asus N50TR;Asus N50V;Asus N50VA;Asus N50VC;Asus N50VF;Asus N50VG;Asus N50VM;Asus N50VN;Asus N51;Asus N51A;Asus N51S;Asus N51T;Asus N51TE;Asus N51TP;Asus N51V;Asus N51VF;Asus N51VG;Asus N51VN;Asus N52;Asus N52A;Asus N52D;Asus N52DA;Asus N52DC;Asus N52DR;Asus N52F;Asus N52J;Asus N52JA;Asus N52JB;Asus N52JC;Asus N52JE;Asus N52JF;Asus N52JG;Asus N52JL;Asus N52JN;Asus N52JQ;Asus N52JT;Asus N52JV;Asus N52N;Asus N52S;Asus N52SN;Asus N52SV;Asus N52V;Asus N52VF;Asus N52X;Asus N52XN;Asus N53;Asus N53D;Asus N53DA;Asus N53E;Asus N53F;Asus N53J;Asus N53JC;Asus N53JE;Asus N53JF;Asus N53JG;Asus N53JH;Asus N53Ji;Asus N53JL;Asus N53JN;Asus N53JQ;Asus N53JR;Asus N53JT;Asus N53JV;Asus N53JX;Asus N53N;Asus N53S;Asus N53SD;Asus N53SL;Asus N53SM;Asus N53SN;Asus N53SQ;Asus N53SV;Asus N53SV-SX019;Asus N53T;Asus N53TA;Asus N53TK;Asus N53V;Asus N53X;Asus N53Xi;Asus N60;Asus N60D;Asus N60DP;Asus N60W;Asus N60WT;Asus N61;Asus N61D;Asus N61DA;Asus N61J;Asus N61JA;Asus N61JB;Asus N61JC;Asus N61JF;Asus N61JG;Asus N61JH;Asus N61JK;Asus N61JN;Asus N61JO;Asus N61JP;Asus N61JQ;Asus N61JQ-QB1;Asus N61JS;Asus N61JV;Asus N61JV-QHDB1;Asus N61JVg;Asus N61JW;Asus N61JX;Asus N61N;Asus N61Q;Asus N61V;Asus N61VA;Asus N61VF;Asus N61VG;Asus N61VJ;Asus N61VN;Asus N61VS;Asus N61W;Asus N61Wi;Asus N61WJ;Asus N61WN;Asus N61WP;Asus N70;Asus N70SV;Asus N71;Asus N71J;Asus N71JA;Asus N71JN;Asus N71JQ;Asus N71JV;Asus N71Jv;Asus N71V;Asus N71VG;Asus N71VN;Asus N71Y;Asus N71Yi;Asus N73;Asus N73F;Asus N73G;Asus N73J;Asus N73JF;Asus N73JF-TY020;Asus N73JG;Asus N73JH;Asus N73JN;Asus N73JQ;Asus N73JQ-A2;Asus N73Q;Asus N73S;Asus N73SD;Asus N73SL;Asus N73SM;Asus N73SN;Asus N73SQ;Asus N73SV;Asus N73SW;Asus N73V;Asus N73Y;Asus N73Yi;Asus N90;Asus N90S;Asus N90SC;Asus N90SV;Asus P52;Asus P52F;Asus P52JC;Asus P53;Asus P53E;Asus P53S;Asus P53SJ;Asus P53Xi;Asus Pro5A;Asus Pro5AV;Asus Pro5AVC;Asus Pro5AVN;Asus Pro5B;Asus Pro5BV;Asus Pro5BVF;Asus Pro5BVG;Asus Pro5DiD;Asus Pro5DiE;Asus Pro5DiJ;Asus Pro5DiL;Asus Pro5DiN;Asus Pro5DiP;Asus Pro5E;Asus Pro5EA;Asus Pro5EAC;Asus Pro5EAE;Asus Pro5G;Asus Pro5GA;Asus Pro5GAG;Asus Pro5GAT;Asus Pro5GV;Asus Pro5GVG;Asus Pro5GVS;Asus Pro5GVT;Asus Pro5i;Asus Pro5iB;Asus Pro5iBY;Asus Pro5iD;Asus Pro5iDE;Asus Pro5iDR;Asus Pro5iDY;Asus Pro5iF;Asus Pro5iJ;Asus Pro5iJB;Asus Pro5iJC;Asus Pro5iJE;Asus Pro5iJK;Asus Pro5iJR;Asus Pro5iJT;Asus Pro5iJU;Asus Pro5iJV;Asus Pro5iN;Asus Pro5J;Asus Pro5Ji;Asus Pro5JiJ;Asus Pro5K;Asus Pro5KF;Asus Pro5KJ;Asus Pro5KJC;Asus Pro5L;Asus Pro5LJ;Asus Pro5LJT;Asus Pro5LJU;Asus Pro5LJV;Asus Pro5N;Asus Pro5NB;Asus Pro5NBE;Asus Pro5NBR;Asus Pro5NBY;Asus Pro5NE;Asus Pro5NS;Asus Pro5NSC;Asus Pro5NSD;Asus Pro5NSJ;Asus Pro5NSK;Asus Pro5NSM;Asus Pro5NSV;Asus Pro5NT;Asus Pro5NTA;Asus Pro5NTK;Asus Pro5NU;Asus Pro5NZ;Asus Pro5P;Asus Pro5PE;Asus Pro5PS;Asus Pro5PSJ;Asus Pro61;Asus Pro61G;Asus Pro61GX;Asus Pro61Q;Asus Pro61S;Asus Pro61SF;Asus Pro61SL;Asus Pro61SV;Asus Pro61Z;Asus Pro62;Asus Pro62J;Asus Pro62V;Asus Pro62VP;Asus Pro63;Asus Pro63D;Asus Pro63DP;Asus Pro64;Asus Pro64D;Asus Pro64DA;Asus Pro64J;Asus Pro64JA;Asus Pro64JQ;Asus Pro64JV;Asus Pro64V;Asus Pro64VG;Asus Pro64VN;Asus Pro70V;Asus Pro78VG;Asus R503;Asus R503A;Asus R503C;Asus R503CR;Asus R503U;Asus R503V;Asus R503VD;Asus R503VDR;Asus U50;Asus U50A;Asus U50F;Asus U50V;Asus U50VG;Asus UL50;Asus UL50A;Asus UL50AG;Asus UL50AT;Asus UL50V;Asus UL50VF;Asus UL50VG;Asus UL50VS;Asus UL50VT;Asus UL50X;Asus W90;Asus W90VP;Asus X52;Asus X52B;Asus X52BY;Asus X52D;Asus X52DE;Asus X52DR;Asus X52DY;Asus X52F;Asus X52J;Asus X52JB;Asus X52JC;Asus X52JE;Asus X52JE-EX098;Asus X52JG;Asus X52JK;Asus X52JR;Asus X52JT;Asus X52JU;Asus X52JV;Asus X52N;Asus X52S;Asus X52SA;Asus X52SG;Asus X52X;Asus X52Xi;Asus X52XV;Asus X53;Asus X53E;Asus X53S;Asus X53SA;Asus X53SC;Asus

X53SD;Asus X53SE;Asus X53SG;Asus X53SJ;Asus X53SK;Asus X53SM;Asus X53SR;Asus X53SV;Asus X53SV-SX200;Asus X53SV-SX200V;Asus X53SV-SX214;Asus X53Z;ASUS X53Z;Asus X54;Asus X54C;Asus X54F;Asus X54H;Asus X54HB;Asus X54HR;Asus X54HY;Asus X54K;Asus X54L;Asus X54LB;Asus X54LY;Asus X54U;Asus X54Xi;Asus X55;Asus X55S;Asus X55SR;Asus X55SV;Asus X55U;Asus X61;Asus X61G;Asus X61GX;Asus X61Q;Asus X61S;Asus X61SF;Asus X61SL;Asus X61SV;Asus X61W;Asus X61Z;Asus X62;Asus X62J;Asus X62V;Asus X62VP;Asus X64;Asus X64D;Asus X64DA;Asus X64J;Asus X64JA;Asus X64JQ;Asus X64JV;Asus X64V;Asus X64VG;Asus X64VN;Asus X66;Asus X66i;Asus X66iC;Asus X72;Asus X72A;Asus X72D;Asus X72DR;Asus X72DY;Asus X72F;Asus X72J;Asus X72JK;Asus X72JR;Asus X72JT;Asus X72JTT;Asus X72JU;Asus X72P;Asus X72Q;Asus X72S;Asus X72SA;Asus X72SL;Asus X72SR;Asus X72T;Asus X72TL;Asus X72TLL;Asus X72TP;Asus X72V;Asus X72VM;Asus X72VN;Asus X72VR;Asus X73;Asus X73E;Asus X73S;Asus X73SD;Asus X73Si;Asus X73SJ;Asus X73SJJ;Asus X73SL;Asus X73SM;Asus X73SV;Asus X73SV-TY193;Asus X75;Asus X75A;Asus X75A1;Asus X75SV;Asus X75V;Asus X75VB;Asus X75VC;Asus X75VD;Asus X75VD1;Asus X75VJ;Asus X75VM;Asus X77;Asus X77J;Asus X77JA;Asus X77JG;Asus X77JO;Asus X77JQ;Asus X77JV;Asus X77V;Asus X77VG;Asus X77VN;Asus X7A;Asus X7AD;Asus X7ADR;Asus X7ADY;Asus X7AF;Asus X7AJ;Asus X7AJK;Asus X7AJR;Asus X7AJT;Asus X7AJU;Asus X7B;Asus X7BJ;Asus X7BJF;Asus X7BJG;Asus X7BJN;Asus X7BJQ;Asus X7BS;Asus X7BSM;Asus X7BSN;Asus X7BSV;Asus X7C;Asus X7CB;Asus X7CBE;Asus X7CBR;Asus X7CBY;Asus X7CE;Asus X7CS;Asus X7CSD;Asus X7CSJ;Asus X7CSM;Asus X7CSV;Asus X7CT;Asus X7CTA;Asus X7CTK;Asus X7DS;Asus X7DSF;Asus X7DSL;Asus Z54;Asus Z54C;Asus Z54HR;Toshiba Satellite Pro;ASUS N75SL-V2G;Asus N45VM;Brick Computer Mobile;Toshiba DynaBook Qosmio;Toshiba Satellite S855D;Uniwill P53INX;Delta Electronics ADP;Toshiba PA5180U;Asus X57VN;Asus X8EJV;Asus X84LY;Asus Z53U;Asus U47VC;Asus X8S;Asus X8FJC;Asus X84SL;Asus Lamborghini VX6S;Asus X88VF;Asus F9SG;Asus Lamborghini VX7SX;Asus Pro52L;Asus X90SV;Toshiba Qosmio F60;Toshiba Satellite A500;Toshiba Satellite A500D;Toshiba Satellite A505;Toshiba Satellite A505D;Toshiba Satellite L350;Toshiba Satellite L350D;Toshiba Satellite L355D;Toshiba Satellite L500;Toshiba Satellite L500D;Toshiba Satellite L505;Toshiba Satellite L505D;Toshiba Satellite L550;Toshiba Satellite L550D;Toshiba Satellite L555;Toshiba Satellite L555D;Toshiba Satellite P200;Toshiba Satellite P200D;Toshiba Satellite P205D;Toshiba Satellite P300;Toshiba Satellite P300D;Toshiba Satellite P305;Toshiba Satellite P305D;Toshiba Equium A300;Toshiba Equium A300D;Toshiba Satellite A200;Toshiba Satellite A202;Toshiba Satellite A205;Toshiba Satellite A210;Toshiba Satellite A215;Toshiba Satellite A300;Toshiba Satellite A300D;Toshiba Satellite A305;Toshiba Satellite A305D;Toshiba Satellite A350;Toshiba Satellite A350D;Toshiba Satellite A355;Toshiba Satellite A355D;Toshiba Satellite L300;Toshiba Satellite L300D;Toshiba Satellite L305D;Toshiba Satellite L310;Toshiba Satellite L510;Toshiba Satellite L515D;Toshiba Satellite M300;Toshiba Satellite M300-700;Toshiba Satellite M301;Toshiba Satellite M302;Toshiba Satellite M303;Toshiba Satellite M305D;Toshiba Satellite M330;Toshiba Satellite M331;Toshiba Satellite M332;Toshiba Satellite M333;Toshiba Satellite M336;Toshiba Satellite M338;Lenovo 3000 Y410;Asus Z83V;Asus A53B;Asus A53BE;Asus A53BR;Asus A53BY;Asus A53T;Asus A73;Asus A73BE;Asus A73BR;Asus A73BY;Asus A73TA;Asus A73TK;Asus K53B;Asus K53BE;Asus K53BR;Asus K53BY;Asus K53T;Asus K53TA;Asus K53TK;Asus K53U;Asus K73B;Asus K73BE;Asus K73BR;Asus K73BY;Asus K73TA;Asus K73TK;Asus X53B;Asus X53BE;Asus X53BJ;Asus X53BR;Asus X53BY;Asus X53T;Asus X53TA;Asus X53TK;Asus X53U;Asus X73B;Asus X73BE;Asus X73BR;Asus X73BY;Asus X73T;Asus X73TA;Asus X73TK;Toshiba Satellite C660;Toshiba Satellite C660D;Toshiba Satellite L750;Toshiba Satellite L755;Toshiba Satellite L850;Toshiba Satellite L850D;Toshiba Satellite L855;Toshiba Satellite L870;Toshiba Satellite L870D;Toshiba Satellite L875;Toshiba Satellite L875D;Lenovo IdeaPad Y550;Packard Bell EasyNote;Packard Bell SB65;Packard Bell SB85;Packard Bell SB86;Packard Bell SB88;Packard Bell SB89;MSI MS;Asus X751LN-TY092H;Toshiba Satellite L40;Toshiba Satellite L50;Toshiba Satellite L50-A;Asus A555;Asus A555DA;Asus A555DG;Asus

A555LA;Asus A555LB;Asus A555LD;Asus A555LF;Asus A555LJ;Asus A555LN;Asus A555LP;Asus A555UB;Asus A555UJ;Asus A555YI;Asus R554;Asus R554LA;Asus R554LD;Asus R555;Asus R555JB;Asus R555JK;Asus R555JM;Asus R555JQ;Asus R555JW;Asus R555JX;Asus R555ZU;Asus R557;Asus R557LA;Asus R557LD;Asus R557LI;Asus R557LJ;Asus R557LN;Asus R557LP;BenQ JoyBook A52;BenQ JoyBook A52E;BenQ JoyBook A53;BenQ JoyBook C41;BenQ JoyBook C41E;BenQ JoyBook Q41;BenQ JoyBook R42;BenQ JoyBook R43;BenQ JoyBook R43C;BenQ JoyBook R43CE;BenQ JoyBook R43E;BenQ JoyBook R56;BenQ JoyBook S41;BenQ JoyBook S42;Toshiba Portege M805;Toshiba Portege M805D;Toshiba Portege M810;Toshiba Portege M830;Toshiba Portege M900;Toshiba Portege T130;Toshiba Portege U400;Toshiba Satellite A660;Toshiba Satellite A660D;Toshiba Satellite A665;Toshiba Satellite A665D;Toshiba Satellite C600;Toshiba Satellite C600D;Toshiba Satellite L600;Toshiba Satellite L600D;Toshiba Satellite M339;Toshiba Satellite M600;Toshiba Satellite P700;Toshiba Satellite P740;Toshiba Satellite P745;Toshiba Satellite P750;Toshiba Satellite P755;Toshiba Satellite P770;Toshiba Satellite P770D;Toshiba Satellite P775;Toshiba Satellite U405;Toshiba Satellite U405D;Asus P31;Asus P31F;Asus P31J;Asus P41;Asus P41F;Asus P41J;Asus P41JC;Asus P41JF;Asus P41JG;Asus P41S;Asus P41SV;Asus U31;Asus U31E;Asus U31F;Asus U31J;Asus U41;Asus U41E;Asus U41F;Asus U41J;Asus U41JC;Asus U41JF;Asus U41JG;Asus U41S;Asus U41SD;Asus U41SV;Asus X35F;Asus X35J;Asus X35JG;Asus X35S;Asus X35SD;Asus X35SG;Asus P42EI;Asus A40;Asus A40DE;Asus A40DQ;Asus A40DR;Asus A40DY;Asus A40F;Asus A40J;Asus A40JA;Asus A40JB;Asus A40JC;Asus A40JE;Asus A40JK;Asus A40JP;Asus A40JR;Asus A40JV;Asus A40JY;Asus A40JZ;Asus A40N;Asus A42;Asus A42D;Asus A42DE;Asus A42DQ;Asus A42DR;Asus A42DY;Asus A42E;Asus A42F;Asus A42J;Asus A42JA;Asus A42JB;Asus A42JC;Asus A42JE;Asus A42JK;Asus A42JP;Asus A42JR;Asus A42JV;Asus A42JY;Asus A42JZ;Asus A42N;Asus A42QR;Asus A52JT;Asus A52JU;Asus A52JV;Asus A52N;Asus A60;Asus A62;Asus B52BY;Asus B53A;Asus B53E;Asus B53E;Asus B53E-SO228X;Asus B53S;Asus B53S;Asus B53V;Asus F85;Asus F86;Asus K42;Asus K42D;Asus K42DE;Asus K42DQ;Asus K42DR;Asus K42DY;Asus K42E;Asus K42Ei;Asus K42F;Asus K42J;Asus K42JA;Asus K42JB;Asus K42JC;Asus K42JC-1Y;Asus K42JE;Asus K42JE-VX183V;Asus K42JK;Asus K42JP;Asus K42JR;Asus K42JV;Asus K42JY;Asus K42JZ;Asus K42JZ-VX065V;Asus K42K;Asus K42N;Asus K52DE-EX016;Asus K52DR-EX040V;Asus N82;Asus N82E;Asus N82EI;Asus N82J;Asus N82JG;Asus N82JQ;Asus N82JV;Asus P42;Asus P42F;Asus P42JC;Asus P82;Asus Pro51;Asus Pro51B;Asus Pro51K;Asus Pro51S;Asus Pro51SA;Asus Pro67;Asus Pro67F;Asus Pro8C;Asus Pro8F;Asus Pro8FE;Asus Pro8FEI;Asus Pro8FF;Asus Pro8FJ;Asus Pro8FJC;Asus X42;Asus X42DE;Asus X42DY;Asus X42E-35JB;Asus X42E-45JB;Asus X42EI-33JE;Asus X42EI-35JB;Asus X42EI-45JE;Asus X42EI-46JE;Asus X42EP-60JB;Asus X42EP-60JE;Asus X42F;Asus X42J;Asus X42JA;Asus X42JB;Asus X42JE;Asus X42JE-VX230;Asus X42JK;Asus X42JR-VX140D;Asus X42JR;Asus X42JV;Asus X42JY;Asus X42JZ;Asus X42N;Asus X52JC-EX508;Asus X52JE-EX098V;Asus X67;Asus X67F;Asus X8F;Asus X8FF;Asus X8FJ;Asus P43EI;Asus X44EI;Asus A43;Asus A43B;Asus A43BY;Asus A43E;Asus A43F;Asus A43J;Asus A43JA;Asus A43JB;Asus A43JC;Asus A43JF;Asus A43JG;Asus A43JH;Asus A43JN;Asus A43JP;Asus A43JQ;Asus A43JR;Asus A43JU;Asus A43JV;Asus A43S;Asus A43SA;Asus A43SD;Asus A43SJ;Asus A43SM-VX002V;Asus A43SM;Asus A43SV;Asus A43TA;Asus A43TK;Asus A44;Asus A44H;Asus A44H-MSR1;Asus A44HR;Asus A44HY;Asus A44L;Asus A44LY;Asus A53J;Asus A53JA;Asus A53JB;Asus A53JC;Asus A53JE;Asus A53JH;Asus A53JQ;Asus A53JR;Asus A53JT;Asus A53JU;Asus A53SC-SX502V;Asus A53SM;Asus A53TA;Asus A53TK;Asus A53U;Asus A54HR SX306V;Asus A54HY;Asus A54L;Asus A83;Asus A83B;Asus A83B;Asus A83BR;Asus A83BY;Asus A83E;Asus A83S;Asus A83SA;Asus A83SD;Asus A83SJ;Asus A83SM;Asus A83SV;Asus A83T;Asus A83TA;Asus A83TK;Asus A83U;Asus K43;Asus K43B;Asus K43BE;Asus K43BR;Asus K43BY;Asus K43E;Asus K43E-VX318V;Asus K43E-VX320;Asus K43F;Asus K43J;Asus K43JC;Asus K43JM;Asus K43JS;Asus K43JY;Asus K43S;Asus K43SA;Asus K43SC;Asus K43SD;Asus K43SE;Asus K43SJ;Asus K43SM;Asus K43SR;Asus K43SV;Asus K43SY;Asus K43T;Asus K43TA;Asus K43TK;Asus K43U;Asus K43U-VX016;Asus K53BR-SX027;Asus

k53BY;Asus K53E;Asus K53J;Asus K53JA;Asus K53JC;Asus K53JE;Asus K53JF;Asus K53JG;Asus K53JN;Asus K53JS;Asus K53JT;Asus K53SC;Asus K53SD;Asus K53TK-SX037V;Asus K54L;Asus K84;Asus K84C;Asus K84L;Asus P43;Asus P43E;Asus P43E-VO111X;Asus P43SJ;Asus P53JC;Asus P53SJ;Asus Pro4G;Asus Pro4GJ;Asus Pro4GJF;Asus Pro4GJM;Asus Pro4GJQ;Asus Pro4GS;Asus Pro4GSL;Asus Pro4GSM;Asus Pro4GSN;Asus Pro4H;Asus Pro4HJ;Asus Pro4HJC;Asus Pro4I;Asus Pro4IJ;Asus Pro4IJF;Asus Pro4IS;Asus Pro4ISV;Asus Pro4J;Asus Pro4JE;Asus Pro4JS;Asus Pro4JSJ;Asus Pro4K;Asus Pro4KS;Asus Pro4KSF;Asus Pro4KSL;Asus Pro4KV;Asus Pro4KVM;Asus Pro4L;Asus Pro4LE;Asus Pro4LS;Asus Pro4LSM;Asus Pro4LSV;Asus Pro4N;Asus Pro4NA;Asus Pro4NV;Asus Pro4NVC;Asus Pro8G;Asus Pro8GB;Asus Pro8GBE;Asus Pro8GBR;Asus Pro8GBY;Asus Pro8GE;Asus Pro8GS;Asus Pro8GSA;Asus Pro8GSD;Asus Pro8GSJ;Asus Pro8GSM;Asus Pro8GSV;Asus Pro8GT;Asus Pro8GTA;Asus Pro8GTK;Asus Pro8GU;Asus Pro8Q;Asus X43;Asus X43B;Asus X43BE;Asus X43BR;Asus X43BY;Asus X43E;Asus X43EC;Asus X43EE;Asus X43J;Asus X43JE;Asus X43JF;Asus X43JR;Asus X43JX;Asus X43S;Asus X43SA;Asus X43SA-VX017;Asus X43SA-VX095;Asus X43SD;Asus X43SJ;Asus X43SM;Asus X43SR;Asus X43SV;Asus X43SV-V1G;Asus X43T;Asus X43TA;Asus X43TA-VX036;Asus X43TA-VX036V;Asus X43TK;Asus X43U;Asus X43V;Asus X44C;Asus X44H;Asus X44HR;Asus X44HY;Asus X44L;Asus X44LY;Asus X4J;Asus X4JE;Asus X4JS;Asus X4JSJ;Asus X53BR-SX030;Asus X53E-FS31;Asus X53K;Asus X53KA;Asus X53Ka;Asus X53KE;Asus X53L;Asus X53Q;Asus X53SD-SX1198V;Asus X53SJ-SX167;Asus X53SK-SX080;Asus X53SV-SX288V;Asus X53U-SH11;Asus X53U-SX201;Asus X53X;Asus X53XC;Asus X53XE;Asus X54HR-SX203;Asus X84;Asus X84C;Asus X84E;Asus X84EB;Asus X84Ei;Asus X84H;Asus X84HO;Asus X84HR;Asus X84HY;Asus X84L;Asus X84S;Asus K53Z-FH41;Asus X53SC-SX081V;Asus X53U-SX086V;Asus A70;Asus A72DR-TY055V;Asus A73TK-TY062;Asus K72JK-TY013;Asus K72JR-TY115;Asus K72JT-TY034;Asus K72JT-TY045;Asus K72JT-TY045V;Asus K73SD;Asus K73SJ;Asus K73SM;Asus N73JQ-TY099V;Asus N73SL-V2G;Asus N73SM-TY022V;Asus N73SV-V1G;Asus Pro7;Asus Pro7A;Asus Pro7AD;Asus Pro7ADR;Asus Pro7ADY;Asus Pro7AF;Asus Pro7AJ;Asus Pro7AJK;Asus Pro7AJR;Asus Pro7AJT;Asus Pro7AJU;Asus Pro7B;Asus Pro7BJ;Asus Pro7BJF;Asus Pro7BJG;Asus Pro7BJQ;Asus Pro7BS;Asus Pro7BSM;Asus Pro7BSV;Asus Pro7C;Asus Pro7CB;Asus Pro7CBE;Asus Pro7CBR;Asus Pro7CBy;Asus Pro7CE;Asus Pro7CS;Asus Pro7CSD;Asus Pro7CSJ;Asus Pro7CSM;Asus Pro7CSV;Asus Pro7CT;Asus Pro7CTA;Asus Pro7CTK;Asus X7;Asus X73CBE;Asus X73E-TY250V;Asus X73TK-TY036;Asus X73V;Asus X7BSV-V1G;Asus X7BSV-V2G;Asus K72DR-TY011V;Fujitsu LifeBook AH531;Fujitsu LifeBook LH520;Fujitsu LifeBook LH522;Medion Akoya P6512;Medion MD98380;MSI GE60;MSI CX70 0ND;MSI CX70 20C;MSI CX70 20C;MSI CX70 20D;MSI CX70 20E;MSI CX70 2PF;MSI FR610;MSI FX600;MSI FX603;MSI FX610;MSI FX620DX;MSI FX700;MSI FX720;MSI GE60 20D;MSI GE60 20E;MSI GE620;Toshiba Satellite S70;Toshiba Satellite C50;Toshiba Satellite C50-A;Toshiba Satellite C70;Toshiba Satellite C70-A;Toshiba Satellite C70-B;Toshiba Satellite C840;Toshiba Satellite C840D;Toshiba Satellite P850;Toshiba Satellite P855;Toshiba Satellite P870;Toshiba Satellite P870D;Toshiba Satellite P875;Toshiba Satellite P875D;Toshiba Satellite Pro C50-A;Toshiba Satellite Pro C70-A;Toshiba Satellite Pro L70-A;Toshiba Satellite S70-A;Toshiba Satellite S70-B;Toshiba Satellite S70T;Toshiba Satellite S70T-A;Toshiba Satellite S800;Toshiba Satellite S800D;Toshiba Satellite S840;Toshiba Satellite S840D;Toshiba Satellite S845;Toshiba Satellite S845D;Toshiba Satellite S850;Toshiba Satellite S850D;Toshiba Satellite S855;Toshiba Satellite S870;Toshiba Satellite S870D;Toshiba Satellite S875;Toshiba Satellite S875D;Toshiba Tecra A50;Toshiba Tecra A50-A;Gateway MS2285;Gateway MS2273;Gateway MS2274;Asus A41;Asus A41i;Asus A41ID;Asus A41IE;Asus A41iN;Asus F82;Asus F82A;Asus F82Q;Asus K40;Asus K40A;Asus K40AB;Asus K40AC;Asus K40AD;Asus K40AE;Asus K40AF;Asus K40C;Asus K40E;Asus K40EA;Asus K40ES;Asus K40ET;Asus K40i;Asus K40iD;Asus K40IE;Asus K40IJ;Asus K40IJ-A1;Asus K40iJ;Asus K40IJ-QMB1;Asus K40iL;Asus K40iN;Asus K40iN-A1;Asus K40iP;Asus K40JV;Asus K40LJ;Asus K40LN;Asus K40ML;Asus K40N;Asus K40S;Asus K50Af;Asus K50IJ-SX446V;Asus K50ip;Asus K51AE-SX057;Asus K6C11;Asus K70AF-TY005;Asus K70ID;Asus K70IL;Asus P81;Asus P81IJ;Asus Pro65;Asus Pro66;Asus Pro66I;Asus

Pro66IC;Asus Pro88Q;Asus Pro8B;Asus Pro8BC;Asus Pro8BI;Asus Pro8BID;Asus Pro8BIE;Asus Pro8BIJ;Asus Pro8BIL;Asus Pro8BIN;Asus Pro8BIP;Asus Pro8BIPV;Asus Pro8D;Asus Pro8DI;Asus Pro8DIJ;Asus Pro8S;Asus X5AVC;Asus X5AVN;Asus X5CQ;Asus X5DAF;Asus X5DE;Asus X5DID;Asus X5DIE;Asus X5DIP;Asus X5GAG-XX052V;Asus X5GAT-XX046V;Asus X5JIJ;Asus X65;Asus X66IC;Asus X70IC;Asus X70ID;Asus X8;Asus X87;Asus X87E;Asus X87Q;Asus X8A;Asus X8AA;Asus X8AAB;Asus X8AAC;Asus X8AAD;Asus X8AAF;Asus X8AC;Asus X8AE;Asus X8AEA;Asus X8Ai;Asus X8AiD;Asus X8AID;Asus X8AiE;Asus X8AIE;Asus X8AiJ;Asus X8AIJ;Asus X8AiL;Asus X8AiN;Asus X8AIN;Asus X8AIP;Asus X8AS;Asus X8B;Asus X8BJ;Asus X8BJT;Asus X8BV;Asus X8BVT;Asus X8C;Asus X8D;Asus X8Di;Asus X8DIJ;Asus X8E;Asus X8E-22DAC;Asus X8EJ;Asus X8EJQ;Asus K50IP-SX097;Asus A56;Asus A56C;Asus A56CA;Asus A56CB;Asus A56CM;Asus A56E;Asus A56V;Asus K56CM;Asus F2;Asus F2F;Asus F2HF;Asus F2J;Asus F2JA;Asus F2JE;Asus F3;Asus F3A;Asus F3E;Asus F3F;Asus F3H;Asus F3J;Asus F3JA;Asus F3JC;Asus F3JE;Asus F3JF;Asus F3JM;Asus F3JP;Asus F3JR;Asus F3JS;Asus F3JV;Asus F3K;Asus F3KA;Asus F3KE;Asus F3KR;Asus F3L;Asus F3M;Asus F3P;Asus F3Q;Asus F3S;Asus F3SA;Asus F3SC;Asus F3SE;Asus F3SG;Asus F3SR;Asus F3SV;Asus F3T;Asus F3TC;Asus F3U;Asus F7;Asus F7B;Asus F7E;Asus F7F;Asus F7K;Asus F7KR;Asus F7L;Asus F7S;Asus F7SE;Asus F7SR;Asus F7Z;Asus M51;Asus M51A;Asus M51AT;Asus M51E;Asus M51K;Asus M51KR;Asus M51Q;Asus M51QA;Asus M51S;Asus M51SE;Asus M51SN;Asus M51SR;Asus M51T;Asus M51TA;Asus M51TR;Asus M51V;Asus M51VA;Asus M51VR;Asus M51VX;Asus Pro31;Asus Pro31E;Asus Pro31F;Asus Pro31H;Asus Pro31J;Asus Pro31JA;Asus Pro31L;Asus Pro31M;Asus Pro31P;Asus Pro31Q;Asus Pro31S;Asus Pro31SA;Asus Pro31SC;Asus Pro31SG;Asus Pro31SR;Asus Pro31SV;Asus Pro31T;Asus Pro31U;Asus Pro57;Asus Pro57A;Asus Pro57K;Asus Pro57KR;Asus Pro57S;Asus Pro57SE;Asus Pro57SN;Asus Pro57T;Asus Pro57TA;Asus Pro57TR;Asus Pro57V;Asus Pro57VA;Asus Pro57VR;Asus Pro71;Asus Pro71E;Asus Pro71F;Gateway MC73;Gateway MC7321U;Gateway MC78;Gateway MC7801U;Gateway MC7803U;Gateway MD2614U;Gateway MD7321U;Gateway MD7330U;Gateway MD7801U;Gateway MD7818U;Gateway MD7820U;Gateway MD7822U;Gateway MD7826U;LITEON PA-1900;Lenovo E46;Fujitsu ADP;Fujitsu CP483452;Fujitsu FMV;Fujitsu PJW1942NA;Asus A9RT;Asus V6Va;Toshiba PA3396E;Toshiba PA3396U;Asus N55;Asus N55S;Asus N55SF;Asus N55SL;Asus N75;Asus N75S;Asus N75SF;Asus N75SF-V2G;Asus N75SL;Asus N75SL-V2G;Asus N45;Asus N45S;Asus N45SF;Asus N45SF-V2G;Asus N45SL;Toshiba Satellite C55;Toshiba Satellite C55-C;Toshiba Satellite C55D;Toshiba Satellite C55D-C;Toshiba Satellite C70-C;Toshiba Satellite Pro C70-C;Toshiba PA3097U;Toshiba PA3432E;Toshiba PA3432U;Acer Aspire 1300;Acer Aspire 1300DXV;Acer Aspire 1300XC;Acer Aspire 1300XV;Acer Aspire 1301XV;Acer Aspire 1306;Acer Aspire 1310;Acer Aspire 1350;Acer Aspire 1351LC;Acer Aspire 1351XC;Acer Aspire 1352LC;Acer Aspire 1352XC;Acer Aspire 1353LC;Acer Aspire 1353LM;Acer Aspire 1353XC;Acer Aspire 1355LC;Acer Aspire 1355LCI;Acer Aspire 1355LM;Acer Aspire 1355LMI;Acer Aspire 1356LC;Acer Aspire 1356LCI;Acer Aspire 1356LMI;Acer Aspire 1357LC;Acer Aspire 1357LM;Acer Aspire 1357LMI;Acer Aspire 1360;Acer Aspire 1363;Acer Aspire 1363LC;Acer Aspire 1363LCI;Acer Aspire 1363LMI;Acer Aspire 1363WLMI;Acer Aspire 1363WLM;Acer Aspire 1363WLM;Acer Aspire 1365;Acer Aspire 1365LCI;Acer Aspire 1365LMI;Acer Aspire 1400;Acer Aspire 1400L;Acer Aspire 1400LC;Acer Aspire 1400X;Acer Aspire 1450;Acer Aspire 1522LMI;Acer Aspire 1522WLM;Acer Aspire 1522WLMI;Acer Ferrari 5000;Acer Ferrari 5005WLHI;Acer Ferrari 5005WLMI;Acer TravelMate 200;Acer TravelMate 200DX;Acer TravelMate 200T;Acer TravelMate 201;Acer TravelMate 201DX;Acer TravelMate 201T;Acer TravelMate 201TXV;Acer TravelMate 202;Acer TravelMate 202T;Acer TravelMate 202TE;Acer TravelMate 203T;Acer TravelMate 210;Acer TravelMate 210DX;Acer TravelMate 210T;Acer TravelMate 210TER;Acer TravelMate 210TXF;Acer TravelMate 211;Acer TravelMate 211T;Acer TravelMate 212;Acer TravelMate 212T;Acer TravelMate 212TE;Acer TravelMate 212TX;Acer TravelMate 212TXV;Acer TravelMate 213;Acer TravelMate 213T;Acer TravelMate 213TX;Acer TravelMate 213TXV;Acer TravelMate 214;Acer TravelMate 219;Acer TravelMate 420;Acer TravelMate 421;Acer TravelMate 422;Acer TravelMate 422XC;Acer

TravelMate 430;Acer TravelMate 500;Acer TravelMate 505;Acer TravelMate 505DX;Acer TravelMate 505T;Acer TravelMate 506;Acer TravelMate 506DX;Acer TravelMate 506T;Acer TravelMate 507;Acer TravelMate 507DX;Acer TravelMate 507T;Acer TravelMate 508;Acer TravelMate 508DX;Acer TravelMate 508T;Acer TravelMate 510;Acer TravelMate 510DX;Acer TravelMate 510T;Acer TravelMate 512;Acer TravelMate 512DX;Acer TravelMate 512T;Acer TravelMate 512TE;Acer TravelMate 513;Acer TravelMate 513DX;Acer TravelMate 513T;Acer TravelMate 514;Acer TravelMate 514T;Acer TravelMate 514TXV;Acer TravelMate 515;Acer TravelMate 515TE;Acer TravelMate 516;Acer TravelMate 516TE;Acer TravelMate 517;Acer TravelMate 517TE;Advent 7066M;Advent 7093;Advent 7107;Aristo Prestige 1600;Aristo Prestige 1800;Asus A1000;Asus A1000B;Asus A1000D;Asus A1000F;Asus A11;Asus A2;Asus A2000;Asus A2000C;Asus A2000D;Asus A2000G;Asus A2000H;Asus A2000K;Asus A2000L;Asus A2000S;Asus A2000T;Asus A2508H;Asus A2514H;Asus A2534H;Asus A2540H;Asus A2C;Asus A2D;Asus A2DC;Asus A2G;Asus A2H;Asus A2K;Asus A2L;Asus A2LP;Asus A2S;Asus A2T;Asus A3;Asus A3000;Asus A3000E;Asus A3000G;Asus A3000L;Asus A3000N;Asus A32;Asus A3500L;Asus A38N;Asus A3AC;Asus A3E;Asus A3FC;Asus A3FP;Asus A3G;Asus A3H;Asus A3HF;Asus A3N;Asus A3VC;Asus A3VP;Asus A4000;Asus A4000D;Asus A4000G;Asus A4000GA;Asus A4000K;Asus A4000KA;Asus A4000L;Asus A4000S;Asus A45;Asus A45A;Asus A45D;Asus A45DE;Asus A45DR;Asus A45N;Asus A45V;Asus A45VD;Asus A45VG;Asus A45VS;Asus A46;Asus A46C;Asus A46CA;Asus A46CB;Asus A46CM;Asus A5;Asus A50;Asus A5000;Asus A5000E;Asus A5000L;Asus A555D;Asus A555L;Asus A555U;Asus A555UQ;Asus A555Y;Asus A5E;Asus A5EB;Asus A5EC;Asus A6;Asus A6000;Asus A6000E;Asus A6000G;Asus A6000GA;Asus A6000J;Asus A6000JA;Asus A6000JC;Asus A6000K;Asus A6000KM;Asus A6000L;Asus A6000N;Asus A6000NE;Asus A6000R;Asus A6000U;Asus A6000V;Asus A6000VA;Asus A6000VC;Asus A6000VM;Asus A65;Asus A6700G;Asus A6700NE;Asus A6E;Asus A6F;Asus A6G;Asus A6GA;Asus A6J;Asus A6JA;Asus A6JC;Asus A6JE;Asus A6JM;Asus A6K;Asus A6KM;Asus A6KT;Asus A6L;Asus A6M;Asus A6N;Asus A6NE;Asus A6R;Asus A6RP;Asus A6T;Asus A6TA;Asus A6TC;Asus A6U;Asus A6V;Asus A6VA;Asus A6VC;Asus A6VM;Asus A7;Asus A7000;Asus A7000G;Asus A7C;Asus A7CC;Asus A7CD;Asus A7D;Asus A7DB;Asus A7DC;Asus A7F;Asus A7FB;Asus A7FC;Asus A7G;Asus A7GB;Asus A7GC;Asus A7J;Asus A7JB;Asus A7JC;Asus A7K;Asus A7KC;Asus A7M;Asus A7MB;Asus A7MC;Asus A7S;Asus A7SN;Asus A7SV;Asus A7T;Asus A7TB;Asus A7TC;Asus A7tv;Asus A7U;Asus A7UC;Asus A7V;Asus A7VB;Asus A7VC;Asus A8;Asus A8000;Asus A8000F;Asus A8000J;Asus A8000JA;Asus A8000JC;Asus A8000JM;Asus A85;Asus A85A;Asus A85D;Asus A85DE;Asus A85DR;Asus A85N;Asus A85V;Asus A85VD;Asus A85VG;Asus A85VJ;Asus A85VM;Asus A85VS;Asus A8A;Asus A8C;Asus A8DC;Asus A8E;Asus A8F;Asus A8FM;Asus A8G;Asus A8H;Asus A8HE;Asus A8J;Asus A8JA;Asus A8JC;Asus A8JE;Asus A8JM;Asus A8JN;Asus A8JP;Asus A8JR;Asus A8JS;Asus A8JV;Asus A8L;Asus A8LE;Asus A8M;Asus A8N;Asus A8S;Asus A8SC;Asus A8SE;Asus A8SG;Asus A8SR;Asus A8T;Asus A8TC;Asus A8TM;Asus A8Z;Asus A9;Asus A9000;Asus A9000RP;Asus A9000T;Asus A93;Asus A93S;Asus A93SM;Asus A93SV;Asus A95;Asus A9500;Asus A9500RP;Asus A9500T;Asus A95A;Asus A95V;Asus A95VM;Asus A9C;Asus A9RP;Asus A9T;Asus B01;Asus B06;Asus B1;Asus B1000;Asus B12;Asus B1A;Asus B23;Asus B23E;Asus B23G;Asus B23GI;Asus B33;Asus B33E;Asus B43;Asus B43A;Asus B43AV;Asus B43E;Asus B43E-VO137X;Asus B43EI;Asus B43F;Asus B43J;Asus B43J-VO029X;Asus B43S;Asus B43V;Asus B43VC;Asus B50;Asus B50-84225SLAA;Asus B50A;Asus B51;Asus B51E;Asus B80;Asus B80-86225SLEA;Asus B80A;Asus E45;Asus E45V;Asus E45VA;Asus E45VJ;Asus E46;Asus E46C;Asus E46CA;Asus E46CB;Asus E46CM;Asus E55;Asus F40;Asus F45;Asus F45A;Asus F45C;Asus F45U;Asus F45V;Asus F45VD;Asus F45VD1;Asus F5;Asus F50G;Asus F50Gx;Asus F520;Asus F520J;Asus F520JD;Asus F520M;Asus F520MD;Asus F520MJ;Asus F530;Asus F5500;Asus F5C;Asus F5Gi;Asus F5GL;Asus F5M;Asus F5N;Asus F5R;Asus F5Ri;Asus F5RL;Asus F5SL;Asus F5SR;Asus F5V;Asus F5VI;Asus F5VL;Asus F6;Asus F6A;Asus F6E;Asus F6H;Asus F6K;Asus F6K233E;Asus F6K54S;Asus F6S;Asus F6V;Asus F6Ve;Asus F70SI;Asus F74;Asus F7400;Asus F7400B;Asus F74B;Asus F8;Asus F80;Asus F80A;Asus F80C;Asus F80CR;Asus F80H;Asus

F80L;Asus F80M;Asus F80Q;Asus F80S;Asus F81;Asus F81E;Asus F81S;Asus F81SE;Asus F83;Asus F83C;Asus F83CR;Asus F83E-335CR;Asus F83E-335T;Asus F83E-A40T;Asus F83S;Asus F83SE;Asus F83T;Asus F83VD;Asus F83VF;Asus F83VX;Asus F8DC;Asus F8P;Asus F8S;Asus F8SA;Asus F8SE;Asus F8SG;Asus F8SN;Asus F8SP;Asus F8SR;Asus F8SV;Asus F8TR;Asus F8V;Asus F8VA;Asus F8VR;Asus F9;Asus F9D;Asus F9Dc;Asus F9E;Asus F9F;Asus F9J;Asus F9S;Asus FL4000;Asus FL4000C;Asus FX50;Asus FX50J;Asus FX50JK;Asus FX50JX;Asus FX50V;Asus FX50VX;Asus FX51;Asus FX51L;Asus FX51LB;Asus FX51LX;Asus FX51U;Asus FX51UB;Asus FX51UX;Asus FX53;Asus FX550;Asus FX550J;Asus FX550JD;Asus FX550JK;Asus FX550V;Asus FX550VX;Asus FX71;Asus G1S;Asus G1SN;Asus G2;Asus G2K;Asus G2P;Asus G2PB;Asus G2PC;Asus G2S;Asus G2SG;Asus G2SV;Asus J1;Asus J2;Asus J2A;Asus J2N;Asus J2NE;Asus J3;Asus J3N;Asus K41;Asus K41E;Asus K41S;Asus K41SE;Asus K41V;Asus K41VD;Asus K41VF;Asus K45;Asus K45A;Asus K45D;Asus K45DE;Asus K45DR;Asus K45N;Asus K45V;Asus K45VD;Asus K45VG;Asus K45VJ;Asus K45VM;Asus K45VS;Asus K50I;Asus K750;Asus K750J;Asus K750JA;Asus K750JB;Asus K750JN;Asus K750L;Asus K750LA;Asus K750LB;Asus K750LN;Asus K95;Asus K95A;Asus K95VB;Asus K95VJ;Asus K95VM;Asus K95VM-YZ007V;Asus L1000;Asus L1000A;Asus L1000B;Asus L1400;Asus L2000;Asus L2000B;Asus L2000D;Asus L3000;Asus L3000D;Asus L3000H;Asus L3000TP;Asus L31;Asus L32;Asus L3200;Asus L34;Asus L3400;Asus L35;Asus L3500;Asus L3500D;Asus L3500T;Asus L3500TP;Asus L3800;Asus L3800C;Asus L3800S;Asus L3800SL;Asus L4;Asus L4000;Asus L4000H;Asus L4000L;Asus L4000R;Asus L41;Asus L42;Asus L44;Asus L45;Asus L4500;Asus L4500R;Asus L4E;Asus L4H;Asus L4L;Asus L4R;Asus L50;Asus L50V;Asus L50VC;Asus L50VM;Asus L50VN;Asus L7000;Asus L7000B;Asus L7000C;Asus L7000D;Asus L7000E;Asus L7000G;Asus L7000H;Asus L7200;Asus L7300;Asus L8000;Asus L8000B;Asus L8000C;Asus L8000CE;Asus L8000F;Asus L8000K;Asus L84;Asus L8400;Asus L8400CE;Asus L8400F;Asus L8400K;Asus L8400L;Asus L84B;Asus L84C;Asus L84F;Asus L84K;Asus L84L;Asus Lamborghini V6;Asus Lamborghini V6000;Asus Lamborghini V6000V;Asus Lamborghini V6V;Asus Lamborghini VX2;Asus Lamborghini VX2S;Asus Lamborghini VX2SE;Asus Lamborghini VX2SN;Asus Lamborghini VX3;Asus Lamborghini VX5;Asus Lamborghini VX6;Asus Lamborghini VX7;Asus Lamborghini VX7S;Asus M50;Asus M500A;Asus M500AE;Asus M500N;Asus M500NP;Asus M50Q;Asus M50S;Asus M50S84VN;Asus M50SA;Asus M50SR;Asus M50SV;Asus M50V;Asus M50VC;Asus M50VM;Asus M50VN;Asus M52;Asus M6000;Asus M6000A;Asus M6000C;Asus M6000CE;Asus M6000N;Asus M6000NA;Asus M6000NE;Asus M6000R;Asus M6000RF;Asus M67;Asus M6700;Asus M6700N;Asus M6700NA;Asus M6700NE;Asus M67A;Asus M67C;Asus M67CE;Asus M67N;Asus M67NA;Asus M67NE;Asus M67R;Asus M67RF;Asus M67V;Asus M67VA;Asus M68;Asus M6800;Asus M6800N;Asus M6800NE;Asus M68A;Asus M68C;Asus M68CE;Asus M68N;Asus M68NA;Asus M68NE;Asus M68R;Asus M68RF;Asus M68V;Asus M68VA;Asus M6B00N;Asus M6BN;Asus M70;Asus M70L;