

Lenovo

- G500S
- G70-70
- G70-70 80HW007CPB
- G70-80
- S600
- Z501
- Z710

seria IdeaPad

- | | | |
|---------------|---------------|---------------|
| • G40-30 | • G50-70 | • S435 |
| • G40-45 | • G50-70A | • S510 |
| • G40-70 | • G50-70M | • S510P |
| • G40-70M | • G50-75 | • S510P TOUCH |
| • G400S | • G50-80 | • Z40 |
| • G400S TOUCH | • G500S | • Z40-70 |
| • G405S | • G500S TOUCH | • Z40-75 |
| • G405S TOUCH | • G505S | • Z50 |
| • G410S | • G505S TOUCH | • Z50-70 |
| • G410S TOUCH | • G510S | • Z70 |
| • G50 | • G510S TOUCH | • Z70-70 |
| • G50-30 | • S410P | • Z70-80 |
| • G50-45 | • S410P TOUCH | |