

- A1718
- A1718
- MNF72Z/A
- MNF72Z/A
- TPN-AA01
- TPN-AA01
- Model ZM/USBC61W

Acer

seria Aspire

- R13
- S13
- SWITCH 12S
- SWITCH ALPHA 12

Apple

- IPAD PRO 10.5
- IPAD PRO 12.9

seria Macbook Pro

- 13" MPXQ2LL/A
- 13" MPXV2LL/A
- A1708

seria iPad

- PRO 11-INCH
- PRO 12.9-INCH 3RD GEN

seria iPhone

- 8
- 11
- 11 PRO
- 8 PLUS
- X
- XS

seria MacBook Air

- 13" (LATE 2018)
- 13" MRE82LL/A
- A1932

seria MacBook Pro 13

- 2016
- 2017
- 2018
- A1706
- A1708
- A1989

seria MacBook 12

- 2015
- 2016
- 2017
- A1534

Asus

- ASUSPRO B9440U
- ZENBOOK 3 DELUXE
- ZENFONE 3
- ZENFONE 4
- ZENFONE 5

seria Zenbook

- 3
- FLIP S
- PRO

seria Chromebook Flip

- C100
- C213
- C302CA

seria Zephyrus

- M GU502
- S GX502
- S GX531
- S GX701

Dell

- INSPIRON CHROMEBOOK 14
- VENUE 10 PRO 5056

- XPS 13 9370

- XPS 15 9575

seria XPS 13

- 7390

- 9360

- 9365

- 9370

- 9380

seria XPS 15

- 9560

- 9565

- 9570

- 9575

- 9580

Google

- CHROMEBOOK PIXEL

- NEXUS 5X

- NEXUS 6P

- PIXEL

- PIXEL 2

- PIXEL 2 XL

- PIXEL XL

- PIXELBOOK

HP

- 608 G1

- CHROMEBOOK 14-DB

- ENVY 12

- ENVY 13

- FOLIO 13-AK

- PRO X2 612 G2

seria EliteBook

- 1030 G

- 1030 G1

- 1040 G4

- 745 G5

- 830

- 840
- 8X0 G5
- X360 1040

seria ProBook

- 430 G5
- 430 G6
- 440 G5
- 440 G6
- 445 G6
- 450 G5
- 450 G6
- 455 G5
- 455 G6
- 470 G5
- 640 G4
- 645 G4
- 650 G4
- X360 11 G3 EE
- X360 440 G1

seria Envy

- 13T
- 17T
- X2 12
- X2 12-E
- X2 12-G
- X360
- X360 13Z
- X360 15-CN
- X360 15-CP
- X360 15T
- X360 15TZ
- X360 15Z

seria Spectre

- 12-A
- 13
- 13-AE
- 13-AF
- 13-AP

- 13-V
- 13T-AF
- FOLIO 13-AK
- FOLIO 13T
- PRO 13
- X2
- X2 12-A
- X2 12-C
- X2 12T-C
- X360
- X360 13
- X360 13-AC
- X360 13-AE
- X360 13-AP
- X360 13-W
- X360 13T-AE
- X360 13T-AP
- X360 13T
- X360 15T

seria ZBook

- 14U G5
- 15
- 17
- G5

seria Elite

- G3
- X2 1012 G1
- X2 1012 G2
- X2 1013 G3

seria Chromebook 11

- G6 EE

seria Chromebook 13

- G1

seria Chromebook 14

- G5

seria Chromebook x360

- 11 G1 EE
- 11-AE
- 14 G1
- 14-DA

HTC

- 10
- U11
- U12

Honor

- 5X
- 8
- 10
- V10

Huawei

- MATE 10
- MATE 10 PRO
- MATE 9
- MATEBOOK 12
- MATEBOOK E
- MATEBOOK X PRO
- P20
- P20 LITE
- P20 PRO
- P9
- P9 PLUS

Kruger&Matz

- LIVE 4S
- LIVE 5
- LIVE 6

LG

- G6
- G7
- NEXUS 5X
- V20
- V30
- G5

seria Gram

- 13
- 14
- 15

Lenovo

- 500E
- C330
- MIIX 630
- MOTO G5 PLUS
- S330
- TAB 4 10 PLUS
- TAB 4 8 PLUS
- YOGA TAB 3 PLUS

seria Thinkpad

- 13
- A285
- A485
- E480
- E485
- E490
- E570
- E580
- E585
- E590
- L390
- L390 YOGA
- L480
- L580
- P51S
- P52S
- T470
- T470S
- T480
- T480S
- T490
- T570
- T580
- T590
- X

- X1 EXTREME
- X1 TABLET
- X1 YOGA
- X1 CARBON
- X270
- X280
- X380 YOGA
- X390
- YOGA 700
- YOGA 720
- YOGA 730
- YOGA 900
- YOGA 910
- YOGA 920

seria IdeaPad

- 720
- 720S
- 730S

Microsoft

seria Lumia

- 950

seria Surface Book 2

- 13.5
- 15

Nintendo

- SWITCH

Razer

- BLADE STEALTH 13

Samsung

seria Galaxy

- A3
- A5
- A6
- A7

- A8
- C10
- NOTE 7
- NOTE 8
- NOTE 9
- S10
- S10E
- S8
- S9
- TAB S3
- TAB S4
- TABPRO S

Sony

Xiaomi

- MI NOTEBOOK AIR 12.5
- MI NOTEBOOK AIR 13.3
- MI NOTEBOOK PRO

seria Mi

- 4C
- 5
- 5S
- 6
- 8
- A1
- A2
- MAX 2
- MAX 3
- MIX
- MIX 2
- MIX 2S
- NOTE 2
- NOTE 3
- NOTEBOOK PRO
- PAD 2
- REDMI PRO
- REDMI PRO 2