

HP: 11 G2, 14-AC, 14-D, 14-D000, 14-DK0017NW, 14-G, 14-R, 14-W, 15-AC, 15-AC100, 15-AC107TU, 15-AC112TU, 15-AC113CL, 15-AC130CA, 15-AC130DS, 15-AC133DS, 15-AC134DS, 15-AC134TU, 15-AC135DS, 15-AC137CL, 15-AC137DS, 15-AC142DX, 15-AC142TU, 15-AC152TU, 15-AC188TU, 15-AC600, 15-AC610TU, 15-AF, 15-BS155NW, 15-D, 15-D000, 15-D030NR, 15-D053NR, 15-DA1027NW, 15-DB0030NW, 15-F, 15-F000, 15-F023WM, 15-F024WM, 15-F027CA, 15-F033WM, 15-F059WM, 15-F085WM, 15-F100, 15-F199NR, 15-F200, 15-F215DX, 15-F222WM, 15-F233WM, 15-F240CA, 15-F269NR, 15-F271WM, 15-F272WM, 15-F278NR, 15-F300, 15-F337NR, 15-F337WM, 15-F355NR, 15-F387WM, 15-G, 15-G000, 15-G000NA, 15-G000NC, 15-G010DX, 15-G010LA, 15-G013CL, 15-G039DS, 15-G039WM, 15-G041CY, 15-G041DS, 15-G068CL, 15-G069CL, 15-G075NR, 15-G082NR, 15-G088CA, 15-G100, 15-G100CA, 15-G121DS, 15-H, 15-H000, 15-R, 15-R000, 15-R034CA, 15-R058TU, 15-R063NR, 15-R067TU, 15-R100, 15-RA073NW, 15-RA097NW, 17-BY0019NW, 17-P, 17-P000, 17-P010NW, 17-P100, 17-P100NA, 17-P100ND, 17-P100NV, 17-P100NW, 17-P100UR, 17-P101NA, 17-P101NS, 17-P101NV, 17-P110NW, 17-P120WM, 17-P121DX, 17-P131NF, 17-P132NB, 17-P150NA, 17-P150NM, 17-P160NW, 17-P162NW, 17-P170NW, 17-P180NW, 210 G1, 215 G1, 240 G2, 240 G3, 240 G4, 240 G5, 245 G2, 245 G3, 245 G4, 245 G5, 250, 250 G2, 250 G3, 250 G5, 250 G6, 255, 255 G2, 255 G3, 255 G4, 255 G5, 255 G6, 256 G3, 256 G4, 340 G2, 350 G2, 355 G2, TPN-Q159, TPN-W112, TPN-W121, TPN-W122

HP Chromebook: 11 G3, 11 G4, 11 G5, 11-2100, 11-2200, 11-2201LA, 14 G1, 14 G3, 14 G4, 14-AK

HP EliteBook: 1030 G1, 1040 G2, 1040 G3, 255 G5, 256 G3, 256 G4, 340 G2, 725 G2, 725 G3, 725 G4, 745 G3, 755 G3, 820, 820 G1, 820 G2, 820 G3, 820 G4, 825 G2, 840, 840 G3, 840 G4, 840R G4, 850, 850 G3, 850 G4

HP EliteBook Folio: 1020 G1, 1020 G2, 1040, 1040 G1, 1040 G2, 1040 G3

HP EliteBook Revolve: 810

HP Envy: 13-AD103NW, 15-AS152NR, 15-AS166NR, 15-AS168NR, 15-AS191MS, X360 15-U000, X360 15-U010DX, X360 M6-AQ003DX, X360 M6-AQ005DX, X360 M6-AQ103DX, X360 M6-AQ105DX, X360 M6-AR000, X360 M6-AR004DX

HP Pavilion: 13-AN0003NW, 14-CE3001NW, 15-D017CL, 15-F024WM, 15-F033WM, 15-F355NR, 15-F387WM, 15-G100CA, 15-G121DS, 15-N200, 15-P, 17-F, 17-F028DS, 17-F028NR, 17-P110NW, 17-P160NW, X360

HP ProBook: 11 EE G1, 11 EE G2, 430 G3, 430 G4, 440 G3, 440 G4, 450 G3, 450 G4, 450 G5, 450 G8, 455 G3, 640 G2, 640 G3, 645 G2, 650 G2, 650 G3, 655 G2

HP Spectre: 13 PRO, X360 13T-4000

HP Split: 13-G110DX, 13-G118CA, 13-G160BR, 13-G180LA, 13-G190LA, 13-M001TU, 13-M002TU, 13-M003TU, 13-M004TU, 13-M005TU, 13-M005TU, 13-M006TU, 13-M007TU,

13-M008TU, 13-M009TU, 13-M010DX, 13-M010TU, 13-M011TU, 13-M100BR, 13-M100LA, 13-M102TU, 13-M110BR, 13-M110CA, 13-M110DX, 13-M111SA, 13-M115SG, 13-M160BBR

HP Stream: 11-AK0502SA, 14-AX002NW, 14-CB050NW