

HP Envy: 1130EW, 13-2157NR, 4-1000, 4-1001TX, 4-1003TU, 4-1004TU, 4-1009TX, 4-1010TU, 4-1013TX, 4-1014TU, 4-1014TX, 4-1015TU, 4-1015TX, 4-1018TU, 4-1020TU, 4-1021TU, 4-1023TU, 4-1024TU, 4-1025T, 4-1025TU, 4-1026TU, 4-1028TU, 4-1029TU, 4-1030TX, 4-1031TU, 4-1032TX, 4-1033TX, 4-1034TX, 4-1035TX, 4-1045TU, 4-1048TU, 4-1050BR, 4-1050TU, 4-1051TU, 4-1051TX, 4-1052TU, 4-1052TX, 4-1053TU, 4-1053TX, 4-1054TU, 4-1054TX, 4-1056TX, 4-1057TX, 4-1060TX, 4-1061TX, 4-1102TX, 4-1103TU, 4-1103TX, 4-1104TU, 4-1104TX, 4-1105DX, 4-1105TU, 4-1105TX, 4-1106TU, 4-1106TX, 4-1107TU, 4-1108TU, 4-1109TU, 4-1109TX, 4-1110TU, 4-1110TX, 4-1110US, 4-1111TX, 4-1115DX, 4-1117NR, 4-1130EW, 4-1130US, 4-1150BR, 4-1150LA, 4-1152LA, 4-1155LA, 6-1000, 6-1001TU, 6-1001TX, 6-1002TU, 6-1003TU, 6-1003TX, 6-1004TX, 6-1005TU, 6-1005TX, 6-1006TU, 6-1007TU, 6-1007TX, 6-1008TX, 6-1009TX, 6-1010TU, 6-1010TX, 6-1011TU, 6-1011TX, 6-1012TU, 6-1013TU, 6-1013TX, 6-1014TU, 6-1014TX, 6-1015TU, 6-1015TX, 6-1016TU, 6-1016TX, 6-1017TU, 6-1017TX, 6-1018TU, 6-1018TX, 6-1019TU, 6-1019TX, 6-1021TU, 6-1022TU, 6-1022TX, 6-1023TX, 6-1024TX, 6-1025TU, 6-1025TX, 6-1026TU, 6-1032EG, 6-1051ER, 6-1101TU, 6-1102TU, 6-1110SG, 6-1110SW, 6-1110US, 6-1111NR, 6-1129WM, 6-1131NR, 6-1146NR

HP Envy Sleekbook: 14-B000, 14-B000ED, 14-B000EE, 14-B000EI, 14-B000EO, 14-B000ET, 14-B001EA, 14-B001EIA, 14-B001TX, 14-B002TX, 14-B004TU, 14-B005AU, 14-B006AU, 14-B007AU, 14-B008AU, 14-B009AU, 14-B009TU, 14-B010AU, 14-B010US, 14-B012AU, 14-B013AU, 14-B014AU, 14-B014TU, 14-B015AU, 14-B015DX, 14-B022AU, 14-B023TX, 14-B024TU, 14-B025TU, 14-B028AU, 14-B028TU, 14-B030TU, 14-B031TU, 14-B034TU, 14-B035TU, 14-B038TU, 14-B043TU, 14-B062LA, 14Z-B000, 4-1005XX, 4-1007, 4-1008TX, 4-1010US, 4-1016NR, 4-1024, 4-1030TU, 4-1032TU, 4-1036TX, 4-1037TX, 4-1038TX, 4-1043CL, 4-1043TU, 4-1044TU, 4-1046TU, 4-1047TU, 4-1049TU, 4-1055TU, 4-1055TX, 4-1058TX, 4-1059TX, 4-1062TX, 4-1063TX, 4-1064TX, 4-1065TX, 4-1066TX, 4-1101TU, 4-1102TU, 4-1107TX, 4-1108TX, 4T-1000, 6-1000, 6-1000EV, 6-1000SV, 6-1002ET, 6-1002ST, 6-1004TX, 6-1005TU, 6-1005TX, 6-1005TX, 6-1006EA, 6-1006SA, 6-1010EB, 6-1010EO, 6-1010SO, 6-1010US, 6-1011ED, 6-1011NR, 6-1011SD, 6-1013TX, 6-1014NR, 6-1014TX, 6-1015NR, 6-1015TX, 6-1016T, 6-1017CL, 6-1019NR, 6-1020EV, 6-1020SV, 6-1020TU, 6-1021NR, 6-1023TU, 6-1024TU, 6-1031ER, 6-1040CA, 6-1047CL, 6-1048CA, 6-1050EX, 6-1050SX, 6-1054ER, 6-1058ER, 6-1071EF, 6-1071SF, 6-1080EX, 6-1080SX, 6-1083CA, 6-1090EE, 6-1101TX, 6-1102TX, 6-1103TX, 6-1140CA, 6-1168CA, 6-1180CA, 6T-1000, 6Z-1000

HP Envy Spectre: 13-2000, 13-2000EA, 13-2000EB, 13-2000ED, 13-2000EE, 13-2000EG, 13-2000EG XT, 13-2000EL, 13-2000EN, 13-2000EO, 13-2000ER, 13-2000ES, 13-2000ET, 13-2000EW, 13-2003EF, 13-2004TU XT, 13-2005TU XT, 13-2010EE, 13-2010EX, 13-2020EX, 13-2021TU XT, 13-2023TU XT, 13-2050NR, 13-2050NR XT, 13-2057NR, 13-2060EZ, 13-2090LA, 13-2095CA, 13-2113TU XT, 13-2114TU XT, 13-2120TU XT, 13-2150NR, 13-2215TU XT, 13-EF2003 XT, 13T-2000, 14-3000, 14-3000EA, 14-3001TU, 14-3001XX, 14-3003TU, 14-3004TU, 14-3005TU, 14-3006TU, 14-3007TU, 14-3008TU, 14-

3009TU, 14-3010NR, 14-3010TU, 14-3011TU, 14-3012TU, 14-3013TU, 14-3014TU, 14-3015TU, 14-3017NR, 14-3017TU, 14-3018TU, 14-3090CA, 14-3090LA, 14-3100EB, 14-3100ED, 14-3100EE, 14-3100EF, 14-3100EG, 14-3100EL, 14-3100EN, 14-3100EO, 14-3100ER, 14-3100ES, 14-3100ET, 14-3100EW, 14-3100EX, 14-3190LA, 14T-3100, PRO 13-B000 XT

HP Envy Ultrabook: 13-1000, 13-1001TX, 13-1001XX, 13-1002TX, 13-1003XX, 13-1004TX, 13-1005TX, 13-1006TX, 13-1007EV, 13-1007LA, 13-1007TX, 13-1008TX, 13-1010ER, 13-1015ER, 13-1030CA, 13-1030NR, 13-1050EA, 13-1050EF, 13-1050EG, 13-1050ES, 13-1099EO, 13-1099XL, 13-1940EZ, 13T-1000, 4-1000, 4-1000ET, 4-1000SG, 4-1000ST, 4-1001ET, 4-1002TX, 4-1004TX, 4-1005XX, 4-1007TX, 4-1010EA, 4-1010ED, 4-1010EN, 4-1010EW, 4-1010SA, 4-1010SD, 4-1010SN, 4-1010SS, 4-1010SW, 4-1012TU, 4-1015DX, 4-1016TX, 4-1017NR, 4-1017TU, 4-1017TX, 4-1018TX, 4-1019TU, 4-1019WM, 4-1020EA, 4-1020EB, 4-1020ES, 4-1020EW, 4-1020SS, 4-1020SW, 4-1020TX, 4-1023TX, 4-1028TU, 4-1029TU, 4-1030CA, 4-1030ED, 4-1030EN, 4-1030SD, 4-1030SN, 4-1030SS, 4-1030US, 4-1031TU, 4-1031TX, 4-1035SG, 4-1035TU, 4-1035TX, 4-1038NR, 4-1038TU, 4-1038TX, 4-1040SS, 4-1040TU, 4-1041TX, 4-1043CL, 4-1043TX, 4-1044TX, 4-1045TU, 4-1045TX, 4-1046TX, 4-1048TX, 4-1049TX, 4-1050BR, 4-1050CA, 4-1050ER, 4-1050LA, 4-1050TX, 4-1051ER, 4-1051TU, 4-1051TX, 4-1052ER, 4-1052TX, 4-1053TU, 4-1053TX, 4-1054TX, 4-1056TX, 4-1057TX, 4-1060TX, 4-1061TX, 4-1062EF, 4-1062SF, 4-1062TX, 4-1066TX, 4-1070EF, 4-1070EL, 4-1070SF, 4-1080EO, 4-1080EX, 4-1080SX, 4-1090EO, 6T-1000

HP Pavilion: 14-B005SA, 14-B017NR, 14-B070ED, 14-B100, 15-B000, 15-B000ED, 15-B000EJ, 15-B000EM, 15-B000ES, 15-B000ET, 15-B000EV, 15-B000SH, 15-B000SM, 15-B000SQ, 15-B001EE, 15-B001EI, 15-B001EM, 15-B001EO, 15-B001EU, 15-B001EV, 15-B001SE, 15-B001SH, 15-B001SIA, 15-B001SQ, 15-B001SS, 15-B001SU, 15-B001TU, 15-B002ED, 15-B002EE, 15-B002EJ, 15-B002EK, 15-B002EM, 15-B002EQ, 15-B002EV, 15-B002SE, 15-B002SH, 15-B002SK, 15-B002SM, 15-B002SX, 15-B002TU, 15-B002TX, 15-B003EE, 15-B003EIA, 15-B003EM, 15-B003EU, 15-B003EV, 15-B003SE, 15-B003SH, 15-B003SIA, 15-B003SM, 15-B003SQ, 15-B003TU, 15-B003TX, 15-B004EV, 15-B004TU, 15-B005EJ, 15-B005EL, 15-B005TU, 15-B006ED, 15-B006EE, 15-B006EO, 15-B006SE, 15-B007EE, 15-B007SE, 15-B007SX, 15-B008EE, 15-B008SE, 15-B008TU, 15-B008TX, 15-B009EE, 15-B009SE, 15-B009SS, 15-B009TU, 15-B010EJ, 15-B010ES, 15-B010ET, 15-B010EW, 15-B010SS, 15-B010ST, 15-B010SW, 15-B010TU, 15-B010TX, 15-B010US, 15-B011ET, 15-B011NR, 15-B011ST, 15-B011TU, 15-B012EE, 15-B012NR, 15-B012SE, 15-B012TU, 15-B013EI, 15-B013TU, 15-B020ET, 15-B020EW, 15-B020ST, 15-B020SW, 15-B023CL, 15-B025EC, 15-B025SC, 15-B027EC, 15-B027EL, 15-B027SC, 15-B030EB, 15-B030EC, 15-B030EG, 15-B030EL, 15-B032EL, 15-B033EL, 15-B035EL, 15-B036EZ, 15-B038CA, 15-B040EP, 15-B040SL, 15-B040SP, 15-B041EB, 15-B041SB, 15-B042SF, 15-B043SF, 15-B044SF, 15-B045EL, 15-B045SF, 15-B050EA, 15-B050EB, 15-B050EL, 15-B050EW, 15-B050SA, 15-B050SF, 15-B050SR, 15-B050SW, 15-B051EA, 15-B051EL, 15-B051ER, 15-B051SF, 15-B051SR, 15-B052EA, 15-B052SA, 15-B053EA, 15-B053SR, 15-

B054SF, 15-B055CA, 15-B055ER, 15-B055SR, 15-B058SR, 15-B060SF, 15-B061EL, 15-B061SF, 15-B070ED, 15-B070SL, 15-B072ED, 15-B076ED, 15-B079ER, 15-B079SR, 15-B086ER, 15-B086SR, 15-B090SD, 15-B107EO, 15-B109WM, 15-B110SW, 15-B115EL, 15-B115EO, 15-B120EW, 15-B120LA, 15-B123NR, 15-B140US, 15-B146SA, 15-B150EW, 15-B151SG, 15-B152SG, 15-B155EW, 15-B155SW, 15-B156ER, 15T-B000