

Lenovo: 300-22ISU, 510-22ISH, C20, C20-30, C40, C40-05, C40-30, C50, C50-30, F0BX, F0CB, G400, G410, G500, G500H, G500S, G510, G510 4056, G510 4059, G510 59-406675, G510 59-441358, G510 80A8, G510S, G700, G710, Z51, Z51-70, Z51-70 80K6

IdeaCentre: 520-22AST, 520-22ICB, 520-22IKL, 520-22IKU, 520-24ARR, 520-24AST

IdeaPad: 700-15ISK, 720S, 720S-15IKB, G500, G500S TOUCH, G510, Y40, Y40-70, Y40-80, Y50, Y50 TOUCH, Y50-80, Y50-80 TOUCH, Z510, Z510 59400193, Z510 59400198, Z510 TOUCH, Z710

Thinkpad: E470, E560P, E570, HELIX, L440, L440 20AS, L540, S440, S5, S531, S540, T440, T440P, T440S, T440S 20AR, T450P, T450S, T540P, X1 CARBON, X240, X240 TOUCH, YOGA

ThinkPad Edge: E431, E440, E531, E540