

Acer Aspire: 1200, 1300, 1410, 1450, 1640, 1650, 1680, 1690, 2000, 2010, 2020, 2930, 3000, 3030, 3500, 3610, 3620, 3630, 3640, 3650, 3660, 3670, 3935, 4220, 4410, 4520, 4530, 4535, 4540, 4715, 4720, 4730, 4735, 4810, 4930, 4935, 5000, 5030, 5050, 5100, 5110, 5320, 5330, 5500, 5515, 5530, 5532, 5535, 5550,

Acer Extensa: 2350, 4010, 4130, 4220, 4230, 4420, 4430, 4620, 4630, 5010, 5120, 5210, 5230, 5235, 5420, 5610, 5620, 5635, 6600, 7230,

Acer Ferrari: 1000, 1100, 1200,

Acer TravelMate: 660, 720, 7230, 730, 7320, 7330, 740, 7520, 800, 8000, 8100, 8331, 8371, 8431, 8471, 8531, 8571,

Advent: 1515 NORDIC, 2008, 3086 NORDIC, 4470, 5365, 5372, 5470, 5471, 5480, 5490, 5493, 6000, 6410, 6412, 6413, 6413A, 6414, 6414B, 6415, 6416, 6417, 6418, 6419, 6421, 6422, 6520, 6521, 6522, 6551, 6552, 6553, 6555, 6651, 7002, 7006, 7007, 7008, 7009, 7011, 7012, 7013, 7014, 7015, 7016, 7017, 7018, 7019, 7026, 7027, 7035, 7038, 7040, 7041, 7045, 7048, 7049, 7053, 7056, 7060, 7061M, 7068, 7070, 7072, 7073, 7078, 7079, 7080, 7081, 7086, 7087, 7088, 7089, 7090, 7094, 7095, 7096, 7100, 7105, 7111, 7200, 7201, 7204, 7206, 7211, 7250, 7255, 7300, 7340, 7360, 7365, 8001, 8109, 8115, 8117, 8212, 8275, 8315, 8480, 9912, MILANO ELITE, QC430, QRC430,

Aristo Slim: 200, 330,

Aristo Smart: 300S, 340, 350, 420, 440,

Asus: 32V, A2L, A3AC, A3E, A3F, A3FC, A3FP, A3G, A3H, A3HF, A3N/L, A3V, A3VC, A3VP, A4000D, A4000G, A4000K, A41ID, A41IE, A41IN, A4700D, A4700K, A52D, A52F, A52F-EX1240U, A52JB, A52JK, A52JT, A52N, A53E, A53SC, A53SD, A53SJ, A53SK, A53SM, A53SV, A53TA, A53TK, A53U, A53Z, A550, A5E, A5EB, A5EC, A6000, A6000G, A6000K, A6000NE, A6000U, A600KM, A6700G, A6700NE, A6F, A6G, A6JC, A6JM, A6K, A6KT, A6L, A6M, A6NE, A6R, A6RP, A6T, A6TC, A6U, A6VC, A84BR, A84SD, A84SJ, A84SM, A8E, A8F, A8FM, A8H, A8HE, A8JA, A8JC, A8JE, A8JM, A8JN, A8JR, A8JV, A8LE, A8M, A9RP, A9T, B1, B1000, B1400A, B1500, B1500A, B43E, B43F, B43S, B53E, B53F, B53J, B53S, B80A, F2F, F2HF, F2J, F2JA, F302LJ, F302LJ-R4051H, F302LJ-R4052H, F3F, F3H, F3JC, F3JE, F3L, F3Q, F450JF, F450L, F450LA, F450LB, F50GX, F50Q, F50Z, F550, F550C, F550CA, F550L, F555, F555L, F555LB, F555LB-X0144T, F555LB-X0236T, F555LJ, F555LJ-X0943T, F555LJ-X0945T, F555LJ-X0947T, F555LJ-X0948T, F555LJ-X0949T, F555LJ-X1265T, F555Q, F555QA, F555QA-DM343T, F555UJ-X0044T, F5G, F5L, F5M, F5N, F5R, F5RI, F6A, F6E, F80CR, F80L, F80Q, F83T, F83VD, F9F, F9J, G1, K40C, K40IJ, K40IL, K40IN, K501U, K50C, K52F, K52N, K550CA, K550CC, K550DP, K550L, K555, K555L, K555LD, K55A, K55DR, K55N, K55V, K55VD, K55VM, K56, K56C, K56CA, K56CB, K56CM, K61IC, K61L, K61LC, K62F, K70IJ, K72F, K72JR, K84C, K84H, K84HR, K84HY, K84L, K84LY, L1, L1A, L1B, L2, L2B, L2D, L2E, L31, L32, L3200, L34, L3400, L35, L3500, L3500D, L3500T, L3800, L3800C, L3C, L3CE, L3D, L3H, L3S, L3TP, L4, L4E, L4H, L4L, L4R, L84, L84B, L84C,

L84CE, L84F, L84K, L84L, LAMBORGHINI VX1, M1A, M2, M2A, M2C, M2E, M2N, M2NE, M3AE, M3N, M3NP, M5, M5000N, M51A, M51E, M52V, M5A, M5AE, M5N, M5NP, M6, M6000N, M6000R, M6700NA, M6700NE, M6800NE, M6A, M6C, M6CE, M6FM, M6N, M6NA, M6NE, M6R, M6RF, M6V, M6VA, M7A, M7V, M9A, M9F, M9J, M9V, N10E, N10J, N10JC, N10JG, N10JH, N20A, N20H, N51A, N51TE, P24E, P30A, P31F, P31JG, P31SD, P31SG, P41JF, P41SV, P50IJ, P52F, P81IJ, PL30JT, PL80JT, PL80VT, Q301LA, Q301LP, R1E, R1F, R300, R510, R510C, R510CA, R510CC, R510L, R510LA, R510LB, R510LC, R510LN, R510VC, R512C, R512CA, R512MA, R513, R513C, R513CL, R513E, R556, R556DG, R556L, R556LA, R556LB, R556LB-X0402T, R556LB-XO153H-8, R556LF, R556U, S121, S121E, S1A, S1B, S1N, S2A, S2B, S2N, S2NE, S3N, S56CM-XX079V-12, S5A, S5N, S5NE, S5NP, S6F, S6FM, S7F, S7FM, U1, U1E, U1F, U20A, U24E, U2E, U30JC, U30SD, U31F, U31SD, U31SG, U35F, U35JC, U3S, U3SG, U43F, U45JC, U50VG, U53F, U53JC, U5A, U5F, U6E, U80V, U81A, U82U, U82U-WX029, U84SG, UL20A, UL20FT, UL30JT, UL30VT, UL50A, UL50AG, UL50AT, UL50VF, UL50VG, UL50VS, UL50VT, UL80A, UL80AG, UL80JT, UL80V, UL80VS, UL80VT, UX20, UX30S, UX31E, UX50V, V6J, V6JE, V6V, V6VA, VX1, W1, W1G, W1GA, W1GC, W1J, W1JA, W1JB, W1JC, W1N, W1NA, W1V, W1VC-S007P, W3A, W3J, W3N, W3V, W3Z, W5A, W5AE, W5F, W5FE, W5FM, W6A, W6F, W6FP, W7E, W7F, W7J, W7S, W7SE, X20E, X20S, X20SG, X32A, X32JT, X32U, X32VT, X33JC, X33SD, X34F, X34JC, X35F, X35JG, X35SD, X35SG, X36JC, X36SD, X36SG, X37U, X401A1, X402, X40U, X42DE, X42DQ, X42DR, X42DY, X42F, X42JA, X42JB, X42JC, X42JE, X42JK, X42JP, X42JR, X42JV, X42JY, X42JZ, X42N, X501, X501A, X501U, X502C, X502CA, X51C, X51EAE, X51H, X51L, X51R, X51RL, X52BY, X52DE, X52DR, X52DY, X52F, X52JB, X52JC, X52JE, X52JK, X52JR, X52JT, X52JU, X52JV, X52N, X52S, X52SG, X550, X550C, X550CA, X550CC, X550CL, X550D, X550E, X550L, X550V, X550VB, X550VC, X551, X551C, X551CA, X551CA-SX024H, X551M, X551MA, X552, X552C, X552CL, X552E, X552EA, X552L, X552LA, X552M, X552WE, X554L, X554LA, X554LD, X555, X555BP, X555L, X555LF, X555LJ, X555LN, X555LP, X555QA, X555YA, X555YI, X55A, X55C, X55CA, X55U-SX052H, X55VM, X58C, X58L, X58LE, X5AVC, X5AVN, X5BTP, X5BVF, X5BVG, X5BVN, X5C, X5DAB, X5DAD, X5DAF, X5DC, X5DID, X5DIE, X5DIJ, X5DIL, X5DIN, X5DIP, X5EAC, X5EAE, X5GAG, X5GAT, X5GVG, X5GVT, X5IBY, X5IDE, X5IDR, X5IDY, X5IF, X5IJB, X5IJC, X5IJE, X5IJK, X5IJR, X5IJT, X5IJU, X5IJV, X5IN, X5IJJ, X5KF, X5KJC, X5LDA, X5LJT, X5LJU, X5LJV, X5MDA, X5MJF, X5MJG, X5MJL, X5MJN, X5MJQ, X5MSM, X5MSN, X5MSV, X5MTA, X5MTK, X5PE, X5PSJ, X5QSF, X5QSL, X5RE, X70AB, X70AC, X70AD, X70AF, X70E, X70F, X70IC, X70IJ, X70IL, X70IO, X70KR, X70L, X70SE, X70SR, X70Z, X751L, X751LD, X756UV, X80A, X80H, X80L, X80LE, X80N, X80Z, X81SC, X81SE, X81SG, X81SR, X84C, X84H, X84HR, X84HY, X84L, X84LY, Z35H, Z35L, Z63A, Z65H, Z65R, Z84F, Z84FM, Z84J, Z923E, Z92F, Z92G, Z92GA, Z92J, Z92JA, Z92JC, Z92JE, Z92JM, Z92K, Z92KM, Z92KT, Z92L, Z92M, Z92NE, Z92R, Z92RP, Z92T, Z92TC, Z92U, Z92V, Z92VA, Z92VC, Z92VM, Z9R,

Asus Vivobook: S300C, S400C, S400CA, S501,

Benq Joybook: 2100, 5000, 5100, 7000, A51, A51E, A52, A52E, A52EG, R22E, R53, S31, S31V, S53, S53W, S72,

Dell Inspiron: 3000, 300233XT, 3200, 3500, 3500D233XT, 3500D266GT, 3500D300GT, 3500XT, 7000, D233XT, D266GT, D300GT,

Fujitsu Amilo / Amilo Pro: K7610, L7310, L7310G, L7310GW, L7310W, V2010, V2030, V2035, V2040, V2045, V2055, V2065, V2085, V3205, V3405, V3505, V8010,

Fujitsu Lifebook: UH552, UH572, UH572M,

Fujitsu-Siemens Amilo Pro V2055,

Fujitsu LifeBook: S752,

Gateway: 1100, 1150, 1200, 1400, 1450, 2100, 2150, 2200, 2300, 2300LS, 2300XL, 2500, 2500LS, 2500SE, 2500XL, 2550, 5100, 5100XL, 5150LS, 5150SE, 5150XL, 9100, 9100LS, 9100SE, 9100XL, 9150, 9300, 9300CX, 9300XL,

HP Omnibook: 6000, 900,

Lenovo: B550, B550L, G450L, G455, G455G, G460, G460A, G460E, G460G, G460L, G465, N500,

Lenovo 3000: G430, G450, G460, G465, G510, G530, G550, G555, G560, G560E, G565, G570, G575, G770,

Lenovo Essential: B470, B550, B940, G450, G455, G460, G465, G530, G550, G555, G560, G570, G575, G770,

Lenovo IdeaCentre: Q190,

Lenovo IdeaPad: U110, U350, U350-2963-23U, U350-2963-25U, U350-2963-26U, U350-2963-27U, U410, U550, V360, V460, V470, V560, V570, Y300, Y300-7759, Y300-9449, Y450, Y460, Y470, Y530, Y530-4051-54U, Y530-4051-62U, Y560, Y560P, Y570, Y650, Y650-4185-36U, Y650G, Z360, Z370, Z460, Z465, Z470, Z560, Z565, Z575,

LG: E300, E510,

Maxdata: ARTIST DENVER

Maxdata Eco: 3100 X, 3100T, 3150X, 3200X, 4000IW, 4000IW SELECT, 4000IW TOP SELECT, 4011 IW, 4011IW, 4011IW SELECT, 4011IW VISTA, 4510IW,

Maxdata M-Book: 1000T,

Maxdata Performance: 110T, 120T,

Maxdata Pro: 4511 IW, 4700 IW, 5000 IR, 5000IR, 5000IR SELECT, 6000 IW, 600IW, 600IW SELECT, 600IW TOP SELECT, 6100 IW, 650, 650 X, 650T, 650X, 7000X, 800 IW, 800IW, 800IW SELECT, 800IW TOP SELECT, 8100IS,

Maxdata Vision: 350, 350M, 4200X, 450, 450T, 755, FX 460, FX 470, FX460, FX470,

Medion: MD96350,

Medion Akoya: E5214, E5217, E5218, E7222, E7223, E7223T, E7415, E7416, E7416T, S4213, S4214, S4215, S4216, S4611, S4613,

MSI: A6200, CR400, CR41, CR410, CR42 2M, CR420, CR420MX, CR460, CR500, CR600, CR61, CR610, CR620, CR630, CR640, CR70, CR700, CR720, CX410, CX413, CX420, CX420MX, CX480 (BATERIA 6 OGNIWOWA), CX500, CX500DX, CX600, CX605, CX61, CX620, CX623, CX650, CX70, CX700, CX705, CX705MX, CX720, EX460, EX465, EX465MX, FR600, FR600 3D, FR720, FX400, FX420 (BATERIA 6 OGNIWOWA), FX600MX, FX610MX, FX720, GP60, P600, PR300, S6000, U250, X350, X360, X370, X400, X420, X430, X460, X600, X600 PRO, X620,

Packard Bell EasyNote: F, LJ 65, LJ61, LJ63, LJ67, LJ71, LJ73, LJ75, LJ77, LK11BZ, LK13BZ, LM81, LM82, LM83, LM85, LM86, LM87, LM94, LM98, LS11HR, LS11SB, LS13HR, LS13SB, LS44HR, LS44SB, NJ31, NJ32, NJ65, NJ66, NM85, NM86, NM87, NM98, NS11HR, NS44HR, NS45, TH36, TJ61, TJ62, TJ63, TJ64, TJ65, TJ66, TJ67, TJ68, TJ71, TJ72, TJ73, TJ74, TJ75, TJ76, TJ77, TJ78, TK11BZ, TK36, TK37, TK81, TK83, TK85, TK87, TM01, TM05, TM80, TM81, TM82, TM83, TM85, TR81, TR82, TR83, TR85, TR86, TR87,

Toshiba Equium: L10-142, M40X-149,

Toshiba Mini: NB550D-10G,

Toshiba Portege: R930-1H5, 700-S1332W, R700-S1311, R700-S1312, R700-S1320, R700-S1322, R700-S1322W, R700-S1330, R700-S1331, R700-S1332, R705-P25, R705-P35, R705-P40, R705-P41, R705-P42, R705-ST2N03, R705-ST2N04, R830-S8310, R830-S8312, R830-S8320, R830-S8322, R830-S8330, R830-S8332, R835-P50X, R835-P55X, R835-P56X, R835-P70, R835-P75, R835-P81, R835-P83, R835-P84, R835-P86, R835-ST3N01,

Toshiba Satellite: A100-209, A100-218, A100-220, A100-232, A100-241, A100-269, A100-270, A100-295, A100-528, A100-529, A100-570, A100-649, A100-785, A100-S8111TD, A100-ST3211, A105-2141, A105-S171, A105-S2021, A105-S2071, A105-S2131, A105-S2201, A105-S2231, A105-S2236, A105-S2712, A105-S361, A105-S3611, A105-SS2716, A110-101, A110-105, A110-110, A110-133, A110-177, A110-178, A110-195, A110-253, A110-260, A110-293, A110-334, A110-339, A110-370, A110-ST1111, A135-2266, A135-2276, A135-S2246, A135-S2256, A135-S2286, A135-S2296, A135-S2306, A135-S4407, A135-S4417, A135-S4427, A135-S4437, A135-S4447, A135-S4457, A135-S4467, A135-S4477, A135-S4478, A135-S4487, A135-S4488, A135-S4498, A135-

S4499, A135-S4517, A85-S107, A85-S1071, A85-S1072, A85-S178TD, A85-SP107, A85-SP1072, C55-A-1FP, C55-A5204, C55-A5281, C645D-S4024, C650, C650-ST2N01, C650-ST2NX1, C650-ST2NX2, C650-ST3NX1, C650-ST4N02, C650-ST4NX1, C650-ST5N02, C650-ST5N03, C650-ST5NX1, C650-ST5NX2, C650D-141, C650D-ST2N01, C650D-ST2N02, C650D-ST2NX1, C650D-ST2NX2, C650D-ST3NX2, C650D-ST4N01, C650D-ST4NX1, C650D-ST5N01, C650D-ST5NX1, C655, C655-S5047, C655-S5049, C655-S5052, C655-S5053, C655-S5054, C655-S5056, C655-S5060, C655-S5061, C655-S5068, C655-S5082, C655-S5090, C655-S5092, C655-S5113, C655-S5118, C655-S5119, C655-S5121, C655-S5122, C655-S5125, C655-S5127, C655-S5128, C655-S5129, C655-S5137, C655-S5140, C655-S5141, C655-S5142, C655-S5193, C655-S5195, C655-S5206, C655-S5208, C655-S5211, C655-S5212, C655-S5221, C655-S5225, C655-S5229, C655-S5231, C655-S5235, C655-S5240, C655-S5301, C655-S5305, C655-S5307, C655-S5310, C655-S5312, C655-S5314, C655-S5333, C655-S5335, C655-S5339, C655-S5340, C655-S5341, C655-S5342, C655-S5343, C655-S5501, C655-S5504, C655-S5514, C655D-S5041, C655D-S5042, C655D-S5043, C655D-S5044, C655D-S5045, C655D-S5046, C655D-S5048, C655D-S5051, C655D-S5057, C655D-S5063, C655D-S5064, C655D-S5079, C655D-S5080, C655D-S5081, C655D-S5084, C655D-S5085, C655D-S5086, C655D-S5087, C655D-S5088, C655D-S5089, C655D-S5091, C655D-S5120, C655D-S5124, C655D-S5126, C655D-S5130, C655D-S5133, C655D-S5134, C655D-S5135, C655D-S5136, C655D-S5138, C655D-S5139, C655D-S5143, C655D-S5192, C655D-S5200, C655D-S5202, C655D-S5209, C655D-S5210, C655D-S5226, C655D-S5228, C655D-S5230, C655D-S5232, C655D-S5233, C655D-S5234, C655D-S5236, C655D-S5300, C655D-S5302, C655D-S5303, C655D-S5304, C655D-S5330, C655D-S5331, C655D-S5332, C655D-S5334, C655D-S5336, C655D-S5337, C655D-S5338, C660-120, C660-121, C660-1M4, C660-28R, C660-2F2, C660-2QH, C660-2QV, C660D, C665, C675-S7103, C675-S7200, C675-S7308, C675-S7318, C675-S7321, C675-S7322, C675D-S7212, C675D-S7310, C675D-S7325, C675D-S7328, C850-12R, E105-S1802, E205-S1904, E205-S1980, E305-S1990X, E305-S1995, L10-100, L10-101, L10-102, L10-108, L10-117, L10-119, L10-123, L10-192, L10-193, L10-194, L10-202, L10-204, L10-205, L10-209, L10-223, L10-224, L10-226, L100-103, L100-104, L100-105, L100-111, L100-113, L100-120, L100-121, L100-140, L100-141, L100-165, L100-173, L100-175, L100-194, L15-S1041, L15-SP104, L20-101, L20-121, L20-149, L20-181, L20-182, L20-183, L20-204, L20-205, L20-256, L20-S310TD, L20-SP119, L20E-101, L25-S119, L25-S1192, L25-S1193, L25-S1194, L25-S1195, L25-S1196, L25-SP129, L25-SP139, L30-101, L30-10P, L30-113, L30-114, L30-115, L30-11E, L30-11H, L30-134, L30-140, L30-142, L35-S1054, L35-S2151, L35-S2161, L35-S2171, L35-S2174, L40-12N, L40-12X, L40-135, L40-137, L40-139, L40-13C, L40-13G, L40-143, L455-S5000, L455-S5008, L455-S5009, L455-S5045, L455-S5046, L455-S5975, L455-S5980, L455-S5981, L455-S5989, L455D-S5976, L50-B-115, L50-B-124, L50-B-13D, L500-1EK, L500-1FW, L500-1GK, L510, L635-S3010, L635-S3010BN, L635-S3010RD, L635-S3010WH, L635-S3015, L635-S3020, L635-S3020BN, L635-S3020RD, L635-S3020WH, L635-S3025, L635-S3040,

L635-S3040BN, L635-S3040RD, L635-S3040WH, L635-S3050, L635-S3050BN, L635-S3050RD, L635-S3050WH, L635-S3100, L635-S3100BN, L635-S3100RD, L635-S3100WH, L635-S3104, L635-S3104BN, L635-S3104RD, L635-S3104WH, L645-S4026, L645-S4026BN, L645-S4026GY, L645-S4026RD, L645-S4026WH, L645-S4038, L645-S4055, L645-S4059, L645-S4060, L645-S4102, L645-S4103, L645-S4104, L645-S4104BN, L645-S4104RD, L645-S4104WH, L645-S4108, L645D-S4025, L645D-S4029, L645D-S4030, L645D-S4033, L645D-S4036, L645D-S4037, L645D-S4037BN, L645D-S4037RD, L645D-S4037WH, L645D-S4040, L645D-S4050, L645D-S4050BN, L645D-S4050GY, L645D-S4050RD, L645D-S4050WH, L645D-S4052, L645D-S4053, L645D-S4056, L645D-S4058, L645D-S4058BN, L645D-S4058RD, L645D-S4058WH, L645D-S4100, L645D-S4100BN, L645D-S4100GY, L645D-S4100RD, L645D-S4100WH, L645D-S4106, L645D-S4106BN, L645D-S4106RD, L645D-S4106WH, L655-S5058, L655-S5059, L655-S5060, L655-S5061, L655-S5062, L655-S5065, L655-S5065BN, L655-S5065RD, L655-S5065WH, L655-S5069, L655-S5071, L655-S5072, L655-S5075, L655-S5078, L655-S5078BN, L655-S5078RD, L655-S5078WH, L655-S5083, L655-S5096, L655-S5097, L655-S5098, L655-S5098BN, L655-S5098RD, L655-S5098WH, L655-S5099, L655-S5100, L655-S5100BK, L655-S5100BN, L655-S5100RD, L655-S5100WH, L655-S5101, L655-S5103, L655-S5105, L655-S5106, L655-S5106BN, L655-S5106RD, L655-S5106WH, L655-S5107, L655-S5108, L655-S5111, L655-S5112, L655-S51121, L655-S51122, L655-S5112BN, L655-S5112RD, L655-S5112WH, L655-S5114, L655-S5115, L655-S5117, L655-S5146, L655-S5147, L655-S5149, L655-S5149WH, L655-S5150, L655-S5153, L655-S5154, L655-S5155, L655-S5156, L655-S5156BN, L655-S5156RD, L655-S5156WH, L655-S5157, L655-S5158, L655-S5160, L655-S5161BNX, L655-S5161RDX, L655-S5161WHX, L655-S5161X, L655-S5162X, L655-S5163, L655-S5165, L655-S5166BNX, L655-S5166RDX, L655-S5166WHX, L655-S5166X, L655-S5167X, L655-S5168, L655-S5188, L655-S5191, L655-S5198, L655D-S5050, L655D-S5055, L655D-S5066, L655D-S5066BN, L655D-S5066RD, L655D-S5066WH, L655D-S5067, L655D-S5076, L655D-S5076BN, L655D-S5076RD, L655D-S5076WH, L655D-S5093, L655D-S5094, L655D-S5095, L655D-S5102, L655D-S5102BN, L655D-S5102RD, L655D-S5102WH, L655D-S5109, L655D-S5110, L655D-S5110BN, L655D-S5110RD, L655D-S5110WH, L655D-S5116, L655D-S5145, L655D-S5148, L655D-S5152, L655D-S5159, L655D-S5159BN, L655D-S5159RD, L655D-S5159WH, L655D-S5164, L655D-S5164BN, L655D-S5164RD, L655D-S5164WH, L670-ST2N01, L670-ST3NX2, L670D-ST2N01, L670D-ST2N02, L670D-ST2N03, L670D-ST2N04, L675-S7018, L675-S7020, L675-S7044, L675-S7048, L675-S7051, L675-S7062, L675-S7108, L675-S7109, L675-S7110, L675-S7112, L675-S7113, L675-S7115, L675D-S7013, L675D-S7014, L675D-S7015, L675D-S7016, L675D-S7017, L675D-S7019, L675D-S7022, L675D-S7040, L675D-S7040GY, L675D-S7042, L675D-S7046, L675D-S7049, L675D-S7052, L675D-S7053, L675D-S7060, L675D-S7100, L675D-S7102, L675D-S7102GY, L675D-S7103, L675D-S7104, L675D-S7105, L675D-S7106, L675D-S7107, L675D-S7111, L730-ST4N01, L730-ST5N01, L735-S3210, L735-S3210BN, L735-S3210RD, L735-S3210WH, L735-S3220, L735-S3220RD, L735-S3221,

L735-S3350, L735-S3370, L735-S3375, L735D-S3300, L740-ST4N02, L740-ST5N02, L740-ST6N01, L745-S4210, L745-S4235, L745-S4302, L745-S4310, L745-S4355, L745D-S4214, L745D-S4220, L745D-S4220BN, L745D-S4220GR, L745D-S4220RD, L745D-S4220WH, L745D-S4230, L745D-S4350, L745D-S4350WH, L750, L750-ST4N02, L750-ST4NX1, L750-ST5N02, L750-ST5NX2, L750D-15G, L750D-ST4N01, L750D-ST5NX1, L755-S5213, L755-S5214, L755-S5216, L755-S5239, L755-S5242, L755-S5242BN, L755-S5242GR, L755-S5242RD, L755-S5242WH, L755-S5244, L755-S5245, L755-S5246, L755-S5247, L755-S5248, L755-S5249, L755-S5252, L755-S5253, L755-S5254, L755-S5255, L755-S5256, L755-S5257, L755-S5258, L755-S5271, L755-S5275, L755-S5280, L755-S5281, L755-S5282, L755-S5306, L755-S5308, L755-S5311, L755-S5349, L755-S5350, L755-S5351, L755-S5353, L755-S5354, L755-S5355, L755-S5356, L755-S5357, L755-S5358, L755-S5360, L755-S5362, L755-S5364, L755-S5365, L755-S5367, L755-S5368, L755D-S5204, L755D-S5218, L755D-S5227, L755D-S5241, L755D-S5250, L755D-S5251, L755D-S5279, L755D-S5347, L755D-S5348, L755D-S5359, L755D-S5361, L755D-S5363, L770-ST4NX1, L770-ST5NX2, L770D-ST4N01, L770D-ST5NX1, L775-S7105, L775-S7240, L775-S7241, L775-S7243, L775-S7245, L775-S7248, L775-S7250, L775-S7307, L775-S7309, L775-S7350, L775-S7352, L775-S7355, L775D-S7206, L775D-S7210, L775D-S7220, L775D-S7222, L775D-S7223, L775D-S7226, L775D-S7228, L775D-S7304, L775D-S7305, L775D-S7330, L775D-S7332, L775D-S7340, L775D-S7345, L830-14G, L855-10T, L855-16H, M30X-1593, M30X-214, M30X-40, M30X-60, M30X-80, M30X-S114, M30X-S1592, M30X-S171, M30X-S181, M30X-S191, M30X-S221, M30X-S234, M30X-SP114, M35X-114, M35X-149, M35X-S109, M35X-S111, M35X-S1141, M35X-S1142, M35X-S1143, M35X-S1492, M35X-S161, M35X-S163, M35X-S1631, M35X-S309, M35X-S311, M35X-S3111, M35X-S3112, M35X-S329, M35X-S3291, M35X-S349, M35X-S3491, M35X-SP114, M35X-SP161, M35X-SP171, M35X-SP181, M35X-SP311, M40-294, M40-295, M45-S165, M45-S1651, M45-S1681, M45-S169, M500-ST5401, M500-ST5405, M500-ST5408, M500-ST54X1, M505-S4020, M505-S4022, M505-S4972, M505-S4975, M505-S4980, M505-S4982, M505-S4985-T, M505D-S4000, M505D-S4000RD, M505D-S4000WH, M505D-S4970, M505D-S4970RD, M505D-S4970WH, M55-S139, M55-S1391, M55-S141, M640-ST2N01, M640-ST2N02, M640-ST2N03, M640-ST2NX1, M640-ST3N01X, P740-ST4N01, P740-ST5GX1, P740-ST5N01, P745-S4217, P745-S4250, P745-S4320, P745-S4360, P745-S4380, P745D-S4240, R50-B-11C, R845-S80, R845-S85, R845-ST5N01, R945, T115-S1100, T115-S1105, T115-S1108, T115D-S1120, T115D-S1120RD, T115D-S1121, T115D-S1125, T115D-S1125RD, T135-S1300, T135-S1300RD, T135-S1300WH, T135-S1305, T135-S1305RD, T135-S1305WH, T135-S1307, T135-S1309, T135-S1310, T135-S1310RD, T135-S1310WH, T135-S1312, T135D-S1320, T135D-S1322, T135D-S1324, T135D-S1325, T135D-S1325RD, T135D-S1325WH, T135D-S1326, T135D-S1327, T235-S1350, T235-S1350RD, T235-S1350WH, T235-S1352, T235-S1370, T235-S1370RD, T235-S1370WH, T235D-S1340, T235D-S1340RD, T235D-S1340WH, T235D-S1345, T235D-S1345RD, T235D-S1345WH, T235D-S1360, T235D-S1360RD, T235D-S1360WH,

Toshiba Satellite Pro: C650, C650-EZ1512, C650-EZ1513, C650-EZ1521, C650-EZ1523, C650-EZ1524, C650-EZ1533, C650-EZ1540, C650-EZ1550, C650-EZ1551, C650-EZ1560, C650-EZ1561, C650-Z2510T, L350-S1701, L450-EZ1510, L450-EZ1522, L450-EZ1541, L450-EZ1542, L450-EZ1543, L630-EZ1312, L640-EZ1410, L640-EZ1411, L640-EZ1412, L670-EZ1710, L670-EZ1712, L740-EZ1413, L770-EZ1710, L850-1U7, T110-EZ1110, T110-EZ1120, U400-113, U400-17G, U400-21E, U500-EZ1311, U500-EZ1321, U500-S1322,

Toshiba Tecra: R840-S8410, R840-S8411, R840-S8412, R840-S8413, R840-S8420, R840-S8422, R840-S8430, R840-S8440, R840-S8450,