

Acer Aspire: 1300, 1350, 1450, E5-573G, E5-573G-31Q2, E5-573G-59CS,

Acer Aspire V15 nitro: VN7-571

Acer Ferrari: 1000, 3000, 3200, 3400, 4000, 5000

Acer Quanta: Z500, Z500A, Z500N

Actina: VIPER, WEBBOOK

Adax: 2300GT

Advent: 1015 NORDIC, 2027, 3082 NORDIC, 7001, 7004, 7099, 8215

Aristo Prestig: 1600

Asus: A1D, A1F, A2C, A2E, A2G, A2K, A2S, A2T, A3, A3L, A3N, A40AB, A40DE, A40DR, A40DY, A40F, A40JA, A40JC, A40JE, A40JK, A40JP, A40JR, A40JV, A40JY, A40JZ, A40N, A42DE, A42DQ, A42DR, A42DY, A42F, A42JA, A42JB, A42JC, A42JE, A42JK, A42JP, A42JR, A42JV, A42JY, A42JZ, A42N, A43BR, A43BY, A43E, A43SA, A43SD, A43SJ, A43SM, A43SV, A43TA, A43TK, A43U, A4D, A4G, A4GA, A4K, A4KA, A4L, A4S, A4SP, A501LX, A501LX-DM099H, A501LX-DM117H, A52BY, A52DE, A52DR, A52DY, A52F-EX943V, A52JB, A52JC, A52JE, A52JK, A52JR, A52JT, A52JU, A52JV, A52N, A53BR, A53BY, A53TK-SX042V, A54C, A54H, A54HR, A54HY, A54L, A54LY, A55, A555, A555L, A55N, A5E, A5EB, A5EC, A6000, A6BA, A6F, A6G, A6J, A6JA, A6JC, A6JE, A6JM, A6K, A6KM, A6KT, A6L, A6M, A6NE, A6R, A6RP, A6T, A6TC, A6U, A6V, A6VA, A6VC, A6VM, A72DR, A72DY, A72F, A72JK, A72JR, A72JT, A72JU, A73BR, A73BY, A73E, A73SD, A73SJ, A73SM, A73SV, A73TA, A73TK, A7C, A7CB, A7CC, A7CD, A7D, A7DB, A7DC, A7F, A7G, A7J, A7JB, A7JC, A7K, A7M, A7S, A7SN, A7SV, A7T, A7U, A7V, A7VB, A7VC, A83BR, A83BY, A83E, A83SA, A83SD, A83SJ, A83SM, A83SV, A83TA, A83TK, A83U, A8D, A8DC, A8J, A8JA, A8JC, A8JE, A8JM, A8JN, A8JP, A8JR, A8JS, A8M, A8N, A8SC, A8SE, A8SG, A8SR, A8T, A8TC, A8TM, A93SM, A93SV, A9RP, A9T, ADAPTERS, B1A, B23, B23E, B23G, B23GI, B43J, B50A, B50A-AP014E, B50A-AQ057E, B51E, B53S-XH71, B53V-S4018X, C90P, C90S, F2F, F2HF, F2J, F2JE, F3, F3A, F3E, F3F, F3J, F3JA, F3JC, F3JM, F3JP, F3JR, F3JV, F3K, F3KA, F3KC, F3M, F3P, F3S, F3SA, F3SC, F3SE, F3SG, F3SR, F3SV, F3T, F3TC, F3U, F450L, F45A, F45C, F45U, F45VD, F50G, F50N, F50SF, F50SL, F50SV, F52A, F52Q, F550ZE, F5C, F5M, F5N, F5R, F5RL, F5SL, F5SR, F5V, F5VL, F5Z, F6H, F6S, F6V, F6VE, F70SL, F74B, F7E, F7F, F7KR, F7L, F7SE, F7SR, F7Z, F80S, F81SE, F82A, F82Q, F83CR, F83SC, F83VF, F8DC, F8P, F8SA, F8SE, F8SG, F8SN, F8SP, F8SR, F8SV, F8TR, F8V, F8VA, F8VR, F9DC, F9E, F9F, F9J, F9S, F9SG, G1, G1S, G2P, G2PB, G2PC, K40AB, K40AC, K40AD, K40AE, K40AF, K40D, K40IE, K40IP, K41SE, K41VD, K41VS, K42DE, K42DQ, K42DR, K42DX, K42F, K42JA, K42JB, K42JC, K42JE, K42JK, K42JP, K42JR, K42JV, K42JY, K42JZ, K42N, K43BR, K43BY, K43E, K43SA, K43SD, K43SJ, K43SM, K43SV, K43TA, K43TK, K43U, K501LX, K501UX, K50AA, K50AB, K50AD, K50AE, K50AF, K50C, K50ID, K50IE, K50IJ, K50IL, K50IN, K50IP, K51AB, K51AC, K51AE, K51IO, K52DE, K52DR, K52DY, K52F, K52J, K52JB, K52JC, K52JE, K52JK, K52JR, K52JT, K52JU, K52JV,

K52N, K53BR, K53BY, K53E, K53J, K53S, K53SC, K53SD, K53SJ, K53SK, K53SM, K53SV, K53TA, K53TK, K53U, K53Z, K54C, K54H, K54HR, K54HY, K54L, K54LY, K55DR, K55VD, K55VJ, K55VM, K55VS, K60, K60IJ, K60IL, K60IN, K60J, K61IC, K62, K62JR, K70AB, K70AC, K70AD, K70AE, K70AF, K70I, K70IC, K70ID, K70IJ, K70IL, K70IO, K72, K72D, K72DR, K72DY, K72F, K72J, K72JB, K72JK, K72JR, K72JT, K72JU, K72JV, K73BR, K73BY, K73E, K73SD, K73SJ, K73SM, K73SV, K73TA, K73TK, K75, K75DE, K75V, K75VJ, K93SM, K93SV, K95VB, K95VJ, K95VM, L1A, L1B, L2B, L2D, L2E, L3C, L3CE, L3D, L3H, L3S, L3TP, L45, L4E, L4H, L4L, L4R, L50VC, L50VM, L50VN, L5C, L5D, L5DF, L5G, L7B, L7C, L7D, L7E, L7G, L7H, M50SA, M50SR, M50SV, M50VC, M50VM, M50VM-B2, M50VM-B4, M50VM-B5, M50VN, M51KR, M51SE, M51SN, M51SR, M51TA, M51TR, M51VA, M51VR, M60J, M60JV, M60VP, M70SA, M70SR, M70SV, M70T, M70TL, M70VM, M70VN, M70VR, M8A, M8B, M8C, M9A, M9F, M9J, M9V, N43DA, N43JF, N43JM, N43JQ, N43SL, N43SM, N43SN, N45SF, N45SL, N50, N50V, N50VC, N50VG, N50VN, N51A, N51TE, N51TP, N51VF, N51VG, N51VN, N52, N52D, N52DA, N52J, N52JV, N53, N53DA, N53J, N53JF, N53JG, N53JI, N53JN, N53JQ, N53S, N53SM, N53SN, N53SV, N53TA, N53TK, N55, N55S, N55SF, N55SL, N56, N56DP, N56V, N56VB, N56VJ, N56VM, N56VZ, N60DP, N61DA, N61J-X2, N61JA, N61JQ, N61JV, N61VF, N61VG, N61VN, N61VN-A, N6JV, N70DP, N70SV, N71JA, N71JN, N71JQ, N71JV, N71VG, N71VN, N73JF, N73JG, N73JN, N73JQ, N73SM, N73SV, N75SF, N75SL, N76VB, N76VJ, N76VM, N76VZ, N80VB, N80VC, N80VM, N80VN, N80VR, N81A, N81VF, N81VG, N81VP, N82JG, N82JQ, N82JV, N90SC, N90SV, P2710JA, P42J, P42JC, P43E, P43SJ, P52JC, P53E, P53SJ, P6, P80A, P80Q, P80VC, PRO10J, PRO21F, PRO21HF, PRO21J, PRO21JE, PRO23A, PRO23FT, PRO24E, PRO30, PRO31E, PRO31F, PRO31H, PRO31JA, PRO31JC, PRO31JM, PRO31JP, PRO31JR, PRO31JV, PRO31K, PRO31L, PRO31M, PRO31P, PRO31Q, PRO31S, PRO31SA, PRO31SC, PRO31SQ, PRO31SV, PRO31T, PRO31U, PRO32A, PRO32JT, PRO32U, PRO33JC, PRO33SD, PRO34F, PRO34JC, PRO35F, PRO35JG, PRO35SD, PRO36JC, PRO36SD, PRO36SG, PRO37U, PRO44SD, PRO4GJF, PRO4GJM, PRO4GJQ, PRO4GSL, PRO4GSM, PRO4GSN, PRO4HJC, PRO4IJF, PRO4ISV, PRO4JE, PRO4JSJ, PRO4KSF, PRO4KSL, PRO4MSG, PRO50GL, PRO50M, PRO50N, PRO50R, PRO50RL, PRO50SL, PRO50V, PRO50VL, PRO50Z, PRO52H, PRO52L, PRO55GL, PRO55SL, PRO55SR, PRO57A, PRO57KR, PRO57S, PRO57SE, PRO57SN, PRO57TA, PRO57TR, PRO57VA, PRO57VR, PRO58SA, PRO58SR, PRO58VC, PRO58VM, PRO58VN, PRO59L, PRO59LE, PRO5AVC, PRO5AVN, PRO5BVF, PRO5BVG, PRO5CQ, PRO5DAB, PRO5DAD, PRO5DAF, PRO5DC, PRO5DID, PRO5DIE, PRO5DIJ, PRO5DIN, PRO5DIP, PRO5EAC, PRO5EAE, PRO5GAG, PRO5GAT, PRO5GVG, PRO5GVS, PRO5GVT, PRO5IBY, PRO5IDE, PRO5IDR, PRO5IDY, PRO5IIF, PRO5IJB, PRO5IJC, PRO5IJE, PRO5IJK, PRO5IJR, PRO5IJT, PRO5IJU, PRO5IJV, PRO5IN, PRO5IJJ, PRO5KF, PRO5KJC, PRO5LJT, PRO5LJU, PRO5LJV, PRO5MDA, PRO5MJF, PRO5MJG, PRO5MJL, PRO5MJN, PRO5MJQ, PRO5MSM, PRO5MSN, PRO5MSV, PRO5MTA, PRO5MTK, PRO5NBR, PRO5NBY, PRO5NE, PRO5NSC, PRO5NSD, PRO5NSJ, PRO5NSK, PRO5NSM, PRO5NSV, PRO5NTA, PRO5NTK, PRO5NU, PRO5NZ, PRO5PE, PRO5PSJ, PRO5QSF, PRO5QSL, PRO5RE, PRO60E, PRO60F, PRO60JA, PRO60JC, PRO60JE,

PRO60JM, PRO60M, PRO60R, PRO60RP, PRO60TC, PRO60V, PRO60VA, PRO60VC, PRO60VE, PRO60VM, PRO61GX, PRO61Q, PRO61SF, PRO61SL, PRO61SV, PRO61Z, PRO62J, PRO62VP, PRO63DP, PRO64DA, PRO64JA, PRO64JQ, PRO64JV, PRO64VG, PRO64VN, PRO66IC, PRO67F, PRO70C, PRO70DB, PRO70DC, PRO70J, PRO70S, PRO70SV, PRO70T, PRO70V, PRO71E, PRO71F, PRO71KR, PRO71L, PRO71SE, PRO71SR, PRO71Z, PRO72A, PRO72J, PRO72Q, PRO72S, PRO72SI, PRO72VN, PRO73R, PRO73SA, PRO73SR, PRO73VM, PRO73VN, PRO75VN, PRO76SI, PRO78JA, PRO78JQ, PRO78JV, PRO78VG, PRO78VN, PRO79AB, PRO79AC, PRO79AD, PRO79AE, PRO79AF, PRO79IC, PRO79ID, PRO79IJ, PRO79IO, PRO7ADR, PRO7AF, PRO7AJK, PRO7AJR, PRO7AJT, PRO7AJU, PRO7BJF, PRO7BJG, PRO7BJQ, PRO7BSM, PRO7BSV, PRO7CBR, PRO7CBB, PRO7CE, PRO7CSD, PRO7CSJ, PRO7CSM, PRO7CSV, PRO7CTA, PRO7CTK, PRO7DSF, PRO7DSL, PRO80E, PRO80F, PRO80FM, PRO80H, PRO80HM, PRO80JC, PRO80JN, PRO80JP, PRO80JR, PRO80JS, PRO80JT, PRO80LE, PRO80N, PRO80SC, PRO80SE, PRO80SR, PRO83Q, PRO83S, PRO86SE, PRO88Q, PRO89JT, PRO89VT, PRO8BC, PRO8BID, PRO8BIE, PRO8BIJ, PRO8BIL, PRO8BIN, PRO8BIP, PRO8DIJ, PRO8EJQ, PRO8EJV, PRO8FF, PRO8FJC, PRO8GBR, PRO8GBY, PRO8GE, PRO8GSA, PRO8GSD, PRO8GSJ, PRO8GSM, PRO8GSV, PRO8GTA, PRO8GTK, PRO8GU, PRO91SM, PRO91SV, Q301LA, Q301LP, R500, R500N, R500V, R500VD, R50A, R557LN, R557LP, R701VB, R704A, R704V, R704VB, R704VC, R704VD, R751J, R752LX, R752LX-T4063T, R900V, S82A, S86A, S97V, T11F, T11J, T11S, T12C, T12EG, T12ER, T12FG, T12JG, T12KG, T12MG, T12UG, T76J, T9A, TRSA10, TRSA20, U30JC, U30SD, U31F, U31JG, U31SD, U32JC, U32U, U33JC, U36JC, U36SD, U36SG, U3S, U3SG, U40SD, U41JF, U41SV, U42F, U42JC, U42SD, U43JC, U43SD, U44SG, U46E, U46SM, U46SV, U50A, U50F, U52F, U52JC, U53F, U53JC, U53SD, U56E, U6EP, U6S, U6SG, U6V, U6VC, U80A, UL30, UL30A, UL30AT, UL50VT-RBBBK05, UL50VT-X1, UX20, UX30S, UX31E, V1A, V1J, V1JP, V1S, V1SN, V1V, V2JE, V2S, V6J, V6JE, V6V, V6VA, VX1, VX2, VX2S, VX2SE, VX3, W1GA, W1GC, W1J, W1JA, W1JB, W1JC, W1N, W1NA, W1V, W2J, W2JB, W2JC, W2P, W2S, W2V, W2VC, W2W, W5A, W5F, W5FE, W5FM, W5V, W6A, W90V, W90VN, W90VP, X23A, X23FT, X24E, X33JC, X33SD, X34F, X34JC, X35F, X35JG, X35SD, X35SG, X36JC, X36SD, X36SG, X37U, X40U, X43BR, X43BY, X43E, X43SA, X43SD, X43SJ, X43SM, X43SV, X43TA, X43TK, X43U, X4GJF, X4GJM, X4GJQ, X4GSL, X4GSM, X4GSN, X4HJC, X4IJF, X4ISV, X4JE, X4JSJ, X4KSF, X4KSL, X4LE, X4LSM, X4LSV, X4MSG, X50, X50C, X50GI, X50GL, X50M, X50N, X50R, X50RL, X50SL, X50SR, X50V, X50VL, X50Z, X51, X51H, X51L, X51R, X51RL, X52, X52F, X52J, X52JR, X52N, X53, X53B, X53BR, X53BY, X53E, X53KA, X53KE, X53L, X53Q, X53S, X53SA, X53SC, X53SD, X53SE, X53SG, X53SJ, X53SK, X53SM, X53SR, X53SV, X53T, X53TA, X53TK, X53U, X53Z, X54, X54C, X54H, X55, X550C, X550DP, X555DG, X555QA, X555QG, X55SA, X55SR, X55SV, X56A, X56KR, X56SE, X56SN, X56TA, X56TR, X56VA, X56VR, X57SA, X57SR, X57SV, X57VC, X57VM, X57VN, X59GL, X59SL, X59SR, X5CQ, X61GX, X61Q, X61SF, X61SL, X61SV, X61Z, X62J, X62VP, X64DA, X64JA, X64JQ, X64JV, X64VG, X64VN, X66IC, X67F, X71A, X71Q, X71SL, X71SR, X71TL, X71TP, X71VN, X72DR, X72DY, X72F, X72JK, X72JR, X72JT, X72JU, X72SA, X72SR, X72TL, X72VM, X72VN, X72VR, X73, X73BR,

X73BY, X73E, X73S, X73SD, X73SI, X73SJ, X73SM, X73SV, X73TA, X73TK, X756UW, X75SV, X75V, X77JA, X77JQ, X77JV, X77VG, X77VN, X7ADR, X7ADY, X7AF, X7AJK, X7AJR, X7AJT, X7AJU, X7BJF, X7BJG, X7BJN, X7BJQ, X7BSM, X7BSV, X7CBR, X7CBY, X7CE, X7CSD, X7CSJ, X7CSM, X7CSV, X7CTA, X7CTK, X7DSF, X7DSL, X81L, X82CR, X82L, X82Q, X82S, X83VB, X83VM, X85SE, X87Q, X88SE, X88VD, X88VF, X8AAB, X8AAD, X8AAF, X8AC, X8AID, X8AIE, X8AIJ, X8AIL, X8AIN, X8AIP, X8BJT, X8BVT, X8DIJ, X8EJQ, X8EJV, X8FF, X8FJC, X90SC, X90SV, X93SM, X93SV, Z1000, Z1B, Z1F, Z2A, Z2B, Z30N, Z31N, Z33A, Z33N, Z35A, Z35F, Z35FM, Z35H, Z35HL, Z35L, Z37A, Z37E, Z37EP, Z37S, Z37SP, Z37V, Z52F, Z52HF, Z52J, Z52JE, Z53, Z53E, Z53F, Z53H, Z53JA, Z53JC, Z53JM, Z53JP, Z53JR, Z53JV, Z53L, Z53M, Z53P, Z53SC, Z53T, Z53TC, Z53U, Z6000, Z60NP, Z61A, Z61AE, Z62E, Z62EP, Z62F, Z62FM, Z62FP, Z62H, Z62HA, Z62J, Z62JM, Z6300, Z65E, Z7000N, Z70A, Z70N, Z70NE, Z70V, Z70VA, Z71A, Z71V, Z80D, Z80DC, Z80G, Z80H, Z80K, Z80L, Z80S, Z80T, Z81D, Z81G, Z81K, Z81KA, Z81L, Z81S, Z81SP, Z82N, Z83C, Z83D, Z83F, Z83J, Z83K, Z83M, Z83SV, Z83T, Z83U, Z83V, Z90R, Z91A, Z91AC, Z91E, Z91ER, Z91F, Z91FC, Z91FP, Z91FR, Z91G, Z91H, Z91HF, Z91L, Z91N, Z91V, Z91VC, Z94G, Z94L, Z94RP, Z96F, Z96FM, Z96H, Z96HM, Z96J, Z96JM, Z96JP, Z96JS, Z96S, Z96SP, Z97V, Z99DE, Z99E, Z99F, Z99FM, Z99H, Z99HE, Z99JA, Z99JC, Z99JE, Z99JM, Z99JN, Z99JR, Z99LE, Z99M, Z99N, Z99SC, Z99SE, Z99SG, Z99SR, Z99TC

Compaq Concerto

Compaq Contura: 400, AREO, NOTEBOOK

Compaq LTE: 5000, 5100, 5150, 5200, 5250, 5280, 5300, 5380, 5400

Compaq Presario: 2100, 2100Z, 2101AP, 2517EA, 2806AP1, 2807AP1, 2808AP1, 2810AP1, 2811AP1, 2812AP1, 2813AP1

Dell

Fujitsu Lifebook: AH521, AH531, AH532, E751, E8110, E8210, E8420, LH520, S7110,

Fujitsu Stylistic: ST6012

Fujitsu-Siemens Amilo: PA3553

Gericom: 5000

HP Business Notebook: NX9000, NX9005, NX9008, NX9010

HP Pavilion: ZE1000, ZE1110, ZE1115, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE4101, ZE4102, ZE4115, ZE4125, ZE4145, ZE4202ZE, ZE4206S, ZE4209, ZE4210, ZE4219, ZE4220, ZE4230, ZE4236, ZE4240, ZE4241, ZE4251, ZE4257EA, ZE4261, ZE4271, ZE4281, ZE4301, ZE4302, ZE4308EA, ZE4310AP, ZE4310EA, ZE4311AP, ZE4312AP, ZE4313, ZE4314AP, ZE4315AP, ZE4315CA, ZE4315US, ZE4316AP, ZE4317, ZE4317EA, ZE4318AP, ZE4318EA, ZE4318US, ZE4319, ZE4320EA, ZE4321, ZE4321EA, ZE4322EA, ZE4323EA, ZE4325CA, ZE4325EA, ZE4325US, ZE4328US, ZE4332EA,

ZE4333EA, ZE4334EA, ZE4335EA, ZE4335US, ZE4336EA, ZE4345US, ZE4347EA,
ZE4349EA, ZE4351EA, ZE4352EA, ZE4353EA, ZE4354EA, ZE4355US, ZE4356EA,
ZE4365US, ZE4367EA, ZE4384EA, ZE4386EA, ZE4400, ZE4401US, ZE4402US, ZE4403EA,
ZE4404EA, ZE4405EA, ZE4406EA, ZE4407EA, ZE4408EA, ZE4409EA, ZE4410AK,
ZE4410AP, ZE4410EA, ZE4411AP, ZE4412AP, ZE4413AP, ZE4414AP, ZE4414EA,
ZE4415AP, ZE4415EA, ZE4416AP, ZE4416EA, ZE4417EA, ZE4420CA, ZE4420US,
ZE4422EA, ZE4423EA, ZE4424EA, ZE4424US, ZE4425EA, ZE4427WM, ZE4428EA,
ZE4430US, ZE4453EA, ZE4454EA, ZE4455EA, ZE4500, ZE4501US, ZE4502US, ZE4504EA,
ZE4505EA, ZE4507EA, ZE4508EA, ZE4509EA, ZE4510AP, ZE4510EA, ZE4510OM,
ZE4511EA, ZE4512EA, ZE4513EA, ZE4514EA, ZE4516EA, ZE4518EA, ZE4519EA,
ZE4520AP, ZE4520EA, ZE4521AP, ZE4521EA, ZE4522AP, ZE4522EA, ZE4523AP,
ZE4523EA, ZE4524EA, ZE4525EA, ZE4525US, ZE4526EA, ZE4530US, ZE4540US,
ZE4545SR, ZE4545US, ZE4546SR, ZE4547WM, ZE4560US, ZE4600, ZE4601US,
ZE4603EA, ZE4604EA, ZE4605EA, ZE4610EA, ZE4610US, ZE4612EA, ZE4614EA,
ZE4615EA, ZE4630US, ZE4700, ZE4715EA, ZE4718EA, ZE4725EA, ZE4800, ZE4803US,
ZE4805US, ZE4805WM, ZE4810US, ZE4821EA, ZE4900, ZE4901, ZE4901US, ZE4902,
ZE4903US, ZE4904US, ZE4906US, ZE4907WM, ZE4908US, ZE4910US, ZE4911US,
ZE4919CL, ZE4920LA, ZE4930LA, ZE4930US, ZE4933US, ZE4935WM, ZE4941US,
ZE4942US, ZE4946CL, ZE4949US, ZE4955EA, ZE4995EA, ZE5000, ZE5155, ZE5160US,
ZE5165, ZE5170, ZE5185, ZE5200, ZE5236, ZE5240, ZE5250, ZE5270, ZE5300,
ZE5315EA, ZE5320AP, ZE5325EA, ZE5344EA, ZE5345US, ZE5354EA, ZE5360EA,
ZE5365US, ZE5375US, ZE5385CA, ZE5385US, ZE5395US, ZE5400, ZE5407LA, ZE5410AP,
ZE5413EA, ZE5414EA, ZE5415AP, ZE5415EA, ZE5416EA, ZE5418EA, ZE5420EA,
ZE5425EA, ZE5426EA, ZE5430EA, ZE5440EA, ZE5443EA, ZE5445EA, ZE5446EA,
ZE5451US, ZE5460EA, ZE5460US, ZE5462EA, ZE5467LA, ZE5468CL, ZE5470US,
ZE5475CA, ZE5477WM, ZE5478CL, ZE5490US, ZE5500, ZE5501US, ZE5504EA,
ZE5505EA, ZE5506EA, ZE5507EA, ZE5510AP, ZE5510EA, ZE5511AP, ZE5511EA,
ZE5512AP, ZE5512EA, ZE5513AP, ZE5514AP, ZE5515AP, ZE5515EA, ZE5516AP,
ZE5516EA, ZE5517AP, ZE5517EA, ZE5518AP, ZE5519AP, ZE5519EA, ZE5520AP,
ZE5520EA, ZE5521AP, ZE5522AP, ZE5523AP, ZE5523EA, ZE5524AP, ZE5524EA,
ZE5525AP, ZE5525EA, ZE5526AP, ZE5526EA, ZE5527EA, ZE5528EA, ZE5529EA,
ZE5530EA, ZE5531EA, ZE5532EA, ZE5533EA, ZE5534EA, ZE5535EA, ZE5547WM,
ZE5560US, ZE5565QV, ZE5568CL, ZE5570US, ZE5575SR, ZE5580US, ZE5600 C,
ZE5601AP, ZE5601EA, ZE5602AP, ZE5602EA, ZE5602US, ZE5603AP, ZE5603EA,
ZE5603US, ZE5604AP, ZE5604EA, ZE5604RS, ZE5605AP, ZE5605EA, ZE5605SR,
ZE5606AP, ZE5607AP, ZE5607EA, ZE5607WM, ZE5608AP, ZE5609AP, ZE5609EA,
ZE5610AP, ZE5610EA, ZE5611AP, ZE5611EA, ZE5612AP, ZE5612EA, ZE5613AP,
ZE5613EA, ZE5614AP, ZE5614EA, ZE5615AP, ZE5615CA, ZE5615EA, ZE5615SR,
ZE5616AP, ZE5616EA, ZE5617AP, ZE5617EA, ZE5617WM, ZE5618AP, ZE5618EA,
ZE5619AP, ZE5619EA, ZE5620AP, ZE5620EA, ZE5620US, ZE5621AP, ZE5622EA,
ZE5623EA, ZE5624EA, ZE5626EA, ZE5630US, ZE5631EA, ZE5635EA, ZE5636EA,

ZE5638EA, ZE5639EA, ZE5640EA, ZE5644EA, ZE5645EA, ZE5657LA, ZE5700, ZE5700 N, ZE5700EA, ZE5701US, ZE5706EA, ZE5715CA, ZE5715EA, ZE5730US, ZE5731US, ZE5732QV, ZE5738RS, ZE5739CL, ZE5749CL, ZE5800

Lenovo: B550, G430, G450, G450A, G555A, G575, G770,

Lenovo: 3000, G230, G230-4107, G230G, G400, G410, G430, G430-2000, G430-4152, G430-4153, G430A, G430L, G430M, G450, G500, G510, G510-4056, G510-4059, G530, G530-4446-23U, G530-4446-25U, G530-4446-38U, G550, N500, N500-4233, Y300, Y510A-15303

Lenovo Essential: G770-10372UU

Lenovo IdeaPad: G430, G450, G450-20022, G460, G460-20041, G460AP, G460AX, G465, G560, G565, G580, U330-2267-3AU, U330-2267-58U, U330-2267-64U, U330-2267-65U, U350, U350-2963-23U, U400, U450P, U450P-3389-2HU, U450P-3389-32U, U450P-3389-33U, U460, U460S, U550, U550-3749, U550-3749-55U, U550-3749-59U, U550-3749-5EU, U550-3759-54U, V360, V370, V430A, V450A, V460, V470, V475, V560, V570, Y450-418935U, Y450-418936U, Y450-418938U, Y450-418939U, Y480, Y480P, Y530-4051-2AU, Y530-4051-2BU, Y530-4051-2NU, Y530-4051-2PU, Y530-4051-2XU, Y530-4051-2YU, Y530-4051-64U, Y530-4051-65U, Y530-4051-66U, Y550, Y550 4186, Y550-418646U, Y550A, Y550P, Y650, Z380, Z380AX, Z380AY, Z460, Z460A, Z465, Z470, Z485, Z560, Z565-431135U, Z570

Maxdata Imperio: 4000, 4500, 4500A, 8100IS, I 4000A

Medion: MD40200, MD5400, MD96987, RAM2000

Medion Akoya: P6620, P6622, P6638, P6648, P6653, P6655, P7816, P7817, P7818

Medion Erazer: P6661

MSI: A6400, CX480 (BATERIA 9 OGNIWOWA), CX61 2OC, CX61 2OD, CX61 2PF, CX61 2QC, CX61 2QF, CX620 3D, CX640, CX640DX, CX640MX, CX70 0NF, CX70 20C, CX70 2OC, CX70 2OD, CX705MX, EX300, FR700, FX420 (BATERIA 9 OGNIWOWA), FX600, FX603, FX610, FX620DX, FX620DX (PROCESORY I3 ORAZ I5), FX700, FX720, GE40 2OL, GE40 2PC, GE600, GE600X, GE603, GE620 (PROCESOR I5), GE700, GT628, GX623, MS-1758, PR600X, PR620, PX200, X460DX,

Packard Bell EasyNote: BG35, BG48, DT85, LM81, LM82, LM83, LM85, LM86, LM87, LM94, LM98, MH36, MH45, ML65, MT65, MX52, NM86, NM87, NM98, NS11HR, NS44HR, NS45, NX69HR, NX86, RS65, RS66, SL35, SL45, SL51, SL65, SL81, ST85, ST86, SX62HR, SX66HR, TJ75, TJ76, TJ77, TJ78, TK13BZ, TM 98, TM85, TM86, TM87, TM89, TM93, TM94, TM97, TM98, TM99, TN36, TN65, TS11HR, TS11SB, TS13HR, TS13SB, TS44HR, TS44SB, TS45HR, TS45SB, TX62HR, TX69HR, TX86,

Toshiba Satellite: A200, A300-14S, A300-1EB, A300-1ED, A300-1EH, A300-234, A350-13A, A500-ST5607, A500-ST5608, A500-ST56EX, A500-ST56X3, A500-ST56X4, A500-ST56X6, A500-ST56X7, A505-S6004, A505-S6005, A505-S6007, A505-S6009, A505-S6012, A505-S6014, A505-S6015, A505-S6016, A505-S6017, A505-S6020, A505-S6025, A505-S6030, A505-S6031, A505-S6033, A505-S6034, A505-S6035, A505-S6040, A505-S6980, A505-S69803, A505-S6981, A505-S6982, A505-S6983, A505-S6984, A505-S6985, A505-S6986, A505-S6989, A505-S6990, A505-S6991, A505-S6992, A505-S6993, A505-S6995, A505-S6996, A505-S6997, A505-S6998, A505-S6999, A505D-S6008, A505D-S6987, A660-121, A660-14T, A660-186, A660-ST2GX1, A660-ST2N01, A660-ST2N02, A660-ST2NX2, A660-ST3N01X, A660-ST3NX1, A660-ST3NX2X, A660-ST5N01, A660D-ST2G01, A660D-ST2NX2, A665-3DV, A665-3DV1, A665-3DV10X, A665-3DV11X, A665-3DV12X, A665-3DV5, A665-3DV6, A665-3DV7, A665-3DV8, A665-S5170, A665-S5171, A665-S5173, A665-S5176X, A665-S5177X, A665-S5179, A665-S5180, A665-S5181, A665-S5182X, A665-S5183X, A665-S5184X, A665-S5185, A665-S5186, A665-S5187X, A665-S5199X, A665-S6050, A665-S6054, A665-S6055, A665-S6056, A665-S6057, A665-S6058, A665-S6065, A665-S6067, A665-S6070, A665-S6079, A665-S6080, A665-S6081, A665-S6085, A665-S6086, A665-S6087, A665-S6088, A665-S6089, A665-S6090, A665-S6092, A665-S6093, A665-S6094, A665-S6095, A665-S6097, A665-S6098, A665-S6100X, C660-1NH, C660-1P8, C660-1RC, C660-1XT, C70-A-17R, L300-11F, L300-2C3, L300-2C5, L305D, L350, L350D, L50-A, L500, L500-1EF, L500-1GF, L550, L550-149, L755, L850-1HL, L850-1N3, M645-S4045, M645-S4047, M645-S4048, M645-S4049, M645-S4050, M645-S4055, M645-S4061, M645-S4062, M645-S4063, M645-S4065, M645-S4070, M645-S4080, M645-S4110, M645-S4112, M645-S4114, M645-S4115, M645-S4116X, M645-S4118X, P200-1EV, P300-135, P75-A7200, P750-10E, P750-ST4N01, P750-ST4N02, P750-ST4NX1, P750-ST4NX2, P750-ST5GX1, P750-ST5GX2, P750-ST5N01, P750-ST5N02, P755-S5375, P770-ST4N01, P770-ST4NX1, P770-ST4NX2, P770-ST5GX1, P770-ST5GX2, P770-ST5N01, P775-S7215, P775-S7232, P775-S7234, P775-S7236, P775-S7238, P775-S7320, P775-S7365, P775-S7368, P775-S7370, P775-S7372, P775-S7375, P775D-S7230, P775D-S7302, P775D-S7360,

Toshiba Satellite Pro: C50-A-1KV, L500, L505,