

MPC (MicronPC) TransPort: GX, GX+, GX2, GX3, LT, VX, XT, XT2, ZX,

Samsung: 270E5E, 270E5V, 275E, 275E5E, 275E5V, 300E, 300E5A, 300E5C, 300E5V, 300E5Z, 300E7A, 300U, 305E, 305E5A, 305E7A, 310E, 350U, 370R, 370R5E, 510R5E, 530U, 535U, A10, A10DX, A10XTC, E172, E251, E272, E352, E452, E5510, E5520, E852, GS6000, GT9000 PRO, M40, M40 PLUS, NP-Q30, NP-Q30 PLUS, NP-Q330, NP-Q35, NP-Q35 XIC 5500, NP-Q35 XIH 2300, NP-Q35 XIP 2300, NP-Q430, NP-Q530, NP-Q530-JS01PL, NP-Q530-JT01PL, NP-Q70, NP-Q70 XEV 7100, NP-QX310, NP-R39 PLUS, NP-R40, NP-R517, NP-R519, NP-R719, NP-RV508, NP-RV510, NP-RV510-A01PL, NP-RV510-A02PL, NP-RV510-A03PL, NP-RV510-S01PL, NP-RV510-S02PL, NP-X118, NP-X120, NP-X420, NP-X520, NP20, NP25, NP270E4E, NP270E5E, NP270E5E-K01, NP270E5E-K01PL, NP270E5E-K02PL, NP270E5E-K05PL, NP270E5E-K06PL, NP270E5E-K07PL, NP270E5E-X01PL, NP270E5E-X02PL, NP270E5E-X04PL, NP270E5G, NP270E5V, NP270E5V-X01PL, NP275E5E, NP275E5E-K01DE, NP275E5E-K01PL, NP275E5V, NP28, NP30, NP300, NP300E4A, NP300E4C, NP300E5A, NP300E5A-A01PL, NP300E5A-A03PL, NP300E5A-A04PL, NP300E5A-A06PL, NP300E5A-A07PL, NP300E5A-A09PL, NP300E5A-S02PL, NP300E5A-S03PL, NP300E5A-S04PL, NP300E5A-S05PL, NP300E5A-S06PL, NP300E5A-S07PL, NP300E5A-S08PL, NP300E5A-S09PL, NP300E5A-S0CPL, NP300E5A-S0DPL, NP300E5AI, NP300E5C, NP300E5C-A01, NP300E5C-A01PL, NP300E5C-A02PL, NP300E5C-A03PL, NP300E5C-A04PL, NP300E5C-A07, NP300E5C-S01PL, NP300E5C-S02PL, NP300E5C-S03PL, NP300E5C-S04PL, NP300E5C-S05PL, NP300E5C-U01PL, NP300E5E, NP300E5V, NP300E5X, NP300E5Z, NP300E7A, NP300E7A-A01PL, NP300E7A-S01PL, NP300E7A-S02PL, NP300E7A-S03PL, NP300E7A-S04PL, NP300E7A-S06PL, NP300E7A-S07PL, NP300E7A-S08PL, NP300E7A-S09PL, NP300E7Z, NP300U1A, NP305E5A, NP305E5A-S03PL, NP305E5A-S04PL, NP305E7A, NP305E7A-S03PL, NP310E5C, NP310E5C-A01, NP310E5C-A01PL, NP310E5C-U01PL, NP310E5C-U02PL, NP35, NP350U2A, NP350U2B, NP3530EA, NP3530EC, NP370R5E, NP370R5E-S02PL, NP370R5E-S03PL, NP370R5E-S04PL, NP370R5E-S05PL, NP370R5E-S06PL, NP400, NP510R5E, NP530U4B, NP530U4C, NP535U4C, NT-X170, NX05, P200, P27, P28, P28G, P29, P30, P35, P40, P400, P45, P50, P50 PRO, Q1, Q1 ULTRA PRO, Q1B PRO, Q30, Q30 PLUS, Q318, Q320, Q330, Q35, Q35 AURA, Q35 PRO, Q35 PRO T5500 BITASA, Q35 XIC 5500, Q35 XIH 2300, Q35 XIP 2300, Q35-T2300 CADERU, Q35-T2300 COTEZAA, Q40, Q40 AURA, Q430, Q45, Q45 AURA, Q530, Q70, Q70 AURA, QX310, R20, R20 AURA, R25, R39, R40, R40 AURA, R40 PLUS, R41, R45, R50, R509, R517, R519, R530, R540, R718, R719, RV408, RV410, RV508, RV509, RV510, RV511, S300, S310, S3510, S3511, S3520, SA21, SF310, SF311, SF410, SF510, SF511, T10, X05, X06, X1, X10, X10PLUS, X11, X11C, X11PRO, X120, X125, X15, X15PLUS, X30, X320, X360, X418, X420, X430, X520, XT,

Samsung ArmnoteOLD: CY23, CY25, CY27,

Samsung GT: GT6000, GT6330, GT6330XT, GT6360, GT6360XT, GT6390XT, GT6400, GT6400XV, GT7000, GT7700, GT8000, GT8100, GT8600, GT8600XT, GT8650, GT8650XT,

GT8700XT, GT8750, GT8750XT, GT8800, GT8800XT, GT8800XV, GT8850, GT8850XT, GT8850XTD, GT8900, GT8900DXV, GT8900XTR, GT8910, GT8910KXV, GT9000, GT9000 PRO,

Samsung MetroBook: LT, VL,

Samsung NP: NP-Q35, NP-R719-JS05DE, NP-R719-XA01PL, NP-RV510-A02CZ, NP-RV510-A02PL, NP-RV510-A03PL, NP-RV510-A04FR, NP-RV510-A04TR, NP-RV510-A08, NP-RV510-A0L, NP-RV510-A0NUK, NP-RV510-S01PL, NP-SF410-S01, NP-X1, NP-X1-1200, NP-X1-C003/SHK, NP-X11, NP-X120-JA01BE, NP-X120-JA04, NP270E5E, NP275E5E-K01AT, NP300E5C, NP300E5E-A02BG, NP300E7A, NP370R5E-S04RU, NT-X1-C110, NT-X1-C120,

Samsung NT: NT-Q330E-PS3,

Samsung R: R510, R519, R522, R530, R540, R580, R719,

Samsung Sens: 630, 690, 820, 830, 900, 950, PRO 680, PRO 850,

Samsung SPA: SPA-690E/E, SPA-690E/UK, SPA-830E/EUR, SPA-830E/UK, SPA-A10E/E, SPA-A10E/UK, SPA-P30, SPA-P30E, SPA-P30E/E, SPA-P30E/UK, SPA-T10/UK, SPA-T10E/EUR, SPA-V20E/E, SPA-V20E/UK, SPA-X10, SPA-X10/E, SPA-X10/UK,

Samsung VM: VM6000, VM6300, VM6300CT, VM7000, VM7550, VM7550CT, VM7600, VM7600CT, VM7650, VM7650CT, VM7650CXTD, VM7700, VM7700XTD, VM8000, VM8080, VM8080CXT, VM8090, VM8090CT, VM8090CXTD, VM8095, VM8095CX, VM8100, VM8100CX, VM8100CXTD, VM8100XTD, VM8110CXTD, VM8110XTC,