

Asus: A512DA, D553M, F201E, F509F, F509FA, F509FA-EJ207T, F540S, F543U, F543UA, F543UA-DM1876T, F543UA-DM1882T, F553M, M409BA, M409DA, M409DJ, M409DL, M509DA, R540, R540S, R541UJ-DM448, S532F, S532FAC, S532FAC-BN094T, X200, X200CA, X200M, X201, X201E, X302LJ, X302UA, X302UJ, X302UV, X407MA, X407UA, X407UB, X407UF, X409FA, X409UA, X441BA, X441MB, X441SC, X441UA, X441UB, X441UV, X456UA, X507LA, X507UA, X509FA, X540BA, X540LA, X540LJ, X540MB, X540NV, X540SA, X540SC, X540UB, X540YA, X541SC, X541UA, X543B, X543BA, X543BP, X543MB, X543U, X543UA, X543UB, X545FA, X553M, X556UA

Asus TaiChi: 21, 31,

Asus Vivobook: 15 F510U, 15 F512UA, 15 F512UA-EJ233T, 15 F512UA-EJ268T, 15 X542UA, A541U, F200, F200CA, F201E, K401L, K401LB, Q200, Q200E, Q301, Q301L, Q301LA, R542U, S13, S13 S330UA, S13 S330UA-EY27T, S14 S410UA, S200, S200E, X201, X201E, X202, X202E, X302LA, X405, X405U, X405UA, X540YA,

Asus VivoBook 14: X411QA, X412FA, X412UA,

Asus VivoBook 15: X505ZA, X509UA, X510UA, X512FA, X512UA, X542UA,

Asus VivoBook 17: X712FA,

Asus VivoBook Flip: TP301UA, TP501U, TP501UA,

Asus VivoBook Flip 14: TP412UA,

Asus VivoBook Max: X441NC, X441UV, X541UA,

Asus VivoBook S13: S330FA-EY024T, S330UA,

Asus VivoBook S14: S406UA, S410UA, S430F, S430FA, S430FA-EB047T, S430FN, S430UA, S430UN, S432FA, X420UA,

Asus VivoBook S15: S510UA, S532FA,

Asus Zenbook: BX21, BX21A, BX31A, BX32, BX32A, U38DT, U38N, UK31K, UX21, UX21A, UX301, UX301LA, UX302L, UX302LA, UX302LG, UX302LG-C4019H, UX302LG-C4019P, UX303LA, UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX305, UX305C, UX305CA, UX305F, UX305FA, UX305L, UX305LA, UX305U, UX305UA, UX305UB, UX306, UX306U, UX306UA, UX306UA-VB72, UX31, UX310UA, UX310UQ, UX31A, UX31A-1AR4, UX31A-1AR5, UX31A-1AR7, UX31A-2D, UX31A-AB71, UX31A-AB72, UX31A-BHI5T11, UX31A-DB51, UX31A-DB52, UX31E, UX31K, UX31L, UX31LA, UX32A, UX32L, UX32LA, UX32LN, UX32V, UX32VD, UX330CA, UX330UA, UX331FN, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX410UA, UX42A, UX42V, UX42VS, UX430U, UX430UA, UX430UQ, UX50, UX510UW, UX510UX, UX52VS, UX560UA, X331UA, X331UN,

Asus ZenBook 13: UX331UA, UX331UAL,

Asus Zenbook Prime: UX32V, UX32VD, UX42V, UX42VS, UX52VS,