

Acer HIPRO HP-A0652R3B

Acer Aspire: 112WSMI, 1200, 1200X, 1200XV, 1202, 1202X, 1203X, 1203XC, 1203XV, 1360, 1410, 1410 (11,6"), 1410 (15,4"), 1411, 1411WLMi, 1412, 1412LC, 1412LCI, 1412LM, 1412LMI, 1412WLMi, 1413, 1413LC, 1413LM, 1413LMI, 1413WLMi, 1414, 1414LC, 1414LM, 1414LMI, 1414WLMi, 1415, 1415LMI, 1430Z, 1430Z-4677, 1551, 1551-32B2G32N, 1551-32B2G32NCC, 1551-32B2G32NKi, 1551-32B2G32NRR, 1551-32B2G32NSS, 1551-32B2G50NSS, 1551-32B4G50NKi, 1551-4650, 1551-4755, 1551-5448, 1551-K62B4G32N, 1551-K62B4G32NKi, 1640, 1640Z, 1642Z, 1650, 1650Z, 1652, 1654, 1680, 1680WLCI, 1680WLMi, 1681, 1681LC, 1681LCI, 1681LMI, 1681WLC, 1681WLCI, 1681WLM, 1681WLMi, 1682, 1682LCI, 1682LMI, 1682WLC, 1682WLM, 1682WLMi, 1683, 1683LMI, 1683WLM, 1683WLMi, 1684, 1684WLMi, 1685, 1685WLCI, 1685WLMi, 1689, 1689WLMi, 1690, 1690LCI, 1690LMI, 1690WLCI, 1690WLMi, 1691, 1691LCI, 1691LMI, 1691WLCI, 1691WLM, 1691WLMi, 1692, 1692LMI, 1692WLCI, 1692WLMi, 1693, 1693WLCI, 1693WLM, 1693WLMi, 1694, 1694LMI, 1694WLCI, 1694WLMi, 1695, 1695WLMi, 1696, 1830, 1830T-4549, 1830TZ, 1830Z, 1830Z-000, 1830Z-A52C/K, 1830Z-A52C/S, 1830Z-U514G50N, 2000, 2000LCI, 2000LMI, 2000WLCI, 2000WLMi, 2001, 2001LC, 2001LCE, 2001LCI, 2001LMI, 2001WLCI, 2001WLMi, 2002, 2002LCI, 2002LMI, 2002WLCI, 2002WLMi, 2003, 2003LC, 2003LCI, 2003LM, 2003LMI, 2003WLCI, 2003WLMi, 2010, 2010LMI, 2010WLCI, 2010WLMi, 2012, 2012LC, 2012LCI, 2012WLCI, 2012WLMi, 2013, 2013WLMi, 2014, 2014WLMi, 2016, 2016WLMi, 2020, 2020LC, 2020WLCI, 2021, 2021WLMi, 2024, 2024WLC, 2024WLMi, 2025, 2025LMI, 2025WLMi, 2026, 2026LMI, 2026WLMi, 2420, 2430, 2920, 2920Z, 2930, 2930Z, 3000, 3000LC, 3000LCI, 3000LM, 3000LMI, 3000WLMi, 3001LC, 3001WLCI, 3001WLMi, 3002LC, 3002LCI, 3002LMI, 3002NLC, 3002NLCI, 3002NWLCI, 3002WLCI, 3002WLMi, 3003LC, 3003LCI, 3003LMI, 3003WLCI, 3003WLMi, 3004LMI, 3004WLMi, 3005LCI, 3005WLCI, 3005WLMi, 3021WLMi, 3023WLMi, 3030, 3040, 3050, 3100, 3410, 3410Z, 3500, 3502LC, 3502LCI, 3502LMI, 3502NLCI, 3502WLC, 3502WLCI, 3502WLMi, 3503NWLM, 3503WLCI, 3503WLMi, 3505LMI, 3505WLMi, 3508WLMi, 3509WLMi, 3510, 3600, 3602NWXM, 3603NWXC, 3603NWXM, 3603NWXM, 3603WLCI, 3603WXCI, 3603WXMI, 3603XCI, 3608NWXC, 3608WXCI, 3608WXMI, 3610, 3610WLM, 3612LC, 3612LCI, 3613LC, 3613LCI, 3613NWLCI, 3613WLCI, 3613WLMi, 3614WLMi, 3620, 3620A, 3630, 3650, 3651, 3651WLCI, 3651WLMi, 3660, 3660-2728, 3670, 3680, 3680-2626, 3680-2633, 3681, 3682, 3690, 3690-2119, 3690-2359, 3690-2363, 3690-2436, 3690-2468, 3692WLMi, 3693WLMi, 3750, 3750G, 3750ZG, 3810T, 3810T-8097, 3810TG, 3810TZ, 3810TZG, 3811TG, 3811TZ, 3811TZG, 3820, 3820G, 3820T, 3820TG-374G32N, 3820TG-374G50NKS, 3820TZG, 3820ZG, 3830, 3830T, 3935, 4152LC, 4152LM, 4153, 4220, 4220G3690-2087, 4230, 4232, 4250, 4251, 4252, 4253, 4310, 4315, 4320, 4330, 4332, 4333, 4336, 4339, 4349, 4350, 4352, 4410, 4520, 4530, 4535, 4540, 4551, 4551G, 4552, 4552G, 4553, 4560, 4625, 4625G, 4710, 4710Z, 4715Z, 4720, 4720Z, 4720ZG, 4730, 4730Z, 4730ZG, 4730ZG-424G25, 4732Z, 4733Z, 4735Z, 4735ZG, 4736, 4736G,

4736Z, 4736ZG, 4738, 4738G, 4738Z, 4738ZG, 4739, 4739Z, 4740, 4740G, 4741, 4743, 4743Z, 4743ZG, 4745, 4745G, 4745G-5452G50MNKS, 4745Z, 4749, 4749Z, 4750Z, 4752, 4752G, 4752G-2332G50MNKK, 4752G-2352G50, 4752G-2432G, 4752G-2432G75MNKK, 4752Z, 4810T, 4810TG, 4810TZ, 4810TZG, 4820, 4820TG, 4820TZG, 4920, 4930, 4935, 5000, 5000WLM, 5001LCI, 5001LM, 5001LMI, 5001WLCI, 5001WLM, 5002LC, 5002LCI, 5002LM, 5002LMI, 5002NWLM, 5002WLCI, 5002WLM, 5002WLM, 5003WLCI, 5003WLM, 5004WLCI, 5004WLM, 5005WLM, 5010, 5020, 5021LMI, 5030, 5040, 5050, 5100, 5102WLM, 5110, 5112WLM, 5220, 5230, 5235, 5250, 5250-BZ436, 5251, 5251-1762, 5252, 5252-V333, 5253, 5253G, 5310, 5315, 5315-050512, 5315-2270, 5315-2698, 5315G, 5320, 5330, 5332, 5333, 5334, 5335, 5336, 5336-2283, 5336-2524, 5338, 5342, 5349-B814G50MI, 5350, 5410, 5500, 5500Z, 5501WXC, 5501WXM, 5502WLM, 5502WXC, 5502WXM, 5503WLM, 5503WXC, 5503WXM, 5504, 5504WXM, 5510, 5512WLM, 5513EWLM, 5513EWLM, 5513WLM, 5514WLM, 5515, 5516, 5517, 5520, 5520-5281, 5520-5313, 5520-5678, 5520-5716, 5520-5929, 5520-7416, 5520G, 5520H, 5530, 5532, 5532-202G25MN, 5532-203G25MN, 5532-204G50MN, 5532-312G25MI, 5532-314, 5532-314G25MI, 5532-314G32MN, 5532-314G50MN, 5532-314G64MN, 5532-423G32MN, 5532-5509, 5532-5534, 5532-5535, 5532-5535WIN, 5532-6C3G32MN, 5532Z, 5534, 5535, 5536, 5538, 5541, 5541G, 5542, 5542G, 5550, 5551, 5551G, 5552, 5552G, 5553, 5553G, 5560, 5560G, 5570, 5600, 5610, 5620, 5625, 5625G, 5630, 5710, 5710Z, 5715Z, 5720, 5720G, 5720Z, 5720ZG, 5730, 5730G, 5730Z, 5730ZG, 5732, 5732Z, 5732Z-4867, 5732ZG, 5733, 5734Z, 5735, 5735Z, 5736, 5736G, 5736Z, 5736Z-4460, 5737, 5737Z, 5738, 5738DG, 5738DZG, 5738G, 5738PG, 5738PZG, 5738Z, 5738ZG, 5739, 5739G, 5740, 5740-333G25, 5740-513, 5740-5144, 5740-5255, 5740-5513, 5740-5749, 5740-5780, 5740-5847, 5740-6025, 5740-6378, 5740-6491, 5740-XX, 5740D, 5740DG, 5740DG-334G64MN, 5740G, 5740G-333G32MN, 5740G-334G32MI, 5740G-334G32MN, 5740G-334G50MN, 5740G-434G64MN, 5740G-624G32BN, 5740G-624G50MN, 5740G-624G64BN, 5740G-624G64MN, 5741, 5741G, 5741Z, 5742, 5742-7458, 5742-7765, 5742G, 5742Z, 5742ZG, 5745, 5745P, 5745Z, 5749, 5750, 5750G, 5750ZG, 5755, 5755G, 5810T, 5810TG, 5820G, 5820T, 5820TG, 5820TZ, 5820TZG, 5830T, 5830TG, 5912, 5920, 5920-6574, 5920G, 5930, 5935G, 5940G, 5950G, 6530, 6920, 6930, 6935, 7100, 7104WSMI, 7110, 7111WSMI, 7230, 7250, 7250-0416, 7250-3821, 7250G, 7315, 7315-313G25, 7330, 7339, 738ZG, 741ZG, 745Z, 7530, 7530-623G25MN, 7530G, 7535, 7540, 7551, 7560, 7715Z, 7730, 7730Z, 7735, 7735Z, 7736, 7736G, 7736G-888G64BN, 7736Z, 7736ZG, 7736ZG-664G32MN, 7740, 7740G, 7741, 7741-333G25BN, 7741-353G25MNSK, 7741G, 7741G-5464G50MNKK, 7741Z, 7745, 7745G-5454G50MNKS, 7745Z, 8372T-353G32MNBB, 8372T-354G32MNBB, 8372T-354G32N, 8372T-373G32MNKK, 8372T-454G32N, 8372T-5454G16MNBB, 8372T-5454G16N, 8372T-5454G32MNBB, 8372T-5454G32N, 8372T-5454G34N, 8372TG-354G32MNBB, 8540, 8735, 9100, 9100WLM, 9101, 9101WLM, 9102WLC, 9102WLCI, 9102WLM, 9103, 9103WLM, 9104, 9104LM, 9104LMI, 9104WLM, 9104WLM, 9104WSM, 9105, 9105WLM, 9110, 9112WLM, 9114WLM, 9120, 9300, 9400, 9404WSMI, 9420, 9420-

6074, 9420-6775, 9422WSMI, 9423WSM, 9424AWSMI, 9500, 9500WSMI, 9502WLMI, 9502WSMI, 9503WLMI, 9510, 9800, 9810, AS1551-32B2G50NSS, AS1551P, AS5250, AS5517-1127, AS5517-1208, AS5517-1216, AS5517-1515, AS5517-1643, AS5517-5078, AS5517-5086, AS5517-5136, AS5517-5358, AS5517-5535, AS5517-5661, AS5517-5671, AS5517-5689, AS5517-5700, AS5517-5997, AS5532-203G25MN, AS5532-314G25MI, AS5532-314G50MN, AS5532-423G32MN, AS5532-5509, AS5532-5534, AS5532-5535, AS5532-6C3G32MN, AS5738G, AS5738G-6335, AS5740D, AS5740DG, AS5740G, AS5740G-5309, AS5740G-6395, AS5741, AS5741G, AS5742, AS5742-373G50, AS5742-7645, AS5742G, AS5742Z, AS5742Z-4200, AS5742Z-4512, AS5742Z-4601, AS5742Z-4621, AS5742Z-4685, AS5742Z-P613G32MNRR, AS5742ZG, AS5820T-5452, AS5820T-5900, AS5820T-6178, AS5820T-7683, AS7736G, AS7736ZG, AS7741-333G25MN, AS7741G-333G25BN, AS7741G-333G32MN, AS7741G-7017, AS7745G, AS8571-352G25MN, AS8571-352G25N, AS8571-353G25MN, AS8571-942G16MN, AS8571-943G25MN, AS8571-943G25N, E1-371G, E1-421, E1-430P, E1-430P-21174G50MNNK, E1-510, E1-521, E1-522, E1-530, E1-531-B964G50MNNKS, E1-531G-B9604G50MNNK, E1-570, E1-571, E1-571-33114G50MNNKS, E1-571-6442, E1-571-6490, E1-572G, E1-V5WE2, E15, E5-422G-45ET, E5-473G-39LZ, E5-473G-39MF, E5-473G-50HZ, E5-473G-57M4, E5-473G-57QQ, E5-473G-58W3, E5-473G-59QT, E5-473G-59U6, E5-473G-72FC, E5-473G-72FC/T014, E5-473G-72ZT, E5-473G-77PC, E5-473G-785H, E5-473T, E5-473TG, E5-511, E5-522G, E5-522G-60EP, E5-522G-671W, E5-522G-895M, E5-532G, E5-532G-P9YD, E5-551, E5-551-T5E7, E5-551G, E5-571, E5-571G, E5-571PG, E5-573G, E5-573G-31Q2, E5-573G-59CS, E5-722G, E5-722G-83DD, E5-722G-86B3, E5-722G-86K1, E5-731G, ES1-511, ES1-511-C35L, ES1-523, ES1-711G-P0RD, ES1-731G, ES17, F5-573, F5-573G, M3-581T, M3-581TG, M5-481, M5-581G, MS2264, MS2376, ONE 721, Q5WPH, Q5WT6, S3-951, V3-531G, V3-532, V3-532G, V3-551, V3-551G, V3-572PG, V3-574-516H, V3-574-58TS, V3-574-72HY, V3-574G, V3-574G-58ZE, V3-574G-755M, V5-121, V5-122P, V5-123, V5-131, V5-431P, V5-471G, V5-471P, V5-471PG, V5-472, V5-473, V5-473-35568G1TALL, V5-473-54204G50AII, V5-473-54204G50APP, V5-473-54206G1TALL, V5-473-6655, V5-473-6846, V5-473-I54204G50AMM, V5-473G-54204G50AII, V5-473G-6814, V5-531, V5-531G, V5-531P, V5-551G, V5-552, V5-571, V5-571-6868, V5-571G, V5-571P, V5-571PG, V5-573P, V5WE2, V7-481P, V7-482P, V7-581, V7-582P, VN7-572TG,

Acer Aspire 1: A111-31-C16R, A111-31-C191, A111-31-C1GR, A111-31-C390, A111-31-C3M0, A111-31-C42X, A111-31-C4G3, A111-31-C4T0, A111-31-C522, A111-31-C5HH, A111-31-C6H0, A111-31-C6RT, A111-31-C7DP, A111-31-C82K, A111-31-C85U, A111-31-C8TB, A111-31-C8X3, A111-31-C978, A111-31-P2J1, A114-31, A114-31-C05G, A114-31-C0HR, A114-31-C0N7, A114-31-C1HU, A114-31-C26A, A114-31-C2ZU, A114-31-C3B7, A114-31-C3E6, A114-31-C44C, A114-31-C472, A114-31-C4HH, A114-31-C4ZV, A114-31-C5UB, A114-31-C5Z2, A114-31-C6FA, A114-31-C76W, A114-32-C3N0, A114-32-C423, A114-32-C4HP, A114-32-C4P3, A114-32-C4WK, A114-32-C57A, A114-32-C5VW, A114-32-C641, A114-32-C6U9, A114-32-C75D, A114-32-C79Z, A114-32-C7BX, A114-

32-C8N6, A114-32-C8W6, A114-32-C97N, A114-32-C9MJ, A114-32-C9VN, A114-32-P0K1, A114-32-P2A4, A114-32-P34S, A114-32-P7E5, A114-32-P84R,

Acer Aspire 3: A311-31, A311-31-C09G, A311-31-C1VB, A311-31-C23K, A311-31-C26C, A311-31-C2WP, A311-31-C64M, A311-31-C9S8, A311-31-C9TW, A311-31-P4JH, A311-31-P7Q9, A314-31, A314-31-C0SG, A314-31-C0T4, A314-31-C1ZV, A314-31-C4MU, A314-31-C4Z5, A314-31-C7BP, A314-31-C7CY, A314-31-C7XK, A314-31-P8VG, A314-31-P9B4, A314-31-P9KD, A314-32, A314-32-C00A, A314-32-C0HQ, A314-32-C65H, A314-32-C83Q, A314-32-C9E0, A314-32-C9MC, A314-32-P02S, A314-32-P2QG, A314-32-P4AS, A314-32-P79Y, A314-32-P8ZN, A314-32-P9A0, A315-21, A315-21-40VS, A315-21-435D, A315-21-43TK, A315-21-44QB, A315-21-49UK, A315-21-603C, A315-21-6237, A315-21-93YN, A315-21-956Y, A315-21-968G, A315-21-96RH, A315-21-97JA, A315-21-99E5, A315-21G, A315-21G-41DY, A315-21G-42EZ, A315-21G-44FZ, A315-21G-472E, A315-21G-67SY, A315-21G-69WG, A315-21G-914U, A315-21G-92GM, A315-21G-96HU, A315-21G-96T2, A315-21G-973W, A315-31-C33J, A315-31-C343, A315-31-C389, A315-31-C3CC, A315-31-C3PK, A315-31-C3T4, A315-31-C3W4, A315-31-C425, A315-31-C4E2, A315-31-P0SY, A315-31-P122, A315-31-P17E, A315-31-P1R9, A315-31-P1RK, A315-31-P26U, A315-31-P2QN, A315-31-P3SX, A315-31-P3ZM, A315-33-C1TQ, A315-33-C1VK, A315-33-C1VL, A315-33-C20X, A315-33-C2KG, A315-33-C2XF, A315-33-C3JA, A315-33-C3QG, A315-33-C3TJ, A315-33-C9RA, A315-33-N14U/K, A315-33-P182, A315-33-P1ZE, A315-33-P3XS, A315-33-P40P, A315-33-P4ED, A315-33-P4X3, A315-33-P68T, A315-33-P6HG, A315-33-P6M9, A315-33-P8HD, A315-33-P9XJ, A315-41, A315-41-R001, A315-41-R09W, A315-41-R0GH, A315-41-R132, A315-41-R2W5, A315-41-R3RF, A315-41-R4B9, A315-41-R4C7, A315-41-R4HQ, A315-41-R4RE, A315-41-R4WN, A315-41-R5KU, A315-41-R5MD, A315-41-R9SJ, A315-41G, A315-41G-R0JT, A315-41G-R0TY, A315-41G-R0ZU, A315-41G-R0ZZ, A315-41G-R1A5, A315-41G-R1GR, A315-41G-R1MK, A315-41G-R4BW, A315-41G-R4GZ, A315-41G-R4PC, A315-41G-R531, A315-41G-R531/T011, A315-41G-R5H7, A315-41G-R5J4, A315-41G-R5RJ, A315-41G-R5U3, A315-51-331E, A315-51-33C0, A315-51-33KW, A315-51-33W2, A315-51-348Z, A315-51-34HU, A315-51-34L7, A315-51-350R, A315-51-3588, A315-51-39N0, A315-51-39X3, A315-51-50BU, A315-51-51AY, A315-51-51SL, A315-51-52AB, A315-51-533U, A315-51-53JJ, A315-51-53UC, A315-52-51UD, A315-52-52ZZ, A315-52-57WF, A315-52-P4HZ, A315-53, A315-53-30BS, A315-53-30GC, A315-53-32CK, A315-53-32TF, A315-53-50K5, A315-53-50Y7, A315-53-51GS, A315-53-51X7, A315-53-52XW, A315-53-5303, A315-53-54BX, A315-53-54JP, A315-53-54P9, A315-53-54VR, A315-53-55Y1, A315-53-57R2, A315-53-57WF, A315-53-58EJ, A315-53G, A315-53G-30FR, A315-53G-30P5, A315-53G-313W, A315-53G-38HQ, A315-53G-38NG, A315-53G-500R, A315-53G-503K, A315-53G-50NW, A315-53G-50R4, A315-53G-5106, A315-53G-5122, A315-53G-5209,

Acer Aspire 5: A514-51-55E7, A514-51-55RP, A514-51-58ZJ, A514-51-78BY, A514-51-791X, A514-51G, A514-51G-3147, A514-51G-33VJ, A514-51G-37B1, A515-51-55BQ, A515-51-55FD, A515-51-55NB, A515-51-55XB, A515-51-563W, A515-51-56DN, A515-51-

56VN, A515-51-572Q, A515-51-589E, A515-51-58D3, A515-51-58W1, A515-51-59DP, A515-51-59GA, A515-51-72UR, A515-51-731Q, A515-51-75UY, A515-51-79FM, A515-51-89UP, A515-51G-36TE, A515-51G-37L6, A515-51G-38F8, A515-51G-3915, A515-51G-39H1, A515-51G-39QT, A515-51G-39TX, A515-51G-504G, A515-51G-50JJ, A515-51G-51CA, A515-51G-51MD, A515-51G-51N4, A515-51G-51RL, A515-51G-520Q, A515-51G-526Y, A515-51G-52GK, A515-51G-52LV, A515-51G-52M4, A515-51G-73JF, A515-51G-741E, A515-51G-74VE, A515-51G-750C, A515-51G-751G, A515-51G-77CS, A515-51G-7850, A515-51G-78AS, A515-51G-78HP, A515-52-33ES, A515-52-35TB, A515-52-38GU, A515-52-39FF, A515-52-500D, A515-52-50G0, A515-52-5109, A515-52-51TW, A515-52-526C, A515-52-52PN, A515-52-52RK, A515-52-52S7, A515-52-53DK, A515-52-55FM, A515-52-55JD, A515-52-56UN, A515-52-572L, A515-52-57TN, A515-52-57UF, A515-52-58S9, A515-52-59HS, A515-52-59ZF, A515-52-70X5, A515-52-712G, A515-52-73EW, A515-52-7426, A515-52-76G4, A515-52-776H, A515-52-785L, A515-52-78YZ, A515-52G, A515-52G-34JC, A515-52G-360F, A515-52G-50AC, A515-52G-50VP, A515-52G-51CS, A515-52G-75D1, A515-52G-75X3, A515-52G-75YQ, A515-52G-770F, A515-52G-77VQ, A515-52G-784Z, A515-52G-78AH, A515-52G-78TJ, A515-52G-79CD, A515-53G-35VX, A515-53G-39J6, A515-53G-5137, A515-53G-5269, A515-53G-52CQ, A515-53G-53YL, A515-53G-564C, A515-53G-56M6, A515-53G-5788, A515-53G-57NK, A515-53G-59JC, A515-53G-71NN, A517-51, A517-51G, A517-51G-31UP, A517-51G-34N3, A517-51G-352P, A517-51G-36EC, A517-51G-501Z, A517-51G-50XS, A517-51G-51MQ, A517-51G-51QE, A517-51G-51YM, A517-51G-51ZZ, A517-51G-521J, A517-51G-52ZX, A517-51G-5405, A517-51G-54AU, A517-51G-54ED, A517-51G-54RC, A517-51G-54Z8, A517-51G-55BM, A517-51G-56D0, A517-51G-5746, A517-51G-575X, A517-51G-57ER, A517-51G-817F, A517-51G-81VB, A517-51G-862F, A517-51G-869V, A517-51G-86CN, A517-51G-86SF, A517-51G-876D, A517-51G-88KP, A517-51GP, A517-51GP-5071, A517-51GP-51WV, A517-51GP-57J0, A517-51GP-58J4, A517-51GP-58ZC, A517-51GP-80LB, A517-51GP-84ZT, A517-51GP-88NX, A517-51P, A517-51P-327Z, A517-51P-32GB, A517-51P-32XH, A517-51P-33EK, A517-51P-52N7, A517-51P-542D, A517-51P-55WD, A517-51P-80AG, A517-51P-80HN,

Acer Aspire 5 Pro: A517-51P-39J7, A517-51P-542D, A517-51P-559T, A517-51P-56D4, A517-51P-58KU, A517-51P-80Y1, A517-51P-85Q0,

Acer Aspire 6: A615-51G-50EK, A615-51G-51J6, A615-51G-51MQ, A615-51G-536X, A615-51G-537J, A615-51G-53QF, A615-51G-55QG, A615-51G-57A2, A615-51G-59EA, A615-51G-59JB,

Acer seria Aspire One: AO721, AO721-3070, AO721-3574, V5-121,

Acer Aspire Timeline: 5810TG, M3-581TG-72634G25MNKK, M3-581TG-7376G12MNKK, M3-581TM3-581T-3236,

Acer Aspire TimelineU: M3-481G, M3-481T,

Acer Aspire TimelineX: 3820G, 3820T, 3820T-334G32N, 3820T-334G50I, 4820Z, 4830TG, 5820T-434G50MN, 5820T-522G16MN, 5820T-524G16MN, 5820T-5462G50MNKS, 5820TG, 5820TG-332G32MN, 5820TG-332G64MN, 5820TG-333G50MN, 5820TG-334G32MN, 5820TG-334G50MN, 5820TG-5462G50MN, 5820TG-5464G50MNKS, 5820TG-5464G50MNSS, 5820TG-5464G75MNKS, 5820TG-5612, 5820TG-624G50MN, 5820TG-624G64MN, 5820TG-624G64MNKS, 5820TG-626G64MN, 5820TG-644G75MNKS, 5820TZ, 5820TZG, AS3820G, AS3820T, AS3820T-332G16N, AS3820T-332G32N, AS3820T-332G50N, AS3820T-333G25I, AS3820T-333G25N, AS3820T-333G32N, AS3820TG-524G64N, AS3820TG-524G64N/2002, AS3820TG-528G50N, AS3820TG-544G64N, AS3820TG-5454G64NKS, AS3820TG-5464G75N, AS3820TG-5464G75NKS, AS3820TG-624G50N, AS3820TG-624G64N, AS3820TZ, AS3820TZG, AS3830T, AS3830T-6417, AS3830TG, AS4820G, AS4820T, AS4820T-331G32MN, AS4820T-332G25MN, AS4820T-332G32MN, AS4820T-333G25MN, AS4820T-333G32MI, AS4820T-434G32MN, AS4820T-522G16MN, AS4820T-522G50MN, AS4820T-524G25MN, AS4820T-5452G50MNKS, AS4820TG-332G16MN, AS4820TG-332G25MN, AS4820TG-332G32MN, AS4820TG-332G64MN, AS5820T-353G32MN, AS5820T-354G32MN, AS5820T-354G32MNS, AS5820T-354G50MN, AS5820T-432G32MN, AS5820T-434G32MN, AS5820T-434G50M, AS5820T-434G50MN, AS5820T-522G16MN, AS5820TG-5454G64MN, AS5820TG-5454G64MNKS, AS5820TG-5462G50MN, AS5820TG-5464G50MNSS, AS5820TG-5612, AS5820TG-624G50MN, AS5820TG-624G64MN, AS5820TG-626G64MN, AS5820TZ, AS5830T-6862,

Acer Emachines: E525-901G16,

Acer Extensa: 2000, 2001LC, 2001LM, 2300, 2350, 2500, 2501FLC, 2501LC, 2501LM, 2510, 2520G, 2520G-50R7, 2600, 2900, 2900D, 2900E, 2950, 3000, 3001WLMI, 3002LMI, 3100, 3102, 3550, 4010, 4100, 4120, 4130, 4210, 4220, 4230, 4420, 4430, 4620, 4620Z, 4630, 4630Z, 5010, 5200, 5210, 5235, 5235ZG, 5320, 5520, 5610, 5620, 5620G, 5620Z, 5620ZG, 5630, 5630EZ, 5635, 5635Z, 5635Z-422G16MN, 5635Z-422G25MN, 5635Z-422G25N, 5635Z-432G16MN, 5635Z-432G25MN, 5635Z-433G2, 5635Z-433G25N, 5635Z-433G25NL, 5635Z-434G32N, 5635Z-443G32MN, 5635Z-443G64MN, 5635Z-444G32MN, 5635Z-444G32N, 5635Z-452G32, 5635Z-452G32N, 5635Z-452G32NKK, 5635Z-454G32N, 5635Z-454G50MN, 5635ZG, 700, 710, 710DX, 710TE, 711, 712, 712TE, 7230, 7230E, 7520, 7620, 7630G, 7630ZG, 900, EX5235-332G16MN,

Acer Ferrari: 1000, 1100, 1200, 3000, 3003WLMI, 3020, 3022WLMI, 3040, 3500, 3502LCI, 3502WLCI, ONE 200,

Acer One 14: Z1401, Z1401-N2840, Z1402, Z1402-30BA, Z1402-31B8, Z1402-31ZJ, Z1402-32BJ, Z1402-32G0, Z1402-330Q, Z1402-343F, Z1402-34M3, Z1402-34VY, Z1402-350L, Z1402-3563, Z1402-35NV, Z1402-36M3, Z1402-376H, Z1402-378D, Z1402-38GR,

Acer Timeline: 8371, 8371G, 8371T, 8471, 8571, TM8471, TM8571,

Acer TravelMate: 230XC, 2310, 233X, 234LCI, 2490, 2700, 280, 281XC, 281XV, 283LC, 283LCI, 283XV, 283XVI, 290, 290E, 290LCI, 290LMI, 290X, 290XCI, 290XI, 290XMI, 290XVI, 291FLMI, 291FXCI, 291LCI, 291LMI, 291XCI, 292EFX, 292EFXC, 292EFXCI, 292ELCI, 292ELMI, 292EXC, 292EXCI, 292FLMI, 292FXCI, 292LCI, 292LMI, 292XCI, 3200, 3240, 3270, 3280, 4200, 4210, 4220, 423, 4260, 4270, 4330, 4350, 4400, 4670, 4720, 4730, 4740, 5330, 5360, 5360G, 5360Z, 5520, 5530, 5542, 5600, 5610, 5620, 5710, 5720, 5720G, 5730, 5735, 5735G, 5735G-663G32MNSS, 5735Z, 5740, 5740-333G25N, 5740-433G32MNSS, 5740-434G32N, 5740-5896, 5740D, 5740G, 5740Z, 5740ZG, 5742, 5742-373G32MNSS, 5742G, 5742Z, 5742ZG, 6291, 6292, 6293, 6410, 6460, 6492, 6493, 6495T, 6592G-704G25MN, 6593, 6593-652G16MN, 6593G, 6593G-6219, 6593G-6347, 6593G-9A4G32MN, 6594, 6594G, 6595, 6595-2524G50MIKK, 6595-2524G64MIKK, 6595T, 6595T-2524G50MIKK, 7530, 7730, 7730-872G25MN, 7730G, 7740, 7750, 8001, 8004, 8005, 8007, 8100, 8200, 8210, 8371, 8473, P2510-M-592C, P2510-M-72MF, P2510-M-72RT, P2510-M-734Q, P2510-M-73ZA, P2510-M-75HR, P2510-MG, P253-E, P255-M, P255-MP, TX40-G2-56DD, TX40-G3-M, TX40-G3-MG, TX420-G2-MG, TX50-G1, TX50-G2, TX520-G2-MG,

Emachines: D440, D442, D443, D520, D525, D528, D620, D640, D642, D720, D725, D727, D728, D729Z, D730, D732, D732Z, E430, E440, E442, E443, E510, E520, E525, E527, E528, E529, E620, E625, E627, E628, E630, E640, E640G, E642, E644, E720, E725, E727, E728, E729, E729Z, E730, E730Z, E732, E732Z, EME443, EME644, EME730, EME730Z, G420, G430, G443, G520, G525, G620, G625, G627, G630, G640, G720, G725, G729Z, G730, M2105, M2350, M2352, M2356, M5105, M5124, M5305, M5307, M5309, M5312, M5313, M5405, M5410, M5414, M6410, M6805, M6807, M6809, M6810, M6811, MX4624, MX4625, N-10, N-12, N-14, W4605, W4620, W4630,

Netbook: 250, 350, 355,

Gateway: NV55C, NV56, NV570P04U, NV570P07U, NV570P08U, NV570P09U, NV570P13U-21174G50DNIK, NV570P17U, NV570P17U-10174G50MNIK, NV570P18U, NV570P18U-33214G75MNIK, NV570P20U, NV58, NV59, NV59C, NV73, NV73A, NV78, NV79, NV79C, TC73, TC74, TC78, TC79,

Packard Bell Easy Note: LJ65,

Packard Bell EasyNote: TE69KB