

Lenovo

seria ThinkPad

- T460S-2MCD
- T460S-2NCD
- T460S-2PCD
- T460S-2RCD
- T460S-2YCD
- T460S-31CD
- T460S-32CD
- T460S-33CD
- T460S-34CD
- T460S-3UCD
- T460S
- T460S (20F9-001QAU)
- T460S (20F9-0026AU)
- T460S (20F9-003MAU)
- T460S (20F9002YCD)
- T460S (20F9A02MCD)
- T460S (20F9A02NCD)
- T460S (20F9A02PCD)
- T460S (20F9A02RCD)
- T460S (20F9A031CD)
- T460S (20F9A032CD)
- T460S (20F9A033CD)
- T460S (20F9A034CD)
- T460S (20F9A03UCD)
- T460S (20FA-001AAU)
- T460S (20FA-001BAU)
- T460S (20FA-001EAU)
- T460S (20FA-001FAU)
- T460S (20FA-0026AU)
- T460S (20FA-002UAU)
- T460S (20FA-003YAU)
- T460S (20FA-A01EAU)
- T460S (20FA-A01GAU)
- T460S (20FA-S05A01)
- T460S (20FA-S0BM00)
- T460S (20FA-S0KD00)
- T460S (20FA-S0KE00)
- T460S (20FA-S0NF00)
- T460S (20FA-S11300)
- T460S 20F9
- T460S 20FA
- T470S
- T470S (20HF0000GE)
- T470S (20HF0001GE)
- T470S (20HF0016GE)
- T470S (20HF0047GE)
- T470S (20HF004UGE)
- T470S 20HF
- T470S 20HG
- T470S 20JS
- T470S 20JT
- T470S-20HGS00V00